

## GENERAL DESCRIPTION

An electronic control system supervises and regulates all the parameters of the engine, optimising performance and consumption levels through response in real time to the different operating conditions: this sophisticated latest generation system comprises a single control unit which controls both ignition and injection.

This is the M 3.7.1 version of the proven and reliable BOSCH MOTRONIC system.

## FUNCTIONS OF THE SYSTEM

### Sequential and timed injection (S.E.F.I.)

With this control unit injection is sequential and timed for each cylinder: the injection instant (delivery of fuel into the intake manifolds through the opening of the injectors) is not simultaneous for all the cylinders, but takes place for each cylinder in correspondence with the optimal point of injection, calculated by the control unit following special maps according to the load, speed and temperature of the engine.

### Static ignition

An ignition system has been adopted with "static distribution" (with semi-conductors, without distributor). This solution makes it possible to eliminate rotary components; in addition, it does not produce external sparks thus reducing the risk of interferences; lastly it reduces the number of high voltage cables and connectors; as the power modules for controlling the primary windings of the coil are inside the control unit.

Static ignition takes place through six coils located on the cylinder head.

Each coil directly supplies a spark plug without intermediate cables.

### Metering the air flow rate

The air flow meter adopted is of a more modern design known as the "hot film" type. Outside, the air-flow meter looks like a part of duct between the intake manifold and the air cleaner.

Inside the air-flow meter there is an electronic circuit and a plate that is crossed by the air which passes in the duct.

The film plate is kept at a constant temperature (appr. 120°C above the temperature of the incoming air) by a heating resistance placed in contact with it.

The mass of air flowing through the manifold tends to withdraw heat from the plate: therefore, to keep its temperature constant, a certain current needs to flow through the heating resistance: this current, suitably measured, is proportionate with the mass of flowing air.

**N.B.** This air flow meter measures directly the mass of air (and not the volume as in the previous versions with "floating port"), thereby eliminating problems of temperature, altitude, pressure, etc.

### Cylinder detection

Following the sequential and timed injection system, a timing sensor has been introduced (cam angle sensor): this makes it possible to detect which cylinder is in the bursting stroke when the engine is started, in order to be able to start the correct injection sequence. The sensor is formed of a Hall-effect device by which the voltage signal sent to the control unit "lowers" suddenly when the tooth machined on the camshaft passes in front of the actual sensor; therefore a signal is sent every two turns of the crankshaft.

Conversely, the rpm sensor sends a reference signal for each turn of the engine and each subsequent tooth of the phonic wheel on the flywheel informs the control unit of an increase of the angular position of the crankshaft, so that injection is sent correctly to the suitable cylinder and the spark to the corresponding pair of cylinders.

### Fuel pump

The control logic of the fuel pump carried out by the control unit which is mainly based on the rpm signal immediately cuts off the supply to the pump as soon as the engine stops.

Moreover, the pump will not operate with the key engaged and the engine not running.

In this car, this logic is integrated - in order to further higher the standards of safety - by the **inertial switch** device: this is an electromechanical switch which, in the event of heavy shocks, opens to cut off the circuit that takes the earth to the fuel pump, which stops instantaneously. This device is particularly important as an integration of the safety guaranteed by the logic of the control unit, especially if the car is hit from behind or in the case of other accidents in which the engine does not stop immediately.

### Percentage of exhaust gas recirculation

Nox (nitric oxide) is developed at high temperatures in the combustion chambers.

To reduce these emissions an E.G.R. (Exhaust Gas Recirculation) system is adopted which by recirculating part of the exhaust gases, lowers the temperature, thus the Nox produced, in the combustion chambers. In fact, part of the exhaust gas is withdrawn through the special EGR Valve and re-admitted to the intake box where it is mixed with the intaken air and burnt again in the engine. The EGR valve is modulated by a solenoid valve controlled by the injection control unit and, as a result of the type of control, in addition to reducing the amount of Nox, consumption levels are also optimised.

The percentage of exhaust gas to be returned to the engine is established by the control unit taking account of a specific characteristic curve which depends on the load, speed and temperature of the engine.

### OPERATING LOGIC

#### – Identification of the "operating point":

the "point of operation of the engine" is located mainly through two sensors: the rpm sensor informs the control unit of the speed of rotation of the engine; the air flow meter supplies the value of the mass of air actually entering the cylinders, defining the instantaneous volumetric yield of the engine.

#### – Adjustment of injection times (quantity of fuel):

the control unit controls the injectors extremely quickly and precisely, calculating the opening time on the basis of engine load (rpm and air flow), also taking into account the battery voltage and the temperature of the engine. Injection is "sequential", i.e. the injectors are opened in correspondence of the exhaust stroke of the corresponding cylinder.

#### – Ignition adjustment (calculation of advances):

the control unit calculates the advance on the basis of the engine load (rpm and air flow); the value is also corrected according to the temperature of the intaken air and that of the engine.

#### – Cold starting control:

during cold starts the control unit uses special advance values and injection times.

When a determinate temperature/rpm ratio is reached, the control unit resumes normal operating conditions.

#### – Control of enrichment during acceleration:

upon the need for acceleration, the control unit increases injection in order to reach the required rpm as quickly as possible.

This function takes place through the potentiometer

located on the throttle which instantaneously informs the control unit of the need to accelerate.

#### – Fuel cut-off during deceleration:

with the throttle closed and an engine speed above a certain threshold, the control unit de-activates fuel injection; this way the rpms decrease rapidly towards idle speed reducing the speed and fuel consumption. The cutoff threshold value varies according to the temperature of the engine and the speed of the car.

#### – Control of idle speed:

the adjustment of the engine idle speed is carried out through the special actuator which acts on the throttle by-pass.

This device acts as a regulator for cutting in the various services (e.g. conditioner compressor): in fact, when the throttle is closed, the actuator adjusts the by-pass gap compensating the load required by the services in order to ensure that idle speed is as constant as possible.

#### – Maximum Rpm limiting:

above a certain threshold the control unit automatically stops the injection of fuel preventing the engine from "over-revving".

#### – Combustion control -lambda sensor:-

the oxygen sensor (or "lambda" sensor) informs the control unit of the amount of oxygen at the exhaust, and therefore the correct air-fuel metering.

The optimum mixture is obtained when the lambda coefficient = 1 (optimum stoichiometric mixture). The electric signal sent by the sensor to the control unit changes abruptly when the composition of the mixture departs from lambda = 1. When the mixture is "lean" the control unit increases the amount of fuel, reducing it when the mixture is "rich" so that in this way the engine operates as far as possible around the ideal lambda rating.

The signal from the lambda sensor is processed inside the control unit by a special integrator which prevents sudden "oscillations".

The sensor is heated by an electrical resistance so that it quickly reaches the correct operating temperature (appr. 300 °C).

Through this probe it is therefore possible to adjust engine carburetion precisely. Among other items, this makes it possible to meet emission limit regulations.

#### – Pinging control:

Through pinging sensors the control unit is informed if any pinging or "knocking" occurs and it corrects the spark advance "delaying" it accordingly; a further correction also takes account of the air temperature, in fact when the temperature of the intake air is high, pinging is more accentuated.

The intaken air temperature sensor, to be found just downstream of the air-flow meter, is not used to calculate the engine load but to control the pinging parameters and spark advances.

### – Fuel vapour recovery:

the fuel vapours collected from the various points of the supply circuit in a special activated carbon canister are ducted to the engine where they are burnt: this takes place through a solenoid valve which is opened by the control unit only when the engine is in a condition that allows correct combustion without adversely affecting the operation of the engine: in fact the control unit compensates this amount of incoming fuel by reducing delivery to the injectors.

### – E.G.R. valve control

The percentage of exhaust gas to be returned to the engine is determined by the control unit taking account of a specific characteristic curve which depends on the engine load and speed: recirculation is only activated when the engine speed is between 2500 and 4000 rpm., also in relation to the temperature of the engine (higher recirculation percentage with high temperatures).

### – Connection with the air conditioner compressor:

the control unit is connected with the air conditioner system and it cuts in the compressor in relation to operation of the engine. As this service absorbs a considerable amount of power, the control unit:

- adapts the engine idle speed each time the compressor cuts in; if the engine speed falls below 700 rpm, the compressor is turned off;
- when there is the need for power (high throttle opening speed starting from below 3500 rpm, or full load, or high engine temperature - over 117°C), it momentarily cuts out the compressor
- when the engine is being started the compressor is disabled until normal operating conditions have been reached.

### – Connection with the ALFA ROMEO CODE system

as soon as the Motronic control unit receives the signal that the key has been turned to MARCIA, it "asks" the ALFA ROMEO CODE system for consent to start the engine: this consent is given only if the ALFA ROMEO CODE control unit recognizes the code of the key engaged in the ignition switch as correct. This dialogue between the control units takes place on diagnosis line K already used for the Alfa Romeo Tester.

### – Self-diagnosis:

the key has a **self-diagnosis system**, which continuously monitors the plausibility of the signals from the various sensors and compares them with the limits

allowed: if these limits are exceeded, the system detects a fault and turns on the corresponding warning light on the instrument cluster.

The warning light turns on when the engine is started to indicate the initial test of the entire system (appr. 4 seconds), it then turns off if no errors have been memorised: otherwise it stays on.

For certain parameters, the control unit replaces the abnormal values with suitable mean ones so that the car can "limp" to a point of the Service Network.

These "recovery" values depend on the other correct signals and they are defined individually by the control unit operating logic.

The self-diagnosis system also enables quick and effective location of faults connecting with the ALFA ROMEO Tester (see "Fault-finding"), through which all the errors memorised can be "read". It is also possible to check the operating parameters recorded by the control unit and operate the single actuators to check whether they are working properly.

## COMPONENTS

The electronic control unit receives the signals leading from the **sensors** which "read" the engine operating parameters. It processes them according to a logic stored inside in "maps" which correlate the different parameters in the best way possible and it operates the **actuators** accordingly so that the engine always works with the highest level of regularity and yield.

The sensors are the following:

- engine temperature sensor (**S7**);
- air temperature sensor (**S34**);
- sensor on throttle body (**S38**);
- rpm sensor (**S31**);
- cam angle sensor (**S52**);
- heated lambda sensor (**S35**)
- air-flow meter (**S5**);
- pinging sensors (**S20a** and **s20b**);

The actuators are the following:

- injectors (**S3**);
- ignition coils (**A8**);
- fuel pump (**P18**);
- idle adjustment actuator (**S29**);
- vapour recovery solenoid valve (**M15**);
- E.G.R. solenoid valve (**L46**);

The control unit is also connected with:

- the climate control unit;

- the ALFA ROMEO CODE control unit (**N77**);
- the instrument cluster (**C10**) to which it supplies the signal for turning on the diagnosis warning light and for the rev counter;
- the sensor (**L17**) from which it receives the car speed signal.

The system is completed by three relays: the first two - the main relay (**S41**), and the fuel pump relay **S12a** operate the fuel pump, the injectors, the coils and the other components of the system, while the third - the air-flow meter relay (**S12e**) supplies the corresponding component.

The supply line for the entire system is protected by fuse **S36**, while the control unit is protected by wander fuse (**S46**); another fuse protects the pump (**S47**). Lastly, there is an earth point (**G60**) on the engine. Connector **T1** enables connection with the ALFA ROMEO Tester: this is located inside the car next to the control unit.

## FUNCTIONAL DESCRIPTION

The Motronic control unit **S11** controls and adjusts the entire electronic ignition and injection system; all the system supplies are protected by fuse **S36** (40A).

The control unit is supplied at pin 26 directly by the battery through fuse **S46** (7.5A). At pin 54 it receives the supply from the main relay **S41**, while at pin 56 it receives the "key-operated" supply.

Pins 55, 6, 28 and 34 are earthed and serve as reference respectively for the ignition coils, the injectors, electronic screening and the final power stages.

The main relay **S41**, acts as supply relay for the whole system; it is energized by a control signal - earth - leading from pin 27 of the control unit and consequently sends the supply (12V) to pin 54 of the control unit itself, to the fuel pump relay **S12a**, to the air-flow meter relay **S12a** to the vapour recovery solenoid valve **M15**, to the idle speed actuator **S29**, to the cam angle sensor **S52**, to the EGR solenoid valve **L46** and lastly to the injectors **S3**.

The "key-operated" supply crosses fuse **G389** and supplies the control unit at pin 56 and the primary windings of the coils **A8**.

The supply of the main relay **S41** is energized by a control signal - earth - leading from pin 1 of the control unit **S11**. Consequently, the relay supplies the resistance of the lambda sensor **S35**, the air flow meter relay **S12e**, and of course the fuel pump **P18**; this supply line is protected by a special fuse **S47** (15A).

The earth reaches the pump **P18** via the inertial switch **H20** which cuts off the circuit in the event of impact.

The control unit **S11** receives numerous signals from the different sensors, thereby keeping all the engine operating parameters under control.

Through a frequency signal sent to pins 43 and 16 of the control unit, the rpm sensor **S31** supplies information about the engine rpm; the two above-mentioned signals are very low in intensity and are therefore suitably screened.

The sensor is inductive and detects the number of revolutions of the engine through the change in a magnetic field produced by the passage of the teeth of a "phonic" wheel (60-2 teeth) fitted on the flywheel.

The cam angle sensor **S52** (timing sensor), is supplied at 12 V by the main relay **S41**, and sends a signal in frequency corresponding to the phase to pin 44 of the control unit itself.

The sensor comprises a Hall effect device due to which the voltage signal sent to the control unit "lowers" abruptly when the tooth machined on the camshaft passes in front of the sensor.

The heated lambda sensor **S35** supplies the control unit information about the correct composition of the air-fuel mixture detecting the concentration of oxygen in the exhaust gas; this takes place through the signal sent to pin 12 of the control unit, while pin 11 supplies the reference earth; The sensor is heated by a resistance to make sure that it operates correctly also when the engine is cold; the resistance is supplied by the fuel pump relay **S12a**.

The throttle body sensor **S38**, is supplied by the control unit from pin 59 and connected to the electronic earth at 72 and it sends a signal to pin 73 which is proportionate with the degree of opening of the throttle itself.

The engine temperature sensor **S7**, connected to the electronic earth at pin 72, supplies a signal to pin 78 proportionate with the temperature of the engine coolant, detected with an NTC material (resistance that lowers with the temperature).

The intaken air temperature sensor **S34**, connected to the electronic earth at pin 72, supplies a signal at pin 77 that is proportionate with the temperature of the air entering the intake box, detected with an NTC material (resistance that lowers with the temperature).

The pinging sensors **S20a** and **S20b**, through a frequency signal sent to pins 69 and 70 of the control unit, supplies information about the pinging conditions, while a reference earth leads from pin 71; these two signals are very low in intensity and are therefore suitably screened.

The sensor comprises a piezoelectric plate which detects the vibrations produced when the engine is running, exploiting a particular characteristic of piezoelectric materials which generate an output voltage when subjected to mechanical stresses; this voltage is filtered and analysed by the control unit which corrects the ignition parameters accordingly.

The air flow meter **S5**, is supplied by the special relay **S12e**: from pin 14 of the control unit it receives the

reference earth, while it sends a signal proportionate with the air flow to pin 41.

The air flow meter is of the "heated film" type: a diaphragm is interposed in a measurement channel, through which the intake air flows: this diaphragm is kept at a constant temperature by a heating resistance; the mass of air that crosses the measurement channel tends to withdraw heat from the diaphragm, therefore, in order to maintain its temperature constant, a certain amount of current must flow through the resistance: this current, appropriately measured, is proportionate with the mass of air flowing in the channel.

Relay **S12e**, supplied directly with 12 V by relay **S41**, is energized by the fuel pump relay **S12a** and thus supplies the meter **S5** itself.

On the basis of the signals received from the sensors and of the calculations carried out, the control unit **S11** controls the opening of the single injectors **S3** through special signals - of the duty-cycle type - pins 3 (cyl. 1), 4 (cyl. 3), 5 (cyl. 5) 31 (cyl. 2), 32 (cyl. 4) and 33 (cyl. 6). The injectors receive consent (12V) to open from the main relay **S41**.

The static ignition system is controlled by the control unit directly which automatically adjusts the advance. N.B. the power modules which generate the high voltage pulses are located inside the control unit. The control signals (earth) for the primary windings of the coil **A8** lead from the control unit, while the secondary winding sends the pulse to the spark plugs **A12**: from pin 23: for cylinder 3, pin 24: cylinder 3, pin 24: cylinder 2, pin 25: cylinder 1; pin 50 cylinder 6; pin 51 cylinder 5 and pin 52 cylinder 4.

The primary windings of the coil **A8** are supplied at 12 V ("key- operated") by relay **S42**.

The power modules inside the control unit are connected to earth via pin 55.

The idle speed adjustment actuator **S29** forms a bypass line for the flow of air; this comprises two windings: one opens and the other closes a valve that adjusts the gap of the by-pass section; a safety spring establishes a mean opening value in the event of a failure to this device; the actuator, supplied by the main relay, **S41**, is controlled by the control unit

through the duty-cycle signals of pins 29 (closing) and 2 (opening).

The vapour recovery solenoid valve **M15** allows the passage of the fuel vapours towards the engine intake where they are added to the mixture entering the combustion chamber; this valve, supplied by the main relay **S41**, is opened by the control unit when the engine is under load through a duty cycle signal from pin 36.

The E.G.R. solenoid valve **L46**, controlled by the control unit, operates the actual E.G.R. valve modulating its opening: the latter is a vacuum-operated diaphragm valve: the electropneumatic valve works by changing this vacuum which is withdrawn from the same "takeoff" used for the servobrake.

The solenoid valve is controlled from pin 9 of the control unit while it is supplied at 12 V by main relay **S41**.



The tachometric signal (car speed) reaches the control unit at pin 42 via sensor **L17**; while from pin 47 the control unit sends a "pulse" signal to the cluster **C10** which is proportionate with the number of revolutions of the engine; the signal for the "Check Engine" diagnosis warning light on the cluster **C10** leads from pin 8.

The control unit **S11** is connected with the air conditioning system through pins 48, 64 and 65. This makes it possible to adapt the engine idle speed to the increased power each time the compressor cuts in, or to cut it out in the case of high speed or engine loads. For further details see the "Climate Control" section.

The control unit **S11** is connected by pin 88 with the ALFA ROMEO CODE control unit **N77** via the diagnosis line K; if the ALFA ROMEO CODE does not recognise a correct "key code" it will not enable the Motronic control unit to start the engine.

The control unit possesses a self-diagnosis system which can be used through connection to the ALFA ROMEO Tester at connector **T1**; the tester receives the fault signals from the control unit through the diagnosis lines L - pin 87 - and K - pin 88 -, while the earth leads from **G131** (line K is also used by the ALFA ROMEO CODE system).


**ELECTRONIC CONTROL UNIT**



**CONTROL UNIT PINOUT**

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1. Fuel pump relay consent</li> <li>2. Idle actuator signal (open)</li> <li>3. Injector control, cylinder no.1</li> <li>4. Injector control, cylinder no.3</li> <li>5. Injector control, cylinder no.5</li> <li>6. Earth for final stages (injectors)</li> <li>8. "Check Engine" warning light</li> <li>9. E.G.R. solenoid valve control</li> <li>11. Lambda sensor earth</li> <li>12. Lambda sensor signal</li> <li>14. Earth for air flow meter</li> <li>16. Rpm sensor signal</li> <li>23. Ignition cylinder no.3</li> <li>24. Ignition cylinder no.2</li> <li>25. Ignition cylinder no.1</li> <li>26. Direct 12V supply</li> <li>27. Main relay control</li> <li>28. Electronic earth (sensor screening)</li> <li>29. Idle speed actuator signal (closed)</li> <li>31. Injector control, cylinder no.2</li> <li>32. Injector control, cylinder no.4</li> <li>33. Injector control, cylinder no.6</li> <li>34. Earth for final stages</li> <li>36. Evaporative solenoid valve signal</li> <li>41. Air-flow meter signal</li> </ul> | <ul style="list-style-type: none"> <li>42. Car speed signal output</li> <li>43. Rpm sensor signal</li> <li>44. Camanglesensor signal</li> <li>47. Engine rpm signal output</li> <li>48. Climate control unit relay control</li> <li>50. Ignition cylinder no. 6</li> <li>51. Ignition cylinder no. 5</li> <li>52. Ignition cylinder no. 4</li> <li>54. Supply from main relay 12V</li> <li>55. Earth for ignition</li> <li>56. "Key-operated" supply</li> <li>59. Reference voltage (5V) for throttle sensor</li> <li>64. Climate control system signal (compressor cut in request)</li> <li>65. Climate control system signal (system control)</li> <li>69. Pinging sensor signal 2</li> <li>70. Pinging sensor signal 1</li> <li>71. Earth for pinging sensors</li> <li>72. Electronic earth for sensors</li> <li>73. Throttle angle sensor signal</li> <li>77. Air temperature sensor signal</li> <li>78. Water temperature sensor signal</li> <li>87. Diagnosis, line L</li> <li>88. Diagnosis, line K (also for ALFA ROMEO CODE system)</li> </ul> |
|--|---|

**LOCATION OF COMPONENTS**




3.0 V6 24v

- (•) Black fuse holder
- (••) Red fuseholder
- (•••) Blue fuseholder
- (••••) Violet fuseholder
- (\*) Black base
- (\*\*) Grey base


## CHECKING COMPONENTS

Rpm sensor **(S31)**




| SPECIFICATIONS                                 |              |
|--|--------------|
| Sensor winding resistance 20 °C                | ~ 540 Ω      |
| Distance (gap) between sensor and phonic wheel | 0.8 ÷ 1.5 mm |

Engine temperature sensor **(S7)**



| SPECIFICATIONS   |                |
|------------------|----------------|
| Temperature (°C) | Resistance (Ω) |
| - 10°C           | 8100 ÷ 10770 Ω |
| + 20°C           | 2280 ÷ 2720 Ω  |
| + 80°C           | 292 ÷ 362 Ω    |


Intake air temperature sensor **(S34)**



| SPECIFICATIONS   |                |
|------------------|----------------|
| Temperature (°C) | Resistance (Ω) |
| - 10°C           | 8100 ÷ 10770 Ω |
| + 20°C           | 2280 ÷ 2720 Ω  |
| + 80°C           | 292 ÷ 362 Ω    |




**Air flow meter (S5)**



| SPECIFICATIONS                      |             |
|-------------------------------------|-------------|
| Current that crosses the diaphragm: |             |
| capacity (kg/h)                     | current (A) |
| 0                                   | ≤ 0.25      |
| 640                                 | ≤ 0.80      |


  

Sensor characteristic curve  
 m = capacity  
 U = voltage between pin 4 and 2




- pin 1 - Earth
- pin 2 - Reference earth
- pin 3 - 12 V supply
- pin 4 - Measurement signal
- A = air
- Rs = hot film sensor

**Throttle position sensor (S38)**




| SPECIFICATIONS                   |          |
|----------------------------------|----------|
| Resistance between terminals:    |          |
| 1 - 2 (fixed)                    | ≈ 2 kΩ   |
| 1 - 3 (throttle closed)          | ≈ 1 kΩ   |
| 1 - 3 (throttle completely open) | ≈ 2.7 kΩ |

Cam angle sensor **S52**




| SPECIFICATIONS  |  |
|---|--|
| The voltage signal "lowers" abruptly when the tooth machined on the camshaft passes in front of the sensor: |  |
|   |  |
| Gap value $T \leq 1.5 \text{ mm}$   |  |




pin 1 - Supply  
pin 2 - Signal output  
pin 3 - Earth

Lambda sensor **S35**




| SPECIFICATIONS     |     |
|--------------------|-----|
| Heating resistance | 3 Ω |

Injectors **S3**




| SPECIFICATIONS     |           |
|--------------------|-----------|
| Winding resistance | appr. 6 Ω |

Fuel pump **P18**




| SPECIFICATIONS  |                          |
|-----------------|--------------------------|
| Capacity        | $\geq 120 \text{ l/h}_m$ |
| Pressure        | 4 bar                    |
| Nominal voltage | 12V                      |

Idle adjustment actuator **(S29)**




| SPECIFICATIONS                |        |
|-------------------------------|--------|
| Resistance between terminals: |        |
| 1 - 3                         | ~ 26 Ω |
| 1 - 2                         | ~ 13 Ω |
| 2 - 3                         | ~ 13 Ω |

Ignition coils **(A8)**




| SPECIFICATIONS                  |      |
|---------------------------------|------|
| Primary resistance              | - Ω  |
| Secondary resistance/secondario | - kΩ |

Evaporative solenoid valve **(M15)**




| SPECIFICATIONS   |             |
|--|-------------|
| Duty-cycle signal  | 12 V; 10 Hz |
| Winding ohmic resistance                                 | 26 ± 4 Ω    |
| When not energised the solenoid valve is normally closed |             |

Inertial switch **(H20)**




| SPECIFICATIONS  |  |
|---|--|
| <b>Check continuity between pin NC and C: this continuity is interrupted in the event of a crash; the contact is closed again pressing the special button</b> |  |

E.G.R. solenoid valve **L46**



| SPECIFICATIONS           |              |
|--------------------------|--------------|
| Duty Cycle signal        | 12V; 15.3 Hz |
| Winding ohmic resistance | ~ 30 Ω       |

Pinging sensor **S20a** **S20b**



| SPECIFICATIONS      |                 |         |
|---------------------|-----------------|---------|
| Resonance frequency | > 20 kHz        |         |
| Impedence           | ≥ 1 MΩ          |         |
| Allowed vibration   | for long times  | ≤ 80 g  |
|                     | for short times | ≤ 400 g |

## FAULT-FINDING

The control unit possesses a self-diagnosis function which continuously checks the signals from the various sensors for plausibility and comparing them with the permissible limits: if these limits are exceeded, the system detects a fault and memorises it. It also turns on the special warning light on the instrument cluster.

For certain parameters the control unit replaces the abnormal values with appropriate mean values so that the car can "limp" to a point of the Service Network. These values, known as "recovery" depend on the other correct signals and are defined individually by the control unit operating logic.

The self-diagnosis system also enables quick and effective location of faults connecting with the ALFA ROMEO Tester, through which the errors memorised may be "read". It is also possible to check the operating parameters recorded by the control unit and engage the single actuators to check whether they are working properly.

## Diagnosis using the ALFA TESTER

N.B. Before carrying out diagnosis with the Tester, carry out the preliminary test described below (**TEST A**).

The Tester and electronic control unit should be connected as follows:

1. Power the Tester either through the cigar lighter socket or connecting it directly to the battery using the special cable.

2. Connect the socket of the Tester to the one for the control unit (to be found next to the control unit).

The information the instrument can provide is:

- display of parameters;
- display of errors;
- active diagnosis.

## Error clearing

Before ending diagnosis the contents of the "permanent" memory are cancelled through the Tester.

|   |                |
|---|----------------|
| <b>PRELIMINARY CHECK OF BOSCH M3.7.1 SYSTEM</b> | <b>PROVA A</b> |
|---|----------------|

**NOTE:** Beforehand check that the ALFA ROMEO CODE system is working properly as it may have cut off the supply to the system!

| TEST PROCEDURE |   | RESULT          | CORRECTIVE ACTION  |
|----------------|---|-----------------|--|
| <b>A1</b>      | CHECK FUSE  | OK →            | Carry out <b>step A2</b>   |
|                | – Check the intactness of fuses <b>S36</b> , <b>S46</b> , <b>S47</b> and <b>G389</b>  | <del>OK</del> → | Replace fuses<br><b>S36</b> : 40A<br><b>S46</b> : 7.5A<br><b>S47</b> : 15A<br><b>G389</b> : 10A  |
| <b>A2</b>      | CHECK VOLTAGE   | OK →            | Carry out <b>step A3</b>   |
|                | – Check for 12 V at pin 30 of relays <b>S41</b> and <b>S12a</b> and also at pin 86 of <b>S41</b>  | <del>OK</del> → | Restore the wiring between the battery <b>A1</b> and relays <b>S41</b> and <b>S12a</b> through fuse <b>S47</b>                               |
| <b>A3</b>      | CHECK VOLTAGE   | OK →            | Carry out <b>step A4</b>   |
|                | – With the key turned, check for 12 V at pin 56 of the control unit <b>S11</b>  | <del>OK</del> → | Restore the wiring between the ignition switch <b>B1</b> and the control unit <b>S11</b> through fuse <b>G389</b> and connector <b>G133a</b> |
| <b>A4</b>      | CHECK RELAYS  | OK →            | Carry out <b>step A5</b>   |
|                | – Check that relays <b>S41</b> , <b>S12e</b> and <b>S12a</b> are working properly   | <del>OK</del> → | Replace any faulty relays  |
| <b>A5</b>      | CHECK CONTROL UNIT SUPPLY   | OK →            | Carry out <b>step A6</b>   |
|                | – Check for 12 V at pin 26 of the control unit <b>S11</b> ; with the key turned 12 V also at pin 54 and 56 of <b>S11</b> and appr. 0 V (very low voltage) at pin 1 and 27 of <b>S11</b> | <del>OK</del> → | Restore the wiring between the control unit <b>S11</b> and the relays and between the control unit and fuse <b>S46</b>                       |
| <b>A6</b>      | CHECK EARTH   | OK →            | CONTINUE DIAGNOSIS USING THE ALFA ROMEO TESTER   |
|                | – Check for an earth at pin 6 and 34, 55 e 28. Also check for an earth at pin 85 of <b>S12e</b>   | <del>OK</del> → | Restore the wiring between <b>S11</b> and the relays and earth <b>G131</b>   |

## **ABS SYSTEM (BOSCH ABS 5.3)**

### **INDEX**

|                                  |      |
|----------------------------------|------|
| WIRING DIAGRAM . . . . .         | 31-2 |
| GENERAL DESCRIPTION . . . . .    | 31-3 |
| FUNCTIONAL DESCRIPTION . . . . . | 31-3 |
| LOCATION OF COMPONENTS . . . . . | 31-4 |
| FAULT-FINDING . . . . .          | 31-5 |





## GENERAL DESCRIPTION

The electronic wheel anti-lock system (**BOSCH ABS 5.3**) adjusts the braking pressure transmitted to the wheels preventing loss of road-holding under all tyre and road conditions.

The system has been designed to integrate, and not replace, the normal mechanical braking system, guaranteeing a high degree of safety in the event of a failure: in fact it operates on the same brake fluid as the conventional mechanical circuit.

Four sensors, located on the four wheels, inform the electronic control unit of the speed of each wheel continuously, thereby recording locking situations affecting the wheels, skidding and loss of grip.

In these situations, the control unit suitably operates the solenoid valves that modulate the pressure in the hydraulic circuit, eliminating wheel locking and bringing the car back to the limit of roadholding, which means that the braking distance is reduced to a minimum, without losing control of steering.

The **adjustment solenoid valves** are, in this version of the system, two (one for pressure charging and one for relief) for each wheel.

**In this version, the control unit controls distribution of the braking load in the rear axle, replacing the braking load proportioning valve used previously ("EBD" function: Electronic Brake Distribution).**


For further details on the hydraulic operation of the system see **GROUP 33-BRAKES**.


### Components

#### The system comprises:

- four magnetic induction sensors which read the speed of the wheels: **L28; L29; L30; L31**.
- the integrated electronic and hydraulic control unit **N51**, which houses the following:
  - the electronic control module (CPU)
  - the eight solenoid valves
  - two brake fluid pumps with corresponding motor
  - two damping accumulators and two reservoirs
  - a safety valve
- the connector for self-diagnosis **T8**
- the brake switch **H3** (the same that turns on the stop lights) which signals the system the braking condition.

The ABS includes a self-diagnosis system which continually monitors all the system parameters and components: in the event of a failure or fault, the system

cuts itself off automatically leaving the conventional servo-assisted mechanical braking system operational: the driver is alerted of this situation by a special warning light "ABS"  on the instrument cluster (**C10**).

A fault on the "EBD" function turns on the "handbrake on" warning light .

Suitably connecting to the diagnosis connector (**T8**) located next to the control unit, it is possible to use the signals of the flashing code to quickly locate the faulty component (see "Fault-finding").

The connector **T8** can also be used to connect to the ALFA ROMEO Tester system.

## FUNCTIONAL DESCRIPTION

### System supply:

With a line protected by wander fuse **G125a** (10A) the key-operated voltage supplies pin 15 of the ABS control unit **N51**, the battery voltage reaches pin 17 and 18 of the same **N51** from the line protected by fuse **G125b** (60A).

The electronic control unit is connected to earth via pin 19 of **N51**, while the pump is via pin 16.

### Sensors and solenoid valves:


Directly inside the control unit **N51**, the module is connected with the adjustment solenoid valves, which modulate the pressure on the brakes of the four wheels; outside, it is connected with the four sensors **L28 - L29 - L30 - L31** (pin 3-4, 6-7, 1-2 and 8-9) which signal the speed of the single wheels, and with the brake switch **H3** (pin 14), which sends a consent signal: in fact the ABS system cannot come into operation if the brake pedal is not pressed.

### Self-diagnosis:

When the control unit detects problems concerning the "ABS" through the self-diagnosis system, it sends a signal to the instrument cluster **C10** which turns on the "ABS failure" warning light: this signal is sent from pin 20. If the problems concern the "EBD" function, the handbrake warning light is turned on, from pin 21.

The diagnosis connector **T8** connected to pin 11 and 12 allows connection of the control unit with the ALFA ROMEO Tester or "reading" of the flashing code (see "Fault-finding").

LOCATION OF COMPONENTS





- (•) Blue base
- (••) black fuseholder
- (•••) red fuseholder

## FAULT-FINDING

**AUTOMATIC CHECK UPON IGNITION:** when the car is started the "ABS warning light" on the instrument cluster turns on for appr. 2 secs., then it goes off meaning that the system is working properly. If the warning light stays on, carry out diagnosis using the flashing code, as mentioned follows.

If the warning light does not turn on, carry out **test H**.

**N.B.:** When the control unit detects an error in the "ABS" function and turns on the warning light , it simultaneously deactivates the system, therefore, in these conditions the car brakes only with the conventional system. When the control unit also detects an error of the "EBD" function, it turns on both warning lights  e  . Under these conditions also control of the rear braking distribution is deactivated, and the car must be driven very carefully.

### Fault-Finding using the Flashing Code

The self-diagnosis system with which this system is fitted, makes it possible to quickly locate a faulty component following the instructions of a **FLASHING CODE**, which is activated as follows:

- earth the line of pin 1 of connector **T8** (LIGHT BLUE-WHITE cable)
- power the ABS control unit **N51** (turning the ignition key to MARCIA)

Read the sequence of flashes on the "ABS warning light" on the instrument cluster **C10**:

- after appr. 3 seconds for three times code "12" appears, meaning correct operation: if this does not occur, carry out **test H**
- after another 3 seconds appr. the codes of the errors memorised appear (each repeated three times) at appr. 3 sec. intervals (see table on following page)

- at the end, code "12" appears for another three times, indicating the end of the sequence
- of disconnecting pin 1 of T8, after 2 seconds the system resumes normal operation.

**NOTE:** Resetting the memorised code is obtained by of disconnecting the line of pin 1 of **T8** and engaging the ignition switch 20 times (or using the ALFA ROMEO Tester)

### Fault-finding using the Alfa Romeo Tester

**N.B.** Before carrying out diagnosis with the Tester, perform the preliminary check described later (TEST A); if the warning light is not working properly also carry out TEST H.

The connection between the TESTER and the control unit must be made as follows:

1. Supply the TESTER either through the cigar lighter socket or connecting directly to the battery using the special lead.
2. Connect the TESTER socket to the control unit (the socket is near the control unit).

The instrument can give the following information:

- parameter display;
- error display;
- active diagnosis.

### Activation of diagnosis



Diagnostic conversation is started with the engine stopped and the ignition key at MARCIA.

## Flashing code table

**NOTE:** The error code is formed of two digits and is displayed by a number of flashes equalling the first digit followed by a 1 second pause and then a number of flashes equalling the second digit.

| CODICE  | DESCRIPTION  | CORRECTIVE ACTION  |
|---------|--|--|
| 12      | Start and end of procedure                             | -  |
| No code | Control unit or diagnosis function fault               | Carry out <b>test A</b>                                  |
| 16      | Faulty LH front load solenoid valve                    | Replace the solenoid valve                               |
| 17      | Faulty RH front load solenoid valve                    | Replace the solenoid valve                               |
| 19      | Faulty solenoid valve supply relay                     | Replace the control unit internal relay                  |
| 25      | Damaged phonic wheel (regardless of which)             | Replace the phonic wheel (see GROUP 33)                  |
| 26      | Faulty LH rear load solenoid valve                     | Replace the solenoid valve                               |
| 27      | Faulty RH rear load solenoid valve                     | Replace the solenoid valve                               |
| 28      | Faulty LH front relief solenoid valve                  | Replace the solenoid valve                               |
| 29      | Faulty RH front relief solenoid valve                  | Replace the solenoid valve                               |
| 31      | Faulty LH rear relief solenoid valve                   | Replace the solenoid valve                               |
| 32      | Faulty RH rear relief solenoid valve                   | Replace the solenoid valve                               |
| 35      | Faulty recovery pump                                   | Replace the electric pump integrated in the control unit |
| 37      | Inefficient brake pedal switch                         | Carry out <b>test B</b>                                  |
| 39      | LH front wheel speed sensor absent                     | Carry out <b>test C</b>                                  |
| 41      | LH front wheel speed sensor discontinuous or irregular | Carry out <b>test C</b>                                  |
| 42      | RH front wheel speed sensor absent                     | Carry out <b>test D</b>                                  |
| 43      | RH front wheel speed sensor discontinuous or irregular | Carry out <b>test D</b>                                  |
| 44      | LH rear wheel speed sensor absent                      | Carry out <b>test E</b>                                  |
| 45      | LH rear wheel sensor signal discontinuous or irregular | Carry out <b>test E</b>                                  |
| 46      | RH rear wheel speed sensor absent                      | Carry out <b>test F</b>                                  |
| 47      | RH rear wheel sensor signal discontinuous or irregular | Carry out <b>test F</b>                                  |
| 48      | Low battery voltage                                    | Carry out <b>test G</b>                                  |
| 55      | Faulty electronic control unit                         | Replace the electronic control unit                      |
| 56      | Flashing code activation procedure fault               | Carry out <b>test A</b>                                  |
| 74      | Inefficient warning light wiring on instrument cluster | Carry out <b>test H</b>                                  |

**NOTE:**

If the control unit detects an error concerning the "EBD" function it turns on both warning lights  and . Fault finding through the Flashing Code or Alfa Romeo Tester is necessary.

|                                 |               |
|---------------------------------|---------------|
| <b>PRELIMINARY SYSTEM CHECK</b> | <b>TEST A</b> |
|---------------------------------|---------------|

| TEST PROCEDURE |  | RESULT          | CORRECTIVE ACTION  |
|----------------|--|-----------------|--|
| <b>A1</b>      | CHECK FUSES  | OK →            | Carry out step A2  |
|                | – Check the intactness of wander fuses <b>G125a</b> and <b>G125b</b> | <del>OK</del> → | Replace the fuses<br>- <b>G125a</b> (10A)<br>- <b>G125b</b> (60A)                    |
| <b>A2</b>      | CHECK VOLTAGE  | OK →            | Carry out <b>step A3</b>   |
|                | – Check for 12 V at pin 17 and 18 of <b>N51</b>                      | <del>OK</del> → | Restore the wiring between pin 17 and 18 of <b>N51</b> and fuse <b>G125b</b>         |
| <b>A3</b>      | CHECK VOLTAGE  | OK →            | Carry out <b>step A4</b>   |
|                | – Turn the ignition key and check for 12 V at pin 15 of <b>N51</b>   | <del>OK</del> → | Restore the wiring between pin 15 of <b>N51</b> and fuse <b>G125a</b>                |
| <b>A4</b>      | CHECK EARTH  | OK →            | Carry out <b>step A5</b>   |
|                | – Check that pin 16 of <b>N51</b> is earthed                         | <del>OK</del> → | Restore the wiring between pin 16 of <b>N51</b> and earth <b>G63a</b> or <b>G63b</b> |
| <b>A5</b>      | CHECK EARTH  | OK →            | CONTINUE DIAGNOSIS USING THE ALFA ROMEO TESTER OR FLASHING CODE                      |
|                | – Check that pin 19 of <b>N51</b> is earthed                         | <del>OK</del> → | Restore the wiring between pin 19 of <b>N51</b> and earth <b>G55b</b>                |

|                            |               |
|----------------------------|---------------|
| <b>FAULTY BRAKE SWITCH</b> | <b>TEST B</b> |
|----------------------------|---------------|

| TEST PROCEDURE  | RESULT               | CORRECTIVE ACTION  |
|---|----------------------|--|
| <b>B1</b> CHECK STOP LIGHTS<br>– Check that the stop lights are working properly            | (OK) ➔<br><br>(OK) ➔ | Carry out <b>step B2</b><br><br>Replace the stop light switch <b>H3</b> , or proceed as described in the "STOP LIGHTS" section             |
| <b>B2</b> CHECK VOLTAGE<br>– With the pedal pressed, check for 12 V at pin 14 of <b>N51</b> | (OK) ➔<br><br>(OK) ➔ | Check and if necessary replace the electronic control unit <b>N51</b><br><br>Restore the wiring between pin 14 of <b>N51</b> and <b>H3</b> |

|                                      |               |
|--------------------------------------|---------------|
| <b>LH FRONT SENSOR NOT CONNECTED</b> | <b>TEST C</b> |
|--------------------------------------|---------------|

| TEST PROCEDURE  | RESULT               | CORRECTIVE ACTION   |
|---|----------------------|---|
| <b>C1</b> CHECK OPEN CIRCUIT<br>– Turn the key and check for an open circuit between pin 7 and 6 of <b>N51</b>  | (OK) ➔<br><br>(OK) ➔ | Carry out <b>step C2</b><br><br>Carry out <b>step C3</b>  |
| <b>C2</b> CHECK CONTINUITY<br>– Disconnect sensor <b>L29</b> and check continuity between the sensor and pin 7 of <b>N51</b> , and between the sensor and pin 6 of <b>N51</b> | (OK) ➔<br><br>(OK) ➔ | Check and if necessary replace sensor <b>L29</b> .<br><br>Restore the wiring between <b>L29</b> and <b>N51</b>  |
| <b>C3</b> CHECK OPEN CIRCUIT<br>– Disconnect sensor <b>L29</b> and check for an open circuit between pin 7 and 6 of <b>N51</b> (wiring side)                                  | (OK) ➔<br><br>(OK) ➔ | Check and if necessary replace sensor <b>L29</b> .<br><br>Restore the wiring eliminating the short circuit between the cables connecting <b>L29</b> with <b>N51</b> |

|                                      |               |
|--------------------------------------|---------------|
| <b>RH FRONT SENSOR NOT CONNECTED</b> | <b>TEST D</b> |
|--------------------------------------|---------------|

|           | TEST PROCEDURE  | RESULT          | CORRECTIVE ACTION   |
|-----------|---|-----------------|---|
| <b>D1</b> | CHECK OPEN CIRCUIT  | OK →            | Carry out <b>step D2</b>  |
|           | – Turn the key and check for an open circuit between pin 4 and 3 of <b>N51</b>  | <del>OK</del> → | Carry out <b>step D3</b>  |
| <b>D2</b> | CHECK CONTINUITY  | OK →            | Check and if necessary replace sensor <b>L28</b> .  |
|           | – Disconnect sensor <b>L28</b> and check for continuity between the sensor and pin 4 of <b>N51</b> , and between the sensor and pin 3 of <b>N51</b> | <del>OK</del> → | Restore the wiring between <b>L28</b> and <b>N51</b>  |
| <b>D3</b> | CHECK OPEN CIRCUIT  | OK →            | Check and if necessary replace sensor <b>L28</b> .  |
|           | – Disconnect sensor <b>L28</b> and check for an open circuit between pin 4 and 3 of <b>N51</b> (wiring side)  | <del>OK</del> → | Restore the wiring eliminating the short circuit between the cables connecting <b>L28</b> with <b>N51</b> |

|                                     |               |
|-------------------------------------|---------------|
| <b>LH REAR SENSOR NOT CONNECTED</b> | <b>TEST E</b> |
|-------------------------------------|---------------|

|           | TEST PROCEDURE  | RESULT          | CORRECTIVE ACTION   |
|-----------|---|-----------------|---|
| <b>E1</b> | CHECK OPEN CIRCUIT  | OK →            | Carry out <b>step E2</b>  |
|           | – Turn the key and check for an open circuit between pin 8 and 9 of <b>N51</b>  | <del>OK</del> → | Carry out <b>step E3</b>  |
| <b>E2</b> | CHECK CONTINUITY  | OK →            | Check and if necessary replace sensor <b>L31</b> .  |
|           | – Disconnect sensor <b>L31</b> and check continuity between the sensor and pin 8 of <b>N51</b> , and between the sensor and pin 9 of <b>N51</b> | <del>OK</del> → | Restore the wiring between <b>L31</b> and <b>N51</b>  |
| <b>E3</b> | CHECK OPEN CIRCUIT  | OK →            | Check and if necessary replace sensor <b>L31</b> .  |
|           | – Disconnect sensor <b>L31</b> and check for an open circuit between pin 8 and 9 of <b>N51</b> (wiring side)                                    | <del>OK</del> → | Restore the wiring eliminating the short circuit between the cables connecting <b>L31</b> with <b>N51</b> |

|                                     |               |
|-------------------------------------|---------------|
| <b>RH REAR SENSOR NOT CONNECTED</b> | <b>TEST F</b> |
|-------------------------------------|---------------|

|           | TEST PROCEDURE  | RESULT            | CORRECTIVE ACTION  |
|-----------|---|-------------------|--|
| <b>F1</b> | CHECK OPEN CIRCUIT  | (OK) →            | Carry out <b>step F2</b>   |
|           | – Turn the key and check for an open circuit between pin 1 and 2 of <b>N51</b>  | <del>(OK)</del> → | Carry out <b>step F3</b>   |
| <b>F2</b> | CHECK CONTINUITY  | (OK) →            | Check and if necessary replace sensor <b>L30</b> .   |
|           | – Disconnect sensor <b>L30</b> and check continuity between the sensor and pin 1 of <b>N51</b> , and between the sensor and pin 2 of <b>N51</b> | <del>(OK)</del> → | Restore the wiring between <b>L30</b> and <b>N51</b>   |
| <b>F3</b> | CHECK OPEN CIRCUIT  | (OK) →            | Check and if necessary replace sensor <b>L30</b> .   |
|           | – Disconnect sensor <b>L28</b> and check for an open circuit between pin 1 and 2 of <b>N51</b> (wiring side)                                    | <del>(OK)</del> → | Restore the wiring eliminating the short circuit between the cables connecting <b>L30</b> con <b>N51</b> |

|                                    |               |
|------------------------------------|---------------|
| <b>INSUFFICIENT SUPPLY VOLTAGE</b> | <b>TEST G</b> |
|------------------------------------|---------------|

|           | TEST PROCEDURE   | RESULT            | CORRECTIVE ACTION  |
|-----------|--|-------------------|--|
| <b>G1</b> | CHECK VOLTAGE  | (OK) →            | Carry out <b>step G2</b>   |
|           | – Check that the battery voltage is 12V                                | <del>(OK)</del> → | Restore the correct voltage charging or changing the battery <b>A1</b>   |
| <b>G2</b> | CHECK VOLTAGE  | (OK) →            | Carry out <b>step G3</b>   |
|           | – Check for a voltage of 12 V at pin 17 and 18 of <b>N51</b>           | <del>(OK)</del> → | Restore the wiring between pin 17 and 18 of <b>N51</b> and the battery <b>A1</b> , via fuse <b>G125b</b>               |
| <b>G3</b> | CHECK VOLTAGE  | (OK) →            | CONTINUE DIAGNOSIS USING THE ALFA ROMEO TESTER   |
|           | – With the ignition key turned, check for 12 V at pin 15 of <b>N51</b> | <del>(OK)</del> → | Restore the wiring between pin 15 of <b>N51</b> and the key-operated cut out relay <b>I108</b> , via fuse <b>G125a</b> |



|  |               |
|--|---------------|
| <b>"ABS" WARNING LIGHT NOT WORKING (*)</b> | <b>TEST H</b> |
|--|---------------|

| TEST PROCEDURE |  | RESULT  | CORRECTIVE ACTION   |
|----------------|--|---|---|
| <b>H1</b>      | <b>CHECK CONTINUITY</b>  | <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; margin-right: 5px;">OK</div> <div style="font-size: 20px; margin-right: 5px;">▶</div> </div>            | Carry out <b>step H2</b>  |
|                | – Check continuity between pin 12 of <b>N51</b> and pin 1 of connector <b>T8</b> and between pin 11 of <b>N51</b> and pin 3 of <b>T8</b> | <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; margin-right: 5px;"><del>OK</del></div> <div style="font-size: 20px; margin-right: 5px;">▶</div> </div> | Restore the wiring between <b>N51</b> and connector <b>T8</b>           |
| <b>H2</b>      | <b>CHECK EARTH SIGNAL</b>  | <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; margin-right: 5px;">OK</div> <div style="font-size: 20px; margin-right: 5px;">▶</div> </div>            | Replace the ABS warning light bulb on the instrument cluster <b>C10</b> |
|                | – Turn the ignition key and for a few seconds, check for 0V at pin A18 of the instrument cluster <b>C10</b>                              | <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; margin-right: 5px;"><del>OK</del></div> <div style="font-size: 20px; margin-right: 5px;">▶</div> </div> | Carry out <b>step H3</b>  |
| <b>H3</b>      | <b>CHECK EARTH SIGNAL</b>  | <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; margin-right: 5px;">OK</div> <div style="font-size: 20px; margin-right: 5px;">▶</div> </div>            | Restore the wiring between <b>N51</b> and <b>C10</b>                    |
|                | – Turn the key and for a few seconds, check for 0V at pin 20 of <b>N51</b>   | <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; margin-right: 5px;"><del>OK</del></div> <div style="font-size: 20px; margin-right: 5px;">▶</div> </div> | Replace the electronic control unit <b>N51</b>                          |

(\*) To check whether the "EBD" warning light is working properly, simply pull the handbrake! In the event of a fault, proceed as described in the "Instrument Cluster" section.

# KEY TO COMPONENTS

**A STARTING - RECHARGING**

- A1 Battery
- A3 Alternator, with integrated voltage regulator
- A8 Ignition coil
- A8a Ignition coil A
- A8b Ignition coil B
- A11 Starter motor
- A12 Spark plugs

**B MANUAL ELECTRICAL CONTROLS**

- B1 Ignition switch
- B9 Heated rearscreen control switch
- B10 Fog lights control switch
- B11 Rear fog guards control switch
- B12 Hazard warning lights control switch
- B16 Instrument panel light dimmer button
- B21a Right front power window control switch (on RH door)
- B21b Right front power window control switch (on LH door)
- B36 Wing mirror control switch
- B40 Trip meter reset switch
- B47 Sun roof motor control switch
- B53 Front power window switch with automatic mechanism
- B61 Fuel flap opening switch
- B68 Steering column lever unit
- B69 Headlamp aiming device
- B87 Luggage compartment opening switch with glove box light
- B98 Air recirculation switch
- B99 Hood release switch
- B100 Hood cover release switch
- B101 Automatic hood control switch

**C INSTRUMENTATION**

- C10 Instrument cluster
- C18 Auxiliary instrument cluster

**D WARNING LIGHTS**

- D31 Anti-theft device led indicator
- D43 Signalling led for automatic hood

**E EXTERIOR LIGHTS**

- E1a LH front direction indicator bulb
- E1b RH front direction indicator bulb
- E2a LH front side light bulb
- E2b RH front side light bulb
- E5a LH low beam light bulb
- E5b RH low beam light bulb
- E7a LH high beam light bulb
- E7b RH low beam light bulb
- E9a LH direction indicator light bulb
- E9b RH direction indicator light bulb
- E10a LH fog light bulb
- E10b RH fog light bulb
- E17a LH number plate light bulb
- E17b RH number plate light bulb
- E19 RH tail light cluster
- E20 LH tail light cluster

- E28 Third stop light
- E30 Rear RH fog guard/reversing light
- E31 Rear LH fog guard/reversing light

**F INTERIOR LIGHTS**

- F3 Passenger compartment ceiling light
- F5 Luggage compartment light
- F8a Heating/ventilation controls light bulb a
- F8b Heating ventilation controls light bulb b
- F23 RH foot well light
- F24 LH foot well light
- F45 Light on LH front door
- F46 Light on RH front door

**G FUSEBOX - CONNECTORS - EARTHS**

- G1 Fusebox
- G3 Fusebox terminal connector
- G4 Free fuse
- G21 Connector for RH front door wiring
- G23 Connector for LH front door wiring
- G38 Air conditioner wiring connector
- G43 Connector for heating and ventilation control wiring
- G53a RH engine compartment earth
- G53b LH engine compartment earth
- G55b LH side panel earth
- G56 Branch terminal board
- G60 Injection wiring earth
- G63a RH rear earth
- G63b LH rear earth
- G65 Coaxial cable for aerial
- G73 Connector for rear services
- G73b Connector for rear services
- G84 Console wiring connector
- G92 Luggage compartment earth
- G99 Connector for dashboard wiring/engine wiring
- G115 Connector for tow bar trailer socket
- G124 ABS system connector
- G125a ABS system fuse
- G125b ABS system fuse
- G131 Earth on upper cover
- G131a Earth on upper cover
- G131b Earth on upper cover
- G133a Connector for electronic injection wiring A
- G133b Connector for electronic injection wiring B
- G148b Earth under dashboard LH
- G193 Connector for electric aerial wiring
- G219 Connector for sun roof
- G254 Fuse for engine fan
- G255 Fuse for heating and ventilation fan
- G261 Fuse for sun roof
- G308 Connector for engine sensors
- G310 Fuse for RH front power window
- G312a Power window and door lock fuse
- G312b Power window and door lock fuse
- G313 Connector for additional conditioner wiring
- G314a Connector for engine wiring / conditioner wiring A
- G314b Connector for engine wiring / conditioner wiring B
- G320 Connector for rear loudspeaker cables

- G337 Connector for conditioner syst./injection syst.
- G338 Coil and injectors connector
- G380 Airbag connector
- G381 Earth for airbag
- G383 Connector for airbag capsule
- G384 Services supply fuse
- G385 Connector for wiring in front bumper
- G389 Fuse for ALFA ROMEO CODE unit
- G391 Rear fog guard fuse
- G399 Dashboard connector for automatic hood
- G400 Rear connector for automatic hood
- G401 Fuse for automatic hood system
- G402 Fuse for automatic hood control unit
- G403 Fuse for automatic hood switch
- G404 Fuse for automatic hood switch

**H SWITCHES**

- H1 Handbrake switch
- H2 Reversing light switch
- H3 Stop lights switch
- H9 RH front brake pad switch
- H10 LH front brake pad switch
- H17 Brake fluid minimum level switch
- H20 Inertial switch
- H24 Luggage compartment light switch
- H44 Bonnet anti-theft device switch
- H51 Sun roof stroke limit switch
- H55a RH hood closing switch
- H55b LH hood closing switch
- H56a RH hood cover closing switch
- H56b LH hood cover closing switch
- H57 "5th arc" raised switch
- H58 Intermediate "5th arc" switch
- H59 Hood cover raised switch
- H60 Hood position switch

**I RELAYS**

- I2 Heated rearscreen relay
- I3 Horn relay
- I17 Fog light relay
- I29 Fuel pump relay
- I35 Key-operated supply relay
- I49 Low beam relay
- I50 High beam relay
- I52 Luggage compartment opening relay
- I53 Fuel flap opening relay
- I58 Sun roof relay
- I64 Side lights relay
- I99 Engine cooling fan 1st speed relay
- I99a Engine cooling fan 1st speed relay
- I99b Engine cooling fan 1st speed relay
- I100 Engine cooling fan 2nd speed relay
- I106 Hood release relay
- I106b Hood emergency release relay
- I107a Hood cover release relay
- I107b Hood cover release relay
- I108 Key-operated supply cutoff relay
- I109 Anti-theft switch relay
- I112a RH hood closing relay
- I112b LH hood closing relay

- I113 Hood cover closing relay
- I116 Automatic hood control relay
- I117 Automatic hood electric pump relay

**L SENDERS**

- L2 Minimum engine oil pressure
- L9 Sender for fuel level gauge
- L10 Sender for engine coolant temperature gauge and max. temperature warning light contact
- L17 Speedometer sensor
- L21 Pierbourg valve
- L28 RH front phonic wheel inductive sensor
- L29 LH front phonic wheel inductive sensor
- L30 RH rear phonic wheel inductive sensor
- L31 LH rear phonic wheel inductive sensor
- L33 Two-level thermal contact
- L46 E.G.R. solenoid valve

**M ELETTRMAGNETS - SOLENOID VALVES**

- M12 Luggage compartment opening actuator electromagnet
- M13 Fuel flap opening actuator electromagnet
- M15 Evaporation solenoid valve
- M26a LH hood release actuator electromagnet
- M26b RH hood release actuator electromagnet
- M27 Hood cover release actuator electromagnet
- M27a LH hood cover release actuator electromagnet
- M27b RH hood cover release actuator electromagnet
- M28 Automatic hood solenoid valve

**N ELECTRONIC DEVICES - INTERMITTENCES- TIMERS**

- N1 Power module
- N13 Hazard warning lights and direction indicators intermittence
- N14 Electronic windscreen wiper intermittence
- N18 Electronic headlamp switching device
- N23 Ignition control unit
- N25 Rear fog guard electronic device
- N45 Anti-theft device control unit
- N51 Hydraulic unit with ABS control unit
- N53 Anti-disturbance condenser on luggage compartment light
- N60 Sun roof control unit
- N67 Remote control signal receiver
- N77 ALFA ROMEO CODE control unit
- N78 ALFA ROMEO CODE receiver
- N79 Car radio supply antisturbance condenser
- N80 Hood cover release timer
- N81 Automatically-operated hood Control unit
- N82 Integrated services control unit

**O SERVICES**

- O1 Heated rearscreen
- O2a High tone horn
- O2b Low tone horn
- O3 Aerial
- O4 Car radio
- O5a RH front loud-speaker
- O5b LH front loud-speaker
- O5c RH rear loud-speaker

- O5d LH rear loud-speaker
- O6 Cigar lighter - current socket
- O18 RH wing mirror defroster
- O19 LH wing mirror defroster
- O22 Additional engine fan resistance
- O22a Additional engine fan resistance
- O22b Additional engine fan resistance
- O31a RH Tweeter loud-speaker
- O31b LH Tweeter loud-speaker
- O37 Rear subwoofer speaker

**P ELECTRIC MOTORS**

- P2 Engine cooling fan
- P2a Engine cooling fan
- P2b Engine cooling fan
- P8 LH wing mirror motor
- P9 RH wing mirror motor
- P10 Front RH door lock motor
- P11 Front LH door lock motor
- P14 Front RH power window motor
- P15 Front LH power window motor
- P18 Electric fuel pump
- P19 Windscreen and rearscreen washer pump
- P24 Sun roof motor
- P27 Windscreen wiper motor with control unit
- P35a RH headlamp aiming motor
- P35b LH headlamp aiming motor
- P51 Automatic hood control pump

**Q HEATING/VENTILATION - AIR CONDITIONING**

- Q1 Heater fan
- Q4 Heater fan control
- Q5 Heater fan speed adjustment resistance
- Q9 Minimum pressure switch
- Q11 Compressor electromagnetic coupling
- Q15 Heating and ventilation fan relay
- Q20 Min. and max. pressure switch
- Q22 Electromagnetic coupling relay
- Q27 Air recirculation flap control motor
- Q32 Auxiliary relay for heating and ventilation
- Q39 Fuse for conditioning system
- Q40 Fuse for conditioning system
- Q41 Set of relay and fuses for air conditioner
- Q42 Conditioner fan delay device
- Q65 Fuse for conditioning system
- Q68 Compressor and air recirculation engagement switches
- Q69

Heater fan 1st speed relay

**R SAFETY DEVICES**

- R22 Airbag control unit
- R23 Capsule on steering wheel for airbag
- R27 Passenger's side airbag capsule
- R28 Capsule on RH pretensioner
- R29 Capsule on LH pretensioner


**S ELECTRONIC INJECTION**


- S3 Elettroinjectors
- S5 Air flow meter
- S7 Engine temperature sensor
- S11 Motronic control unit
- S12a Motronic fuel pump relay
- S12c Phase variator relay
- S12e Air flow meter relay
- S15 Phase variator
- S16 Altitude corrector
- S20 Pinging sensor
- S20a Pinging sensor a
- S20b Pinging sensor b
- S29 Idle adjustment actuator
- S31 Rpm and crankshaft position sensor
- S34 Air temperature sensor
- S35 Heated lambda probe
- S36 Fuse for injection relay
- S38 Sensor on throttle body
- S39 1st cylinder detection sensor
- S41 Main relay
- S42 Secondary relay
- S43 Absolute pressure sensor
- S45 Lambda probe fuse
- S46 Fuse for Motronic supply
- S47 Fuse for fuel pump
- S52 Cam angle sensor

**T DIAGNOSIS**

- T1 Connector for ALFA TESTER (Motronic and ALFA ROMEO CODE)
- T3 Connector for ALFA TESTER (airbag)
- T7 Connector for ALFA TESTER (anti-theft device)
- T8 Connector for ALFA TESTER (ABS)
- T13 Diagnosis connector for ALFA ROMEO TESTER (automatic hood)

# COMPONENTS AND CONNECTORS



















|   |                    |   |                    |
|---|--------------------|---|--------------------|
| <p>Heated rearscreen control switch</p>                     | <p><b>B9</b></p>   | <p>Fog lights control switch</p>                            | <p><b>B10</b></p>  |
|   |                    |   |                    |
| <p>Rear fog guards control switch</p>                       | <p><b>B11</b></p>  | <p>Hazard warning lights control switch</p>                 | <p><b>B12</b></p>  |
|   |                    |   |                    |
| <p>Instrument panel light dimmer button</p>                 | <p><b>B16</b></p>  | <p>Right front power window control switch (on RH door)</p> | <p><b>B21a</b></p> |
|   |                    |   |                    |
| <p>Right front power window control switch (on LH door)</p> | <p><b>B21b</b></p> | <p>Wing mirror control switch</p>                           | <p><b>B36</b></p>  |
|   |                    |   |                    |


|   |                       |                                      |                       |
|---|-----------------------|--------------------------------------|-----------------------|
| <p>Trip meter reset switch</p>                            | <p><b>B40</b></p>     | <p>Sun roof motor control switch</p> | <p><b>B47</b></p>     |
|   |                       |                                      | <p>GTV</p>            |
| <p>Front power window switch with automatic mechanism</p> | <p><b>B53</b></p>     | <p>Fuel flap opening switch</p>      | <p><b>B61</b></p>     |
|   |                       |                                      |                       |
| <p>Steering column lever unit</p>                         | <p><b>B68</b> [A]</p> | <p>Steering column lever unit</p>    | <p><b>B68</b> [B]</p> |
|   |                       |                                      |                       |
| <p>Steering column lever unit</p>                         | <p><b>B68</b> [C]</p> | <p>Steering column lever unit</p>    | <p><b>B68</b> [D]</p> |
|   |                       |                                      |                       |

|   |                            |  |   |
|---|----------------------------|--|---|
| <p>Steering column lever unit</p>   | <p><b>B68</b> <b>E</b></p> | <p>Headlamp aiming device</p>  | <p><b>B69</b></p>   |
|    |                            |    |   |
| <p>Luggage compartment opening switch with glove box light</p>                      | <p><b>B87</b></p>          | <p>Air recirculation switch</p>  | <p><b>B98</b></p>   |
|   |                            |   |    |
| <p>Hood release switch</p>  | <p><b>B99</b></p>          | <p>Hood release switch</p>   | <p><b>B99</b></p>   |
|  |                            |  |  |
| <p>Hood cover release switch</p>  | <p><b>B100</b></p>         | <p>Hood cover release switch</p>   | <p><b>B100</b></p>  |
|  |                            |  |  |


Automatic hood control switch (B101)











Instrument cluster (C10) A



Instrument cluster (C10) B




|                                   |            |                                   |
|-----------------------------------|------------|-----------------------------------|
| Auxiliary instrument cluster      |            | <b>C18</b>                        |
|                                   |            |                                   |
| Auxiliary instrument cluster      |            | <b>C18</b>                        |
| 3.0 V6 24v                        |            |                                   |
|                                   |            |                                   |
| Anti-theft device led indicator   | <b>D31</b> | Signalling led for automatic hood |
|                                   |            |                                   |
| LH front direction indicator bulb | <b>E1a</b> | RH front direction indicator bulb |
|                                   |            |                                   |


|   |            |  |            |
|---|------------|--|------------|
| LH front side light bulb  | <b>E2a</b> | RH front side light bulb   | <b>E2b</b> |
|    |            |    |            |
| LH low beam light bulb  | <b>E5a</b> | RH low beam light bulb   | <b>E5b</b> |
|   |            |   |            |
| LH high beam light bulb   | <b>E7a</b> | RH low beam light bulb   | <b>E7b</b> |
|  |            |  |            |
| LH direction indicator light bulb   | <b>E9a</b> | RH direction indicator light bulb  | <b>E9b</b> |
|  |            |  |            |






|                                   |                    |                                   |                    |
|-----------------------------------|--------------------|-----------------------------------|--------------------|
| <p>LH fog light bulb</p>          | <p><b>E10a</b></p> | <p>RH fog light bulb</p>          | <p><b>E10b</b></p> |
|                                   |                    |                                   |                    |
| <p>LH number plate light bulb</p> | <p><b>E17a</b></p> | <p>RH number plate light bulb</p> | <p><b>E17b</b></p> |
|                                   |                    |                                   |                    |
| <p>RH tail light cluster</p>      | <p><b>E19</b></p>  | <p>LH tail light cluster</p>      | <p><b>E20</b></p>  |
|                                   |                    |                                   |                    |
| <p>Third stop light</p>           | <p><b>E28</b></p>  | <p>Third stop light</p>           | <p><b>E28</b></p>  |
| <p>GTV</p>                        |                    | <p>SPIDER</p>                     |                    |

|   |            |   |            |
|---|------------|---|------------|
| Rear RH fog guard/reversing light         | <b>E30</b> | Rear LH fog guard/reversing light         | <b>E31</b> |
|   |            |   |            |
| Passenger compartment ceiling light       | <b>F3</b>  | Luggage compartment light                 | <b>F5</b>  |
|   |            |   |            |
| Heating/ventilation controls light bulb a | <b>F8a</b> | Heating ventilation controls light bulb b | <b>F8b</b> |
|   |            |   |            |
| RH foot well light                        | <b>F23</b> | LH foot well light                        | <b>F24</b> |
|   |            |   |            |










Connector for RH front door wiring (door side)

**G21**







- 1 1.5PNK-BLK — 
  - 1.5PNK-BLK • 05a
  - 1.5PNK-BLK • 031a
- 2 1.5PPL-BLK — 
  - 1.5PPL-BLK • 05a
  - 1.5PPL-BLK • 031a
- 3 RED • F46
- 4 PPL-WHT • F46
- 5 1BRN-WHT • 018
- 6 GRN-BLK • B21a
- 7 GRN • B21a
- 8 LTB • P9
- 9 N.C.
- 10 N.C.
- 11 1.5GRY • P9
- 12 1.5YEL-RED • P9
- 13 N.C.

- 14 N.C.
- 15 1YEL • P10 A
- 16 1GRY • P10 A
- 17 WHT • P10 A
- 18 LTB • P10 A
- 19 GRY-GRN • P10 B
- 20 1.5PPL-WHT • P14
- 21 PNK • B21a
- 22 1.5BLK — 
  - 1BLK • 018
  - BLK • B21a
  - BLK • P10 B
  - BLK • B21a
- 23 1.5WHT-RED • P14

Connector for RH front door wiring (vehicle side)







G21



- |   |  |
|---|--|
| <u>1</u> 1.5PNK-BLK • O4 [A]                                | <u>15</u> 1YEL —◇— 1YEL • G23<br>1YEL • N82 [B]                                |
| <u>2</u> 1.5BLK-PPL • O4 [A]                                | <u>16</u> 1GRY —◇— 1GRY • G23<br>1GRY • N82 [B]                                |
| <u>3</u> RED —◇— 1ORN-BLU • G1 [G]                          | <u>17</u> WHT —◇— WHT • G23<br>WHT • N82 [B]                                   |
| <u>4</u> 1PPL-WHT —◇— PPL • N82 [C]<br>1PPL-WHT • G23       | <u>18</u> LTB —◇— LTB • G23<br>LTB • N82 [B]                                   |
| <u>5</u> 1BRN-WHT —◇— 1BRN-WHT • G23<br>1.5BRN-WHT • G1 [D] | <u>19</u> GRY-GRN —◇— GRY-GRN • G124<br>GRY-GRN • C10 [A]<br>GRY-GRN • N82 [B] |
| <u>6</u> 1GRN-BLK • N82 [A]                                 | <u>20</u> 1.5PPL-WHT • N82 [A]   |
| <u>7</u> 1GRN • N82 [A]                                     | <u>21</u> PNK —◇— PNK • G23<br>PNK • G310                                      |
| <u>8</u> LTB-WHT • G84                                      | <u>22</u> 1.5BLK • G148b   |
| <u>9</u> N.C.   | <u>23</u> 1.5WHT-RED • N82 [A]   |
| <u>10</u> N.C.  |  |
| <u>11</u> GRY-GRN • G84                                     |  |
| <u>12</u> YEL-RED —◇— YEL-RED • G84                         |  |
| <u>13</u> N.C.  |  |
| <u>14</u> N.C.  |  |





Connector for LH front door wiring (door side)

G23




Connector for LH front door wiring (vehicle side)

G23




- |  |  |
|--|--|
| <p><u>1</u> 1.5RED-BLK • (O4) [A]</p> <p><u>2</u> 1.5WHT-BLK • (O4) [A]</p> <p><u>3</u> RED —◇— 1ORN-BLU • (G1) [G]<br/>RED • G21</p> <p><u>4</u> 1PPL-WHT —◇— PPL • (N82) [C]<br/>1PPL-WHT • G21</p> <p><u>5</u> 1BRN-WHT —◇— 1BRN-WHT • G21<br/>1.5BRN-WHT • (G1) [D]</p> <p><u>6</u> 1GRN-YEL • (N82) [A]</p> <p><u>7</u> 1GRN-WHT • (N82) [A]</p> <p><u>8</u> LTB-RED • G84</p> <p><u>9</u> 1ORN-BLK • (N82) [A]</p> <p><u>10</u> 1ORN • (N82) [A]</p> <p><u>11</u> GRY-RED • G84</p> <p><u>12</u> YEL-RED —◇— GRY-RED • G84</p> <p><u>13</u> 1.5PPL-YEL • (N82) [A]</p> <p><u>14</u> 1.5WHT-GRN • (N82) [A]</p> | <p><u>15</u> 1YEL —◇— 1YEL • G21<br/>1YEL • (N82) [B]</p> <p><u>16</u> 1GRY —◇— 1GRY • G21<br/>1GRY • (N82) [B]</p> <p><u>17</u> WHT —◇— WHT • G21<br/>WHT • (N82) [B]</p> <p><u>18</u> LTB —◇— LTB • G21<br/>LTB • (N82) [B]</p> <p><u>19</u> GRY-YEL —◇— GRY-YEL • G99<br/>GRY-YEL • (C10) [A]<br/>GRY-YEL • (N82) [B]</p> <p><u>20</u> N.C.</p> <p><u>21</u> PNK —◇— PNK • G21<br/>PNK • (G310)</p> <p><u>22</u> 1.5BLK • G148b</p> <p><u>23</u> N.C.</p> |
|--|--|


Air conditioner wiring connector **G38**




Connector for heating and ventilation control wiring **G43**




Connector for heating and ventilation control wiring **G43**






RH engine compartment earth **G53a**
















|                           |            |
|---------------------------|------------|
| Luggage compartment earth | <b>G92</b> |
|---------------------------|------------|



|  |            |
|--|------------|
| Connector for dashboard wiring/engine wiring | <b>G99</b> |
|--|------------|




|                      |              |                 |
|----------------------|--------------|-----------------|
| ABS system connector |              | <b>G124</b>     |
|                      |              |                 |
| ABS system fuse      | <b>G125a</b> | ABS system fuse |
|                      |              |                 |
| Earth on upper cover |              | <b>G131</b>     |
|                      |              |                 |
| Earth on upper cover |              | <b>G131</b>     |
|                      |              | 3.0 V6 24v      |




Connector for electronic injection wiring A (engine)

G133a




Connector for electronic injection wiring A (engine)

G133a








Connector for electronic injection wiring B (dashboard)

G133b








|  |                    |  |                    |
|--|--------------------|--|--------------------|
| <p>Fuse for engine fan</p>   | <p><b>G254</b></p> | <p>Fuse for engine fan</p>   | <p><b>G254</b></p> |
| <p>2.0 T.S. 16v</p> <p>10RED • G1 — 6RED</p> <p>6RED • P2</p> <p>4RED • P2a — 4RED • P2b — 6RED</p>  |                    | <p>2.0 V6 TB<br/>3.0 V6</p> <p>10RED • G1 — 2.5RED</p> <p>10RED • G1 — 6RED</p> <p>6RED • P2</p> <p>2.5RED • G314b</p> |                    |
| <p>Fuse for engine fan</p>   | <p><b>G254</b></p> | <p>Fuse for heating and ventilation fan</p>  | <p><b>G255</b></p> |
| <p>3.0 V6 24v</p> <p>10RED • G1 — 2.5RED</p> <p>4RED • P2</p> <p>2.5RED • P2b — 2.5RED • P2a — 4RED</p>  |                    | <p>2.5GRY-RED • G313</p> <p>10RED • G1 — 2.5RED</p>  |                    |
| <p>Fuse for sun roof</p>   |                    | <p><b>G261</b></p>   |                    |
| <p>GTV</p> <p>4RED • G1 — 1.5RED</p> <p>1.5RED-BLK • I58</p>   |                    |  |                    |
| <p>Connector for engine sensors</p>  |                    |  | <p><b>G308</b></p> |
| <p>2.0 T.S. 16v</p> <p>1GRY-BLK • L2 A</p> <p>2.5RED-BLK • A11 B</p> <p>1GRY-YEL • A3 C</p> <p>A 1GRY-BLK • C10 B</p> <p>B 2.5RED-BLK • B1 A</p> <p>C 1GRY-YEL • C10 B</p> |                    |  |                    |

|   |             |  |
|---|-------------|--|
| Connector for engine sensors                |             | <b>G308</b>  |
|   |             | <div style="border: 1px solid black; padding: 2px; display: inline-block;">2.0 V6 TB</div><br><div style="border: 1px solid black; padding: 2px; display: inline-block;">3.0 V6</div><br><div style="border: 1px solid black; padding: 2px; display: inline-block;">3.0 V6 24v</div>   |
| Fuse for RH front power window              | <b>G310</b> | Power window and door lock fuse  |
|   |             |  |
| Power window and door lock fuse             |             | <b>G312b</b>   |
|   |             |  |
| Connector for additional conditioner wiring |             | <b>G313</b>  |
|   |             | <div style="border: 1px solid black; padding: 2px; display: inline-block;">2.0 T.S. 16v</div><br><div style="border: 1px solid black; padding: 2px; display: inline-block;">2.0 V6 TB</div><br><div style="border: 1px solid black; padding: 2px; display: inline-block;">2.0 V6 TB</div><br><div style="border: 1px solid black; padding: 2px; display: inline-block;">3.0-V6</div> |

|   |                     |
|---|---------------------|
| <p>Connector for additional conditioner wiring</p>        | <p><b>G313</b></p>  |
| <p>3.0 V6 24v</p>   |                     |
| <p>Connector for engine wiring / conditioner wiring A</p> | <p><b>G314a</b></p> |
| <p>2.0 V6 TB<br/>3.0 V6</p>                               |                     |
| <p>Connector for engine wiring / conditioner wiring B</p> | <p><b>G314b</b></p> |
| <p>2.0 V6 TB<br/>3.0 V6</p>                               |                     |
| <p>Connector for rear loudspeaker cables</p>              | <p><b>G320</b></p>  |
| <p>GTV</p>  |                     |


Connector for rear loudspeaker cables **G320**

SPIDER




Connector for conditioner syst./injection syst. **G337**

2.0 T.S. 16v




Connector for conditioner syst./injection syst. **G337**

2.0 V6 TB




Connector for conditioner syst./injection syst. **G337**

3.0 V6




Connector for conditioner syst./injection syst. **G337**

3.0 V6 24v




Coil and injectors connector **G338**


3.0 V6 24v






Airbag connector **G380**




Earth for airbag **G381**






Fuse for ALFA ROMEO CODE unit

G389




Rear fog guard fuse

G391



Dashboard connector for automatic hood


G399





Rear connector for automatic hood

G400 **A**





|  |                      |  |             |
|--|----------------------|--|-------------|
| Rear connector for automatic hood  |                      | <b>G400</b> <b>B</b>   |             |
| <p>1 YEL-RED • N82 <b>B</b> 2 1 YEL-RED • N82 <b>B</b><br/>         1 RED-BLK • G402 3<br/>         PNK-BLK • I122b PNK-BLK 10<br/>         PNK-BLK • I106b<br/>         GRN-WHT • N81 <b>D</b> 1<br/>         2 YEL-RED • N81 <b>D</b><br/>         3 RED-BLK • N81 <b>D</b><br/>         10 PNK-BLK • N81 <b>D</b></p> |                      |  |             |
| Rear connector for automatic hood  | <b>G400</b> <b>C</b> | Fuse for automatic hood system   | <b>G401</b> |
| <p>A 6 BLK • G63b 4 BLK • P51 A<br/>         6 RED • G401 B 4 RED • I117 B</p>   |                      | <p>6 RED • G400c<br/>         6 RED • A1</p>   |             |
| Fuse for automatic hood control unit   | <b>G402</b>          | Fuse for automatic hood switch   | <b>G403</b> |
| <p>1 RED-BLK • A1<br/>         1 RED-BLK • G400b</p>   |                      | <p>4 RED • A1<br/>         ORN • I106b<br/>         2.50RN • I107<br/>         2.50RN • I106<br/>         2.50RN • I112a<br/>         2.50RN • I112b<br/>         2.50RN • I113<br/>         4 ORN</p> |             |
| Fuse for automatic hood switch   | <b>G404</b>          | Handbrake switch   | <b>H1</b>   |
| <p>4 RED • G1<br/>         1.5 RED<br/>         1.5 RED-BLK • I116</p>   |                      | <p>WHT-BLK • G1 <b>E</b> WHT-BLK</p>   |             |

|   |                   |  |                   |
|---|-------------------|--|-------------------|
| <p>Reversing light switch</p>           | <p><b>H2</b></p>  | <p>Stop lights switch</p>              | <p><b>H3</b></p>  |
|   |                   |  |                   |
| <p>RH front brake pad switch</p>        | <p><b>H9</b></p>  | <p>LH front brake pad switch</p>       | <p><b>H10</b></p> |
|   |                   |  |                   |
| <p>Brake fluid minimum level switch</p> | <p><b>H17</b></p> | <p>Inertial switch</p>                 | <p><b>H20</b></p> |
|   |                   |  |                   |
| <p>Luggage compartment light switch</p> | <p><b>H24</b></p> | <p>Bonnet anti-theft device switch</p> | <p><b>H44</b></p> |
|   |                   |  |                   |

|  |  |
|--|--|
| <p>RH hood closing switch</p> <p><b>H55a</b></p>       | <p>LH hood closing switch</p> <p><b>H55b</b></p>           |
| <p>RH hood cover closing switch</p> <p><b>H56a</b></p> | <p>LH hood cover closing switch</p> <p><b>H56b</b></p>     |
| <p>Intermediate "5th arc" switch</p> <p><b>H58</b></p> | <p>Hood position switch</p> <p><b>H60</b></p>              |
| <p>Fog light relay</p> <p><b>I17</b></p>               | <p>Luggage compartment opening relay</p> <p><b>I52</b></p> |

|  |            |   |            |
|--|------------|---|------------|
| <p>Fuel flap opening relay</p>   | <p>I53</p> | <p>Sun roof relay</p>   | <p>I58</p> |
| <p> <b>GTV</b> 4RED • G384 — 2.5RED 30<br/> <b>SPIDER</b> 4ORN • G384 — 2.5ORN 30<br/>                 GRN-BLK • G73<br/>                 2.5GRN-BLK • M13 87<br/>                 1LTB-BLK • I108 — LTB-BLK 86             </p> |            | <p> <b>GTV</b><br/>                 1.5RED-BLK • G261 30<br/>                 1LTB • G1 H — 1LTB 85<br/>                 1.5BLK • G148b — BLK 86<br/>                 1.5RED-BLK • G84 87             </p>            |            |
| <p>Engine cooling fan 1st speed relay</p>  |            |   | <p>I99</p> |
| <p>                 WHT-BLK • L33 85<br/>                 2.5BLK • G53a 87<br/>                 1LTB-RED • I100 — 1LTB-RED 86<br/>                 1.5RED • G1 A             </p>  |            | <p>                 1PNK-WHT • G133a 85 2.0 T.S. 16v<br/>                 2.5LTB-WHT • O22 30 3.0 V6 24v<br/>                 2.5WHT • O22 30<br/>                 1ORN — 1.5ORN • G99 86 3.0 V6 24v             </p> |            |
| <p>Engine cooling fan 1st speed relay</p>  |            |   | <p>I99</p> |
| <p>                 1PNK-WHT • G133a 85<br/>                 2.5BLK • G53a 87<br/>                 1.5RED • G1 A — 1LTB-RED 86             </p>  |            | <p>                 2.5WHT • O22a 30<br/>                 2.5WHT • O22b             </p>  |            |
| <p>Engine cooling fan 1st speed relay</p>  |            |   | <p>I99</p> |
| <p>                 WHT-BLK • L33 — WHT-BLK 85<br/>                 WHT-BLK • Q42<br/>                 2.5BLK • G53a 87<br/>                 1.5ORN • G99 — 1ORN 86             </p>   |            | <p>                 2.5LTB-WHT — 2.5LTB-WHT • O22a 30<br/>                 2.5LTB-WHT • O22a             </p>   |            |
































|   |              |
|---|--------------|
| <p>Hood cover release relay</p>         | <p>I107a</p> |
|   |              |
| <p>Hood cover release relay</p>         | <p>I107b</p> |
|   |              |
| <p>Key-operated supply cutoff relay</p> | <p>I108</p>  |
|   |              |
| <p>RH hood closing relay</p>            | <p>I112a</p> |
|   |              |













|                              |        |                                    |
|------------------------------|--------|------------------------------------|
| LH hood closing relay        |        | (I112b)                            |
|                              |        |                                    |
| Hood cover closing relay     |        | (I113)                             |
|                              |        |                                    |
| Automatic hood control relay | (I116) | Automatic hood electric pump relay |
|                              |        |                                    |
| Minimum engine oil pressure  | (L2)   | Sender for fuel level gauge        |
|                              |        |                                    |









|  |                   |  |                   |
|--|-------------------|--|-------------------|
| <p>Sender for engine coolant temperature gauge and max. temperature warning light contact</p>  | <p><b>L10</b></p> | <p>Sender for engine coolant temperature gauge and max. temperature warning light contact</p>  | <p><b>L10</b></p> |
| <p>2.0 T.S. 16v</p>  <p>GRY-GRN • C18 1</p> <p>GRY-RED • C18 2</p>                              |                   | <p>3.0 V6<br/>2.0 V6 TB</p>  <p>GRY-RED • C18</p> <p>GRY-GRN • C18</p>             |                   |
| <p>Sender for engine coolant temperature gauge and max. temperature warning light contact</p>  | <p><b>L10</b></p> | <p>Speedometer sensor</p>  | <p><b>L17</b></p> |
| <p>3.0 V6 24v</p>  <p>GRY-GRN • G133a 1</p> <p>GRY-RED • G133a 2</p>                           |                   |  <p>ORN • C10 B 3</p> <p>LTB • G133a</p> <p>LTB • C10 B 2</p> <p>BLK • G53b 1</p> |                   |
| <p>Pierbourg valve</p>   | <p><b>L21</b></p> | <p>RH front phonic wheel inductive sensor</p>  | <p><b>L28</b></p> |
| <p>2.0 V6 TB</p>  <p>1GRN-BLK • S12a 1GRN-BLK</p> <p>1ORN-BLK • S35</p> <p>1LTB-RED • N23</p> |                   |  <p>WHT • N51</p> <p>BRN • N51</p>   |                   |
| <p>LH front phonic wheel inductive sensor</p>  | <p><b>L29</b></p> | <p>RH rear phonic wheel inductive sensor</p>   | <p><b>L30</b></p> |
|  <p>GRN • N51</p> <p>BRN • N51</p>  |                   |  <p>RED • N51</p> <p>BRN • N51</p>   |                   |

|   |                   |  |                   |
|---|-------------------|--|-------------------|
| <p>LH rear phonic wheel inductive sensor</p>  | <p><b>L31</b></p> | <p>Two-level thermal contact</p>   | <p><b>L33</b></p> |
|                      |                   | <p>2.0 V6 TB<br/>3.0 V6</p>  |                   |
| <p>Two-level thermal contact</p>  | <p><b>L33</b></p> | <p>E.G.R. solenoid valve</p>   | <p><b>L46</b></p> |
| <p>3.0 V6 24v</p>    |                   | <p>3.0 V6</p>               |                   |
| <p>E.G.R. solenoid valve</p>  | <p><b>L46</b></p> | <p>Luggage compartment opening actuator electromagnet</p>  | <p><b>M12</b></p> |
| <p>3.0 V6 24v</p>  |                   |                            |                   |
| <p>Fuel flap opening actuator electromagnet</p>   | <p><b>M13</b></p> | <p>Evaporation solenoid valve</p>  | <p><b>M15</b></p> |
|                    |                   | <p>2.0 T.S. 16v</p>        |                   |


|   |                    |   |                    |
|---|--------------------|---|--------------------|
| <p>Evaporation solenoid valve</p>   | <p><b>M15</b></p>  | <p>Evaporation solenoid valve</p>   | <p><b>M15</b></p>  |
| <p>2.0 V6 TB</p>  |                    | <p>3.0 V6<br/>3.0 V6 24v</p>  |                    |
|    |                    |     |                    |
| <p>LH hood release actuator electromagnet</p>                                       | <p><b>M26a</b></p> | <p>LH hood release actuator electromagnet</p>   | <p><b>M26a</b></p> |
| <p>SPIDER</p>   |                    |    |                    |
|   |                    |    |                    |
| <p>RH hood release actuator electromagnet</p>                                       | <p><b>M26b</b></p> | <p>RH hood release actuator electromagnet</p>   | <p><b>M26b</b></p> |
| <p>SPIDER</p>   |                    |  |                    |
|  |                    |   |                    |
| <p>Hood cover release actuator electromagnet</p>                                    | <p><b>M27</b></p>  | <p>LH hood cover release actuator electromagnet</p>                                   | <p><b>M27a</b></p> |
|  |                    | <p>SPIDER</p>   |                    |
|  |                    |   |                    |

|  |                     |   |                     |
|--|---------------------|---|---------------------|
| <p>RH hood cover release actuator electromagnet</p>  | <p><b>M27b</b></p>  | <p>Automatic hood solenoid valve</p>  | <p><b>M28 A</b></p> |
| <p>SPIDER</p>  |                     |                     |                     |
| <p>Automatic hood solenoid valve</p>   | <p><b>M28 B</b></p> | <p>Automatic hood solenoid valve</p>  | <p><b>M28 C</b></p> |
|               |                     |                    |                     |
| <p>Automatic hood solenoid valve</p>   | <p><b>M28 D</b></p> | <p>Automatic hood solenoid valve</p>  | <p><b>M28 E</b></p> |
|              |                     |                   |                     |
| <p>Automatic hood solenoid valve</p>   | <p><b>M28 F</b></p> | <p>Power module</p>   | <p><b>N1</b></p>    |
|              |                     | <p>2.0 V6 TB</p>  |                     |




|  |                      |   |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
|--|----------------------|---|---|----------------------------|-------------|------------------------|---|-------------|------------------|---------|-------------|------------------|------------------|-------------|--------------------|--------------------|-------------|----------------------|--------------------|-------------|----------------|----------------|-------------|--|--|
| <p>Rear fog guard electronic device</p>  | <p><b>N25</b></p>    | <p>Rear fog guard electronic device</p>   | <p><b>N45</b> <b>A</b></p>  |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
|  <p>10RN • G391 6<br/>3 GRN • GRN • C10 A<br/>1GRN • I17<br/>1GRY-WHT • G73 8<br/>1GRY • C10 A 5<br/>1BLK • G148b 4<br/>1 1BRN • 1GRY • B68 D<br/>1GRY • G1 F</p>  |                      |  <p>1.5RED • N45 B<br/>10RED • G1<br/>BLU • G99 2<br/>PPL • G99 1<br/>1.5BLK • G53a 9<br/>10RN • I109<br/>1.5RED 3<br/>6 LTB-WHT • T7</p>       |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| <p>Rear fog guard electronic device</p>  |                      | <p><b>N45</b> <b>B</b></p>  |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
|  <p>1LTB • G1 I<br/>1LTB • E9b<br/>10RN • I109<br/>10RED • G1<br/>1.5RED • N45 A<br/>1LTB 1<br/>2 1LTB-BLK<br/>1LTB-BLK • G1 I<br/>1LTB-BLK • E9a<br/>1.5RED 7<br/>GRY-YEL • G99 8<br/>GRY-GRN • G99 9<br/>17 PNK • G99<br/>12 ORN<br/>1.5ORN • G99<br/>18 WHT • WHT • H44</p>   |                      |   |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| <p>Hydraulic unit with ABS control unit</p>  |                      |   | <p><b>N51</b></p>   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| <table border="0"> <tr> <td>1 RED • L30</td> <td>9 BRN • L31</td> <td>17 4RED • 4RED • G125b</td> <td rowspan="8">  </td> </tr> <tr> <td>2 BRN • L30</td> <td>11 1WHT-RED • T8</td> <td>18 4RED</td> </tr> <tr> <td>3 WHT • L28</td> <td>12 1LTB-WHT • T8</td> <td>19 2.5BLK • G55b</td> </tr> <tr> <td>4 BRN • L28</td> <td>14 1RED-BLK • G124</td> <td>20 1LTB-WHT • G124</td> </tr> <tr> <td>6 GRN • L29</td> <td>15 1.5PNK-BLK • G124</td> <td>21 1LTB-YEL • G124</td> </tr> <tr> <td>7 BRN • L29</td> <td>16 4BLK • G63b</td> <td>22 1LTB • G124</td> </tr> <tr> <td>8 YEL • L31</td> <td></td> <td></td> </tr> </table> |                      |   |   | 1 RED • L30                | 9 BRN • L31 | 17 4RED • 4RED • G125b |  | 2 BRN • L30 | 11 1WHT-RED • T8 | 18 4RED | 3 WHT • L28 | 12 1LTB-WHT • T8 | 19 2.5BLK • G55b | 4 BRN • L28 | 14 1RED-BLK • G124 | 20 1LTB-WHT • G124 | 6 GRN • L29 | 15 1.5PNK-BLK • G124 | 21 1LTB-YEL • G124 | 7 BRN • L29 | 16 4BLK • G63b | 22 1LTB • G124 | 8 YEL • L31 |  |  |
| 1 RED • L30  | 9 BRN • L31          | 17 4RED • 4RED • G125b  |  |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| 2 BRN • L30  | 11 1WHT-RED • T8     | 18 4RED   |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| 3 WHT • L28  | 12 1LTB-WHT • T8     | 19 2.5BLK • G55b  |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| 4 BRN • L28  | 14 1RED-BLK • G124   | 20 1LTB-WHT • G124  |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| 6 GRN • L29  | 15 1.5PNK-BLK • G124 | 21 1LTB-YEL • G124  |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| 7 BRN • L29  | 16 4BLK • G63b       | 22 1LTB • G124  |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| 8 YEL • L31  |                      |   |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
| <p>Remote control signal receiver</p>  | <p><b>N67</b></p>    | <p>ALFA ROMEO CODE control unit</p>   |   | <p><b>N77</b> <b>A</b></p> |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |
|  <p>LTB • G73b 6<br/>5 WHT • G73b<br/>1LTB-RED • G1 E<br/>LTB-RED 7<br/>1RED • G1 E<br/>RED 3<br/>2 WHT-BLU • G73<br/>4 BLK • G63b</p>   |                      |  <p>1RED • G133b 3<br/>1LTB-RED • G99<br/>1LTB-RED 8<br/>1WHT-GRN • G133b 6<br/>1WHT-RED • G133b 5<br/>1BLK • G133b 4<br/>2 ORN-WHT • G99</p> |   |                            |             |                        |   |             |                  |         |             |                  |                  |             |                    |                    |             |                      |                    |             |                |                |             |  |  |


ALFA ROMEO CODE control unit (N77) B




Hood cover release timer (N80)



Automatic-operated hood control unit (N81) A




Automatic-operated hood control unit (N81) B







Automatic-operated hood control unit (N81) (D)




Integrated services control unit (N82) (A)











Integrated services control unit (N82) (B)











Integrated services control unit (N82) (C)



















|                              |                           |                              |                           |
|------------------------------|---------------------------|------------------------------|---------------------------|
| <p>Heated rearscreen</p>     | <p><b>O1</b></p>          | <p>High tone horn</p>        | <p><b>O2a</b></p>         |
|                              |                           |                              |                           |
| <p>Low tone horn</p>         | <p><b>O2b</b></p>         | <p>Car radio</p>             | <p><b>O4</b> <b>A</b></p> |
|                              |                           |                              |                           |
| <p>Car radio</p>             | <p><b>O4</b> <b>B</b></p> | <p>RH front loud-speaker</p> | <p><b>O5a</b></p>         |
|                              |                           |                              |                           |
| <p>LH front loud-speaker</p> | <p><b>O5b</b></p>         | <p>RH rear loud-speaker</p>  | <p><b>O5c</b></p>         |
|                              |                           |                              | <p>GTV</p>                |

|  |                    |  |                    |
|--|--------------------|--|--------------------|
| <p>LH rear loud-speaker</p>  | <p><b>O5d</b></p>  | <p>Cigar lighter - current socket</p>  | <p><b>O6</b></p>   |
| <p>GTV</p>  |                    |    |                    |
| <p>RH wing mirror defroster</p>  | <p><b>O18</b></p>  | <p>LH wing mirror defroster</p>  | <p><b>O19</b></p>  |
|            |                    |   |                    |
| <p>Additional engine fan resistance</p>  | <p><b>O22</b></p>  | <p>Additional engine fan resistance</p>  | <p><b>O22</b></p>  |
|            |                    |  |                    |
| <p>Additional engine fan resistance</p>  | <p><b>O22a</b></p> | <p>Additional engine fan resistance</p>  | <p><b>O22a</b></p> |
|           |                    |  |                    |

|   |             |  |             |
|---|-------------|--|-------------|
| <p>Additional engine fan resistance</p>   | <p>O22a</p> | <p>Additional engine fan resistance</p>  | <p>O22b</p> |
|                  |             |                  |             |
| <p>Additional engine fan resistance</p>   | <p>O22b</p> | <p>Additional engine fan resistance</p>  | <p>O22b</p> |
|                 |             |                 |             |
| <p>RH Tweeter loud-speaker</p>  | <p>O31a</p> | <p>LH Tweeter loud-speaker</p>   | <p>O31b</p> |
|                |             |                |             |
| <p>Rear subwoofer speaker</p>   | <p>O37a</p> | <p>Rear subwoofer speaker</p>  | <p>O37b</p> |
| <p>SPIDER</p>  |             | <p>SPIDER</p>  |             |

|                           |                   |                           |                   |
|---------------------------|-------------------|---------------------------|-------------------|
| <p>Engine cooling fan</p> | <p><b>P2</b></p>  | <p>Engine cooling fan</p> | <p><b>P2</b></p>  |
|                           |                   |                           |                   |
| <p>Engine cooling fan</p> | <p><b>P2a</b></p> | <p>Engine cooling fan</p> | <p><b>P2a</b></p> |
|                           |                   |                           |                   |
| <p>Engine cooling fan</p> | <p><b>P2a</b></p> | <p>Engine cooling fan</p> | <p><b>P2b</b></p> |
|                           |                   |                           |                   |
| <p>Engine cooling fan</p> | <p><b>P2b</b></p> | <p>Engine cooling fan</p> | <p><b>P2b</b></p> |
|                           |                   |                           |                   |

|   |                            |  |                            |
|---|----------------------------|--|----------------------------|
| <p>LH wing mirror motor</p>   | <p><b>P8</b></p>           | <p>RH wing mirror motor</p>  | <p><b>P9</b></p>           |
|  <p>019</p> <p>LTB-RED • G23 A</p> <p>1.5YEL-RED • G23 B</p> <p>1.5GRY-RED • G23 C</p>                         |                            |  <p>018</p> <p>LTB • G21 A</p> <p>1.5YEL-RED • G21 B</p> <p>1.5GRY • G21 C</p> |                            |
| <p>Front RH door lock motor</p>   | <p><b>P10</b> <b>A</b></p> | <p>Front RH door lock motor</p>  | <p><b>P10</b> <b>B</b></p> |
|  <p>1.5BLK • G21 —◇— BLK 5</p> <p>LTB • G21 4</p> <p>WHT • G21 3</p> <p>1GRY • G21 2</p> <p>1YEL • G21 1</p>  |                            |  <p>GRY-YEL • G23 2</p> <p>1.5BLK • G23 —◇— BLK 1</p>                         |                            |
| <p>Front LH door lock motor</p>   | <p><b>P11</b> <b>A</b></p> | <p>Front LH door lock motor</p>  | <p><b>P11</b> <b>B</b></p> |
|  <p>1.5BLK • G23 —◇— BLK 5</p> <p>LTB • G23 4</p> <p>WHT • G23 3</p> <p>1GRY • G23 2</p> <p>1YEL • G23 1</p> |                            |  <p>GRY-YEL • G23 2</p> <p>1.5BLK • G23 —◇— BLK 1</p>                        |                            |
| <p>Front RH power window motor</p>  | <p><b>P14</b></p>          | <p>Front LH power window motor</p>   | <p><b>P15</b></p>          |
|  <p>1.5WHT-RED • G21 A</p> <p>1.5PPL-WHT • G21 B</p>   |                            |  <p>1.5PPL-YEL • G23 A</p> <p>1.5WHT-GRN • G23 B</p>                         |                            |

|   |                            |  |                            |
|---|----------------------------|--|----------------------------|
| <p>Electric fuel pump</p>   | <p><b>P18</b></p>          | <p>Windscreen and rearscreen washer pump</p>   | <p><b>P19</b></p>          |
|    |                            |    |                            |
| <p>Windscreen wiper motor with control unit</p>                                     | <p><b>P27</b> <b>A</b></p> | <p>Windscreen wiper motor with control unit</p>                                      | <p><b>P27</b> <b>B</b></p> |
|   |                            |   |                            |
| <p>RH headlamp aiming motor</p>   | <p><b>P35a</b></p>         | <p>LH headlamp aiming motor</p>  | <p><b>P35b</b></p>         |
|  |                            |  |                            |
| <p>Automatic hood control pump</p>  | <p><b>P51</b></p>          | <p>Heater fan</p>  | <p><b>Q1</b></p>           |
|  |                            |  |                            |


|   |             |   |             |
|---|-------------|---|-------------|
| <p>Heater fan</p>                             | <p>Q1</p>   | <p>Heater fan control</p>                     | <p>Q4 A</p> |
|   |             |   |             |
| <p>Heater fan control</p>                     | <p>Q4 B</p> | <p>Heater fan control</p>                     | <p>Q4 B</p> |
|   |             |   |             |
| <p>Heater fan speed adjustment resistance</p> | <p>Q5</p>   | <p>Heater fan speed adjustment resistance</p> | <p>Q5</p>   |
|   |             |   |             |
| <p>Minimum pressure switch</p>                | <p>Q9</p>   | <p>Compressor electromagnetic coupling</p>    | <p>Q11</p>  |
|   |             |   |             |












|  |                   |                                      |                   |
|--|-------------------|--------------------------------------|-------------------|
| <p>Heating and ventilation fan relay</p> | <p><b>Q15</b></p> | <p>Min. and max. pressure switch</p> | <p><b>Q20</b></p> |
|  |                   |                                      |                   |
| <p>Min. and max. pressure switch</p>     | <p><b>Q20</b></p> | <p>Min. and max. pressure switch</p> | <p><b>Q20</b></p> |
|  |                   |                                      |                   |
| <p>Min. and max. pressure switch</p>     |                   |                                      | <p><b>Q20</b></p> |
|  |                   |                                      |                   |
| <p>Electromagnetic coupling relay</p>    |                   |                                      | <p><b>Q22</b></p> |
|  |                   |                                      |                   |

|  |  |
|--|--|
| <p><b>Electromagnetic coupling relay</b> <b>Q22</b></p>              | <p><b>Air recirculation flap control motor</b> <b>Q27</b></p>                |
| <p><b>Auxiliary relay for heating and ventilation</b> <b>Q32</b></p> |  |
| <p><b>Auxiliary relay for heating and ventilation</b> <b>Q32</b></p> | <p><b>Fuse for conditioning system</b> <b>Q39</b></p>                        |
| <p><b>Fuse for conditioning system</b> <b>Q39</b></p>                | <p><b>Set of relay and fuses for air conditioner</b> <b>Q41</b> <b>A</b></p> |

|   |  |
|---|--|
| <p>Set of relay and fuses for air conditioner <b>Q41</b> <b>A</b></p> | <p>Set of relay and fuses for air conditioner <b>Q41</b> <b>B</b></p>  |
| <p>Set of relay and fuses for air conditioner <b>Q41</b> <b>C</b></p> | <p>Set of relay and fuses for air conditioner <b>Q41</b> <b>D</b></p>  |
| <p>Conditioner fan delay device <b>Q42</b></p>                        | <p>Compressor and air recirculation engagement switches <b>Q68</b></p> |
| <p>Heater fan 1st speed relay <b>Q69</b></p>                          |  |
|   |  |









|  |           |   |           |
|--|-----------|---|-----------|
| <p>Air flow meter</p>  | <p>S5</p> | <p>Air flow meter</p>   | <p>S5</p> |
| <p>2.0 T.S. 16v</p> <p>1.5ORN-BLK • S46 —◇— 1RED-BLK 3</p> <p>1WHT-BLK • S11 4</p> <p>1WHT • S11 —◇— 1GRN 2</p> <p>6BLK • G60 —◇— 1BLK 1</p>  |           | <p>2.0 V6 TB</p> <p>1YEL-BLK • S11 —◇— 1YEL-BLK 1</p> <p>1YEL-BLK • N23 —◇— 1WHT-BLK 2</p> <p>1WHT-BLK • S11 —◇— 1GRN 4</p> <p>1GRN • N23 —◇— 1GRN 4</p> <p>1LTB-WHT • S11 —◇— 1LTB-WHT 3</p> <p>1LTB-WHT • N23 —◇— 1LTB-WHT 3</p>  |           |
| <p>Air flow meter</p>  | <p>S5</p> | <p>Air flow meter</p>   | <p>S5</p> |
| <p>3.0 V6</p> <p>1RED-BLK • S12e 3</p> <p>1WHT-BLK • S11 4</p> <p>1GRN • S11 2</p> <p>1BLK • G131b 1</p>                                     |           | <p>3.0 V6 24v</p> <p>1ORN-WHT • S12e 3</p> <p>1WHT-BLK • S11 4</p> <p>1GRN • S11 2</p> <p>1BLK • G131 1</p>    |           |
| <p>Engine temperature sensor</p>   | <p>S7</p> | <p>Engine temperature sensor</p>  | <p>S7</p> |
| <p>2.0 T.S. 16v</p> <p>1WHT • S11 —◇— 1WHT 2</p> <p>1BRN • S11 1</p>    |           | <p>2.0 V6 TB</p> <p>1BRN • S11 2</p> <p>1BRN • N23 1</p>    |           |
| <p>Engine temperature sensor</p>   | <p>S7</p> | <p>Engine temperature sensor</p>  | <p>S7</p> |
| <p>3.0 V6</p> <p>1WHT • S11 —◇— 1WHT 2</p> <p>1BRN • S11 1</p>    |           | <p>3.0 V6 24v</p> <p>1BLU-GRN • S11 2</p> <p>1YEL • S11 —◇— 1YEL 1</p>    |           |

Motronic control unit

S11



2.0 T.S. 16V





Motronic control unit

S11

- 1 2.5WHT • N23
- 2 1WHT • S38
- 3 1YEL • N23
- 4 1LTB-YEL • T1
- 5 1BLK —◇— 1.5BLK • G131a
- 6 1GRN —◇— 1GRN • N23
- 7 1WHT-BLK —◇— 1WHT-BLK • N23
- 9 1LTB-WHT —◇— 1LTB-WHT • N23
- 12 1WHT-GRN • G133b
- 13 1BRN • S7
- 14 2.5YEL —◇—
  - 1YEL • S3 [1]
  - 1YEL • S3 [2]
  - 1YEL • S3 [3]
  - 1YEL • S3 [4]
  - 1YEL • S3 [5]
  - 1YEL • S3 [6]
- 16 2.5BLK • G131b
- 17 RED-GRN • G133b
- 18 1RED —◇— 4RED • S36
- 20 1GRY-BLK —◇—
  - 1GRY-BLK • S12a
  - 1GRY-BLK • N23
- 21 1BRN-WHT • G133a
- 22 1YEL-BLK —◇— 1YEL-BLK • N23
- 23 BLU-RED —◇—
  - 1BLK • S31
  - BLU-RED • S31
- 24 —◇— 1GRN • S35
- 25 —◇— 1YEL-BLK • S31

2.0 V6 TB



- 26 1WHT • N23
- 27 1GRY-GRN • G131a
- 29 1GRN-WHT • G337
- 31 1WHT-RED • N23
- 32 1GRY-YEL • G337
- 33 1LTB-BLK • S29
- 34 1BLK-PPL • M15
- 35 1.5RED —◇—
  - 2.5RED • S41
  - 1RED • N23



Motronic control unit

S11

3.0 V6

1 1GRY-BLK • S12a

2 1ORN-BLK • S29

3 1YEL • S3 1

4 1YEL-BLK • S3 2

5 1YEL-GRN • S3 3

6 1.5BLK • G131a

8 1RED-GRN • G133b

9 1GRY-RED • L46

11 BLK • S35

12 GRN • S35

14 1GRN • S5

16 BLK • S31

24 1GRY • A8

25 1LTB • A8

26 1RED • S46

27 1GRN-YEL • S41

28 1BLK —◇— 1BLK • G131b

29 1LTB-BLK • S29

31 1YEL-RED • S3 4

32 1YEL-BLU • S3 5

33 1GRY-YEL • S3 6

34 1.5BLK • G131a

36 1ORN • M15

41 1WHT-BLK • S5

42 1LTB • G133a

43 YEL • S31

44 1GRY • S52

47 1BRN-WHT • G133a

48 1BRN • G337

52 1.5GRN • A8

54 1.5RED-BLK —◇— 4RED-BLK • S41

55 2.5BLK —◇— 2.5BLK • G131a

56 1PNK-BLK • S42

59 1LTB-WHT • S38

64 1GRN-WHT • G337

65 1GRY-YEL • G337

69 RED • S20b

70 YEL • S20a

71 1BLK —◇— BLK • S20a

WHT • S20b

72 1WHT —◇— 1WHT • S34

1WHT • S7

1WHT • S38



73 1YEL • S38

77 1PNK-WHT • S34

78 1BRN • S7

87 1LTB-YEL • T1



88 1WHT-GRN • G133b



Motronic control unit

S11

3.0 V6 24v



















- 1 1RED-BLK • S12a
- 2 1ORN-BLK • S29
- 3 1.5GRY-RED • G338
- 4 1YEL-RED • G338
- 5 1GRN-RED • G338
- 6 1.5BLK • G131
- 8 1RED-GRN • G133b
- 9 1GRY-RED • L46
- 11 BLK • S35
- 12 GRN • S35
- 14 1GRN • S5
- 16 BLK • S31
- 23 WHT • G338
- 24 RED • G338
- 25 YEL • G338
- 26 1RED • S46
- 27 1PPL-BLK • S41
- 28 1BLK • G131
- 29 1LTB-BLK • S29
- 31 1RED-BLK • G338
- 32 1LTB-RED • G338
- 33 1WHT-RED • G338
- 34 1.5BLK • G131
- 36 1LTB • M15
- 41 1WHT-BLK • S5
- 42 1LTB • G133a







- 43 YEL • S31
- 44 1WHT-BLU • S52
- 47 1BRN-WHT • G133a
- 48 1BRN • G337
- 50 BLU • G338
- 51 WHT • G338
- 52 BRN • G338
- 54 1GRY —◇— 4GRY • S41
- 55 2.5BLK • G131
- 56 1PNK —◇— 1ORN • G133a
- 59 1PPL-WHT • S38
- 64 1GRN-WHT • G337
- 65 1GRY-YEL • G337
- 69 YEL • S20b
- 70 BLU-BLK • S20a
- 71 BLU —◇— BLU • S20a  
BLU • S20b
- 72 1YEL —◇— 1YEL • S34  
1YEL • S7  
1YEL • S38
- 73 1WHT-BLK • S38
- 77 1YEL-BLU • S34
- 78 1BLU-GRN • S7
- 87 1LTB-WHT • T1
- 88 1WHT-GRN • G133b


|  |                    |   |                    |
|--|--------------------|---|--------------------|
| <p>Motronic fuel pump relay</p>  | <p><b>S12a</b></p> | <p>Motronic fuel pump relay</p>   | <p><b>S12a</b></p> |
| <p>2.0 T.S. 16v</p> <p>1BLK-PPL • S41 85<br/>         1.5PNK-WHT • G133b 87<br/>         1GRY-BLK • S11 86<br/>         4RED • S36 30</p>  |                    | <p>2.0 V6 TB</p> <p>1GRY-BLK • S11<br/>         1GRY-BLK • N23 85<br/>         1.5PNK-WHT • G133b 87<br/>         1ORN-BLK • S35<br/>         1GRN-BLK • L21 86<br/>         1RED-BLK • S41 30<br/>         2.5PNK • S47</p>    |                    |
| <p>Motronic fuel pump relay</p>  | <p><b>S12a</b></p> | <p>Motronic fuel pump relay</p>   | <p><b>S12a</b></p> |
| <p>3.0 V6</p> <p>1GRY-BLK • S11 85<br/>         1PNK-WHT • S12e 87<br/>         1ORN-BLK • S35<br/>         1.5PNK-WHT • G133b<br/>         4RED-BLK • S41 86<br/>         1RED-BLK 30<br/>         1.5RED • S47</p> |                    | <p>3.0 V6 24v</p> <p>1RED-BLK • S11 85<br/>         1.5RED • S47 87<br/>         4RED-BLK • S41 86<br/>         1RED 30<br/>         1PNK-YEL • S12e<br/>         1PNK-YEL • S35<br/>         2.5PNK-YEL • G133b 2.5PNK-YEL</p> |                    |
| <p>Phase variator relay</p>  | <p><b>S12c</b></p> | <p>Air flow meter relay</p>   | <p><b>S12e</b></p> |
| <p>2.0 T.S. 16v</p> <p>ORN-BLK • S46<br/>         1BLK-PPL 85<br/>         1RED-GRN • S15 87<br/>         1BLK-PPL • S11 86<br/>         1RED 30</p>   |                    | <p>3.0 V6</p> <p>1BLK • G131a 85<br/>         1RED-BLK • S5 87<br/>         2.5PNK-WHT • S12a 86<br/>         1PNK-WHT<br/>         4RED-BLK • S41 30<br/>         1RED-BLK</p>   |                    |
| <p>Air flow meter relay</p>  | <p><b>S12e</b></p> | <p>Phase variator</p>   | <p><b>S15</b></p>  |
| <p>3.0 V6 24v</p> <p>2.5PNK-YEL • S12a 85<br/>         1PNK-YEL<br/>         4GRY • S41 87<br/>         1GRY<br/>         1BLK • G131 86<br/>         1ORN-WHT • S5 30</p>   |                    | <p>2.0 T.S. 16v</p> <p>1BLK • G60 2<br/>         1RED-GRN • S12c 1</p>  |                    |

|                           |                    |                         |                    |
|---------------------------|--------------------|-------------------------|--------------------|
| <p>Altitude corrector</p> | <p><b>S16</b></p>  | <p>Pinging sensor</p>   | <p><b>S20</b></p>  |
| <p>2.0 V6 TB</p>          |                    | <p>2.0 T.S. 16v</p>     |                    |
| <p>Pinging sensor a</p>   | <p><b>S20a</b></p> | <p>Pinging sensor a</p> | <p><b>S20a</b></p> |
| <p>2.0 V6 TB</p>          |                    | <p>3.0 V6</p>           |                    |
| <p>Pinging sensor a</p>   | <p><b>S20a</b></p> | <p>Pinging sensor b</p> | <p><b>S20b</b></p> |
| <p>3.0 V6 24v</p>         |                    | <p>2.0 V6 TB</p>        |                    |
| <p>Pinging sensor b</p>   | <p><b>S20b</b></p> | <p>Pinging sensor b</p> | <p><b>S20b</b></p> |
| <p>3.0 V6</p>             |                    | <p>3.0 V6 24v</p>       |                    |

|  |              |  |              |
|--|--------------|--|--------------|
| <p>Idle adjustment actuator</p>  | <p>(S29)</p> | <p>Idle adjustment actuator</p>  | <p>(S29)</p> |
| <p>2.0 T.S. 16v</p>    |              | <p>2.0 V6 TB</p>     |              |
| <p>Idle adjustment actuator</p>  | <p>(S29)</p> | <p>Idle adjustment actuator</p>  | <p>(S29)</p> |
| <p>3.0 V6</p>         |              | <p>3.0 V6 24v</p>   |              |
| <p>Rpm and crankshaft position sensor</p>  | <p>(S31)</p> | <p>Rpm and crankshaft position sensor</p>  | <p>(S31)</p> |
| <p>2.0 T.S. 16v</p>  |              | <p>2.0 V6 TB</p>   |              |
| <p>Rpm and crankshaft position sensor</p>  | <p>(S31)</p> | <p>Rpm and crankshaft position sensor</p>  | <p>(S31)</p> |
| <p>3.0 V6</p>        |              | <p>3.0 V6 24v</p>  |              |









|   |                   |  |                   |
|---|-------------------|--|-------------------|
| <p>Air temperature sensor</p>   | <p><b>S34</b></p> | <p>Air temperature sensor</p>  | <p><b>S34</b></p> |
| <p>2.0 T.S. 16v</p>  |                   | <p>3.0 V6</p>          |                   |
| <p>Air temperature sensor</p>   | <p><b>S34</b></p> | <p>Heated lambda probe</p>   | <p><b>S35</b></p> |
| <p>3.0 V6 24v</p>   |                   | <p>2.0 T.S. 16v</p>   |                   |
| <p>Heated lambda probe</p>  | <p><b>S35</b></p> | <p>Heated lambda probe</p>   | <p><b>S35</b></p> |
| <p>2.0 V6 TB</p>   |                   | <p>3.0 V6</p>        |                   |
| <p>Heated lambda probe</p>  | <p><b>S35</b></p> | <p>Fuse for injection relay</p>  | <p><b>S36</b></p> |
| <p>3.0 V6 24v</p>  |                   | <p>2.0 T.S. 16v</p>  |                   |

|   |     |  |     |
|---|-----|--|-----|
| Fuse for injection relay  |     | S36  |     |
|  <p>2.0 V6 TB</p> <p>4RED • A1</p> <p>1RED • G133b</p> <p>1RED • N23</p> <p>2.5RED • S42</p> <p>4RED • S41</p> <p>4RED</p> <p>1RED • S11</p>                    |     |  |     |
| Fuse for injection relay  |     | S36  |     |
|  <p>3.0 V6</p> <p>4RED • G56</p> <p>1RED • G133b</p> <p>1.5RED • S47</p> <p>2.5RED • S42</p> <p>1RED • S46</p> <p>4RED • S41</p> <p>4RED</p> <p>1RED • S41</p> |     |  |     |
| Fuse for injection relay  | S36 | Sensor on throttle body  | S38 |
|  <p>3.0 V6 24v</p> <p>4RED-BLK • A1</p> <p>1.5RED • S47</p> <p>1.5RED • S46</p> <p>1.5RED • S41</p> <p>4RED</p> <p>4RED • S41</p>                              |     |  <p>2.0 T.S. 16v</p> <p>1PPL-WHT • S11</p> <p>1WHT • S11</p> <p>1LTB-WHT</p> <p>1GRY-GRN • S11</p> |     |
| Sensor on throttle body   | S38 | Sensor on throttle body  | S38 |
|  <p>2.0 V6 TB</p> <p>1BLK • G131a</p> <p>1WHT • S11</p> <p>1LTB • N23</p> <p>1GRY-RED • N23</p> <p>1YEL-RED • N23</p>  |     |  <p>3.0 V6</p> <p>1YEL • S11</p> <p>1WHT • S11</p> <p>1LTB-WHT • S11</p>                           |     |





|                                 |            |              |
|---------------------------------|------------|--------------|
| <b>Main relay</b>               |            | <b>S41</b>   |
|                                 |            | 3.0 V6 24v   |
|                                 |            |              |
| <b>Secondary relay</b>          | <b>S42</b> | <b>S42</b>   |
|                                 |            | 2.0 V6 TB    |
|                                 |            |              |
|                                 |            |              |
| <b>Lambda probe fuse</b>        |            | <b>S45</b>   |
|                                 |            | 3.0 V6       |
|                                 |            |              |
| <b>Fuse for Motronic supply</b> |            | <b>S46</b>   |
|                                 |            | 2.0 T.S. 16v |
|                                 |            |              |
| <b>Fuse for Motronic supply</b> |            | <b>S46</b>   |
|                                 |            | 3.0 V6       |
|                                 |            |              |
| <b>Fuse for Motronic supply</b> |            | <b>S46</b>   |
|                                 |            | 3.0 V6 24v   |
|                                 |            |              |

|   |                   |  |                   |
|---|-------------------|--|-------------------|
| <p>Fuse for fuel pump</p>   | <p><b>S47</b></p> | <p>Fuse for fuel pump</p>  | <p><b>S47</b></p> |
| <p>2.0 T.S. 16v</p>   |                   | <p>2.0 V6 TB</p>   |                   |
|    |                   |    |                   |
| <p>Fuse for fuel pump</p>   | <p><b>S47</b></p> | <p>Fuse for fuel pump</p>  | <p><b>S47</b></p> |
| <p>3.0 V6</p>   |                   | <p>3.0 V6 24v</p>  |                   |
|   |                   |   |                   |
| <p>Cam angle sensor</p>   | <p><b>S52</b></p> | <p>Cam angle sensor</p>  | <p><b>S52</b></p> |
| <p>2.0 T.S. 16v</p>   |                   | <p>3.0 V6</p>  |                   |
|  |                   |  |                   |
| <p>Cam angle sensor</p>   | <p><b>S52</b></p> | <p>Connector for ALFA TESTER (Motronic and ALFA ROMEO CODE)</p>                      | <p><b>T1</b></p>  |
| <p>3.0 V6 24v</p>   |                   | <p>2.0 T.S. 16v</p>  |                   |
|  |                   |  |                   |

|   |           |   |            |
|---|-----------|---|------------|
| <p>Connector for ALFA TESTER (Motronic and ALFA ROMEO CODE)</p>   | <p>T1</p> | <p>Connector for ALFA TESTER (Motronic and ALFA ROMEO CODE)</p> | <p>T1</p>  |
| <p>2.0 V6 TB</p>  |           | <p>3.0 V6</p>   |            |
| <p>Connector for ALFA TESTER (Motronic and ALFA ROMEO CODE)</p>   | <p>T1</p> | <p>Connector for ALFA TESTER (airbag)</p>                       | <p>T3</p>  |
| <p>3.0 V6 24v</p>   |           |   |            |
| <p>Connector for ALFA TESTER (anti-theft device)</p>              | <p>T7</p> | <p>Connector for ALFA TESTER (ABS)</p>                          | <p>T8</p>  |
|   |           |   |            |
| <p>Diagnosis connector for ALFA ROMEO TESTER (automatic hood)</p> |           |   | <p>T13</p> |
|   |           |   |            |