



E.G.R. solenoid valve **L46** (if present)




SPECIFICATIONS	
Duty-Cycle signal	12 V; 15.3 Hz
Winding ohmic resistance (at 20°C)	26.6 ± 1.4 Ω

Timing variator **S15**



SPECIFICATIONS	
Resistance between the two terminals	~ 10 Ω
Max. absorption at 13.5 V	1.34 A

Pinging sensor **S20**



SPECIFICATIONS		
Resonance frequency	> 20 kHz	
Impedence	± 1 MΩ	
Allowed vibration	for long times	≤ 80 g
	for short times	≤ 400 g

FAULT-FINDING

The control unit possesses a self-diagnosis function which continuously checks the signals from the various sensors for plausibility and comparing them with the permissible limits: if these limits are exceeded, the system detects a fault and memorises it. It also turns on the special warning light on the instrument cluster,

For certain parameters the control unit replaces the abnormal values with appropriate mean values so that the car can "limp" to a point of the Service Network. These values, known as "recovery" depend on the other correct signals and are defined individually by the control unit operating logic.

The self-diagnosis system also enables quick and effective location of faults connecting with the ALFA ROMEO Tester, through which the errors memorised may be "read". It is also possible to check the operating parameters recorded by the control unit and engage the single actuators to check whether they are working properly.

Diagnosis using the ALFA TESTER

N.B. Before carrying out diagnosis with the Tester, carry out the preliminary test described below (**TEST A**).

The Tester and electronic control unit should be connected as follows:

1. Power the Tester either through the cigar lighter socket or connecting it directly to the battery using the special cable.

2. Connect the socket of the Tester to the one for the control unit (to be found next to the control unit).

The information the instrument can provide is:

- display of parameters;
- display of errors;
- active diagnosis.

Error clearing

Before ending diagnosis the contents of the "permanent" memory are cancelled through the Tester in Active Diagnosis.

Otherwise, reconnecting the Tester errors already examined would be signalled.

The contents of the "permanent memory" can be erased as follows:

- through the tester in Active Diagnosis;
- if the cause that determined the error is no longer present and the engine has been started 10 times (running for no less than 20 minutes) with at least 2 minutes between one start and the next.

N. B.:

Disconnecting the control unit for at least 30 seconds the contents of the "permanent" memory are cleared

PRELIMINARY TEST OF BOSCH M2.10.4 SYSTEM	TEST A
---	---------------

NOTE: Beforehand check that the ALFA ROMEO CODE system is working correctly as it may have cut off the supply to the system!


TEST PROCEDURE		RESULT	CORRECTIVE ACTION
A1	CHECK FUSE	OK →	Carry out step A2
	– Check the intactness of fuses S36 , S46 and G389	OK →	
			Change fuses S36: 40A S46: 15A G389: 10A
A2	CHECK VOLTAGE	OK →	Carry out step A3
	– Check for 12 V at pin 30 of relays S41 and S12a	OK →	
			Restore the wiring between the battery A1 and relays 41 and S12a through fuse S36
A3	CHECK VOLTAGE	OK →	Carry out step A4
	– With the key turned, check for 12 V at pin 85 of relay S41	OK →	
			Restore the wiring between the ignition switch B1 and relay S41 - through fuse G389
A4	CHECK RELAYS	OK →	Carry out step A5
	– Check that relays S41 and S12a are working properly	OK →	
			Replace any faulty relays
A5	CHECK CONTROL UNIT SUPPLY	OK →	Carry out step A6
	– Check for 12 V at pin 18 of the control unit S11 ; with the key turned 12 V also at pins 27 and 37 of S11 and for appr. 0 V (very low voltage) at pin 3 and 36 of S11	OK →	
			Restore the wiring between the control unit S11 and relays S41 and S12a
A6	CHECK EARTH	OK →	CONTINUE DIAGNOSIS USING THE ALFA ROMEO TESTER
	– Check for an earth at pins 2, 14, 19 and 24 of S11	OK →	
			Restore the wiring between S11 and earth G60

**CONTROL SYSTEM -
3.0 V6 Engine:
BOSCH MOTRONIC M3.7**

INDEX

WIRING DIAGRAM A 30-2
GENERAL DESCRIPTION 30-4
FUNCTIONAL DESCRIPTION 30-7
LOCATION OF COMPONENTS 30-11
CHECKING COMPONENTS 30-12
FAULT-FINDING 30-17

WIRING DIAGRAM A



(*) from chassis no. _____

GENERAL DESCRIPTION

An electronic control system supervises and regulates all the parameters of the engine, optimising performance and consumption levels through response in real time to the different operating conditions: this sophisticated latest generation system comprises a single control unit which controls both ignition (static with lost spark) and injection (timed).

This is the M 3.7 version of the proven and reliable BOSCH MOTRONIC system.

Compared with the previous versions this new M 3.7 system adopts a control unit - with 88 pins - with advanced design and production technology, it also possesses many possibilities for inserting auxiliary functions.

Owing to the use of new sensors and revision to the control programmes, the system makes it possible to achieve considerable improvements in terms of consumption, emission levels and handling of the vehicle.

Another feature of this system is self-adaptation, i.e. the capability to recognise the changes that take place in the engine and to compensate them, according to functions which mainly correct:

- mixture titration
- the carburetion parameters according to the command of the evaporative solenoid valve
- an adaptive programme for idle speed control.

FUNCTIONS OF THE SYSTEM

Sequential and timed injection (S.E.F.I.)

With this control unit injection is sequential and timed for each cylinder: the injection instant (delivery of fuel into the intake manifolds through the opening of the injectors) is not simultaneous for all the cylinders, but takes place for each cylinder in correspondence with the optimal point of injection, calculated by the control unit according to special maps according to the load, speed and temperature of the engine.

NOTE: the instant considered in the design of the maps is that of the start of injection (the cylinder is in the exhaust stroke - intake valve still closed).

Static Ignition

An ignition system has been adopted with "static distribution" (with semi-conductors, without distributor). This solution makes it possible to eliminate rotary components; in addition, it does not produce external sparks thus reducing the risk of interferences; lastly it reduces the number of high voltage cables and connectors; as the power modules for controlling the primary windings of the coil are inside the control unit.

Static ignition takes place through three coils, according to the "lost spark" logic: this solution exploits the different pressures and environments existing contemporaneously in a pair of cylinders: when one of the cylinders approaches the bursting stroke, with a mixture of air and fuel, the corresponding cylinder is at the end of the exhaust stroke in the presence of exhaust gas.

In a V six-cylinder engine, the paired cylinders are 1/5 6/2 and 3/4.

Metering the air flow rate

The air flow meter adopted is of a more modern design known as the "hot film" type. Outside, the air-flow meter looks like a part of duct between the intake manifold and the air cleaner.

Inside the air-flow meter there is an electronic circuit and a plate that is crossed by the air which passes in the duct.

The film plate is kept at a constant temperature (appr. 120°C above the temperature of the incoming air) by a heating resistance placed in contact with it.

The mass of air flowing through the manifold tends to withdraw heat from the plate: therefore, to keep its temperature constant, a certain current needs to flow through the heating resistance: this current, suitably measured, is proportionate with the mass of flowing air.

N.B. This air flow meter measures directly the mass of air (and not the volume as in the previous versions with "floating port"), thereby eliminating problems of temperature, altitude, pressure, etc.

Cylinder detection

Following the sequential and timed injection system, a timing sensor has been introduced (cam angle sensor): this makes it possible to detect which cylinder is in the bursting stroke when the engine is started, in order to be able to start the correct injection sequence. The sensor is formed of a Hall-effect device by which the voltage signal sent to the control unit "lowers" suddenly when the tooth machined on the camshaft passes in front of the actual sensor; therefore a signal is sent every two turns of the crankshaft.

Conversely, the rpm sensor sends a reference signal for each turn of the engine and each subsequent tooth of the phonic wheel informs the control unit of an increase of the angular position of the crankshaft, so that injection is sent correctly to the suitable cylinder and the spark to the corresponding pair of cylinders.

Fuel pump

The control logic of the fuel pump carried out by the control unit which is mainly based on the rpm signal immediately cuts off the supply to the pump as soon as the engine stops.

Moreover, the pump will not operate with the key engaged and the engine not running.

In this car, this logic is integrated - in order to further higher the standards of safety - by the **inertial switch** device: this is an electromechanical switch which, in the event of heavy shocks, opens to cut off the circuit that takes the earth to the fuel pump, which stops instantaneously. This device is particularly important as an integration of the safety guaranteed by the logic of the control unit, especially if the car is hit from behind or in the case of other accidents in which the engine does not stop immediately.

Percentage of exhaust gas recirculation

Nox (nitric oxide) is developed at high temperatures in the combustion chambers.

To reduce these emissions an E.G.R. (Exhaust Gas Recirculation) system is adopted which by recirculating part of the exhaust gases, lowers the temperature, thus the Nox produced, in the combustion chambers. In fact, part of the exhaust gas is withdrawn through the special EGR Valve and re-admitted to the intake box where it is mixed with the intaken air and burnt again in the engine. The EGR valve is modulated by a solenoid valve controlled by the injection control unit and, as a result of the type of control, in addition to reducing the amount of Nox, consumption levels are also optimised.

The percentage of exhaust gas to be returned to the engine is established by the control unit taking account of a specific characteristic curve which depends on the load, speed and temperature of the engine.

OPERATING LOGIC

- Identification of the "operating point":

the "point of operation of the engine" is located mainly through two sensors: the rpm sensor informs the control unit of the speed of rotation of the engine; the air flow meter supplies the value of the mass of air actually entering the cylinders, defining the instantaneous volumetric yield of the engine.

- Adjustment of injection times (quantity of fuel):

the control unit controls the injectors very quickly and precisely, calculating the opening time on the basis of engine load (rpm and air flow), also taking into account the battery voltage and the temperature of the engine. Injection is "sequential", i.e. the injectors are opened in correspondence of the exhaust stroke of the corresponding cylinder.

- Ignition adjustment (calculation of advances):

the control unit calculates the advance on the basis of the engine load (rpm and air flow); the value is also corrected according to the temperature of the intaken air and that of the engine: ignition is "static" as described previously.

- Cold starting control:

during cold starts the control unit uses special advance values and injection times.

When a determinate temperature/rpm ratio is reached, the control unit resumes normal operating conditions.

- Control of enrichment during acceleration:

upon the need for acceleration, the control unit increases injection in order to reach the required rpm as quickly as possible.

This function takes place through the potentiometer located on the throttle which instantaneously informs the control unit of the need to accelerate.

- Fuel cut-off during deceleration:

with the throttle closed and an engine speed above a certain threshold, the control unit de-activates fuel injection; this way the rpms decrease rapidly towards idle speed reducing the speed and fuel consumption. The cutoff threshold value varies according to the temperature of the engine and the speed of the car.

- Control of idle speed:

the adjustment of the engine idle speed is carried out through the special actuator which acts on the throttle by-pass.

This device acts as a regulator for cutting in the various services (e.g. conditioner compressor); in fact, when the throttle is closed, this valve adjusts the by-pass gap compensating the load required by the services in order to ensure that idle speed is as constant as possible.

- Maximum Rpm limiting:

above a certain threshold the control unit automatically stops the injection of fuel preventing the engine from "over-revving".

- Combustion control -lambda probe:-

the oxygen sensor (or "lambda" probe) informs the control unit of the amount of oxygen at the exhaust, and therefore the correct air-fuel metering.

The optimum mixture is obtained when the lambda coefficient = 1 (optimum stoichiometric mixture). The electric signal sent by the probe to the control unit changes abruptly when the composition of the mixture departs from lambda = 1. When the mixture is "lean" the control unit increases the amount of fuel, reducing it when the mixture is "rich" so that in this way the engine operates as far as possible around the ideal lambda rating.

The signal from the lambda probe is processed inside the control unit by a special integrator which prevents sudden "oscillations".

The probe is heated by an electrical resistance so that it quickly reaches the correct operating temperature (appr. 300 °C).

Through this probe it is therefore possible to adjust engine carburetion precisely. Among other items, this makes it possible to meet emission limit regulations.

- Knocking control:

Through knocking sensors the control unit is informed if any pinging or "knocking" occurs and it corrects the spark advance "delaying" it accordingly; a further correction also takes account of the air temperature, in fact when the temperature of the intake air is high, pinging is more accentuated.

The intaken air temperature sensor, to be found just downstream of the air-flow meter, is not used to calculate the engine load but to control the knocking parameters and spark advances.

- Fuel vapour recovery:

the fuel vapours collected from the various points of the supply circuit in a special active carbon canister are ducted to the engine where they are burnt: this takes place through a solenoid valve which is opened by the control unit only when the engine is in a condition that allows correct combustion without adversely affecting the operation of the engine: in fact the control unit compensates this amount of incoming fuel by reducing delivery to the injectors.

- E.G.R. valve control

The percentage of exhaust gas to be returned to the engine is determined by the control unit taking account of a specific characteristic curve which depends on the engine load and speed: recirculation is only activated when the engine speed is between 2500 and 4000 rpm., also in relation to the temperature of the

engine (higher recirculation percentage with high temperatures).

- Connection with the air conditioner compressor:

the control unit is connected with the air conditioner system and it cuts in the compressor in relation to operation of the engine. As this service absorbs a considerable amount of power, the control unit:

- adapts the engine idle speed each time the compressor cuts in; if the engine speed falls below 700 rpm, the compressor is turned off;

- when there is the need for power (high throttle opening speed starting from below 3500 rpm, or full load, or high engine temperature - over 117°C), it momentarily cuts out the compressor

- when the engine is being started the compressor is disabled until normal operating conditions have been reached.

- Connection with the ALFA ROMEO CODE system

on cars fitted with the ALFA ROMEO CODE system, as soon as the Motronic control unit receives the signal that the key has been turned to MARCIA, it "asks" the above-mentioned system for consent to start the engine: this consent is given only if the ALFA ROMEO CODE control unit recognizes the code of the key engaged in the ignition switch as correct. This dialogue between the control units takes place on diagnosis line K already used for the Alfa Romeo Tester.

- Self-diagnosis:

the key a **self-diagnosis system**, which continuously monitors the plausibility of the signals from the various sensors and compares them with the limits allowed: if these limits are exceeded, the system detects a fault and turns on the corresponding warning light on the instrument cluster.

The warning light turns on when the engine is started to indicate the initial test of the entire system (appr. 4 seconds), it then turns off if no errors have been memorised: otherwise it stays on.

For certain parameters, the control unit replaces the abnormal values with suitable mean ones so that the car can "limp" to a point of the Service Network.

These "recovery" values depend on the other correct signals and they are defined individually by the control unit operating logic.

The self-diagnosis system also enables quick and effective location of faults connecting with the ALFA ROMEO Tester (see "Fault-finding"), through which all the errors memorised can be displayed. It is also possible to check the operating parameters recorded by the control unit and operate the single actuators to check whether they are working properly.

COMPONENTS

The electronic control unit receives the signals leading from the **sensors** which "read" the engine operating parameters. It processes them according to a logic stored inside in "maps" which correlate the different parameters in the best way possible and it operates the **actuators** accordingly so that the engine always works with the highest level of regularity and yield.

The sensors are the following:

- engine temperature sensor (**S7**);
- air temperature sensor (**S34**);
- sensor on throttle body (**S38**);
- rpm sensor (**S31**);
- cam angle sensor (**S52**);
- heated lambda sensor (**S35**);
- air-flow meter (**S5**);
- knock sensors (**S20a** and **s20b**);

The actuators are the following:

- electroinjectors (**S3**);
- ignition coil (**A8**);
- fuel pump (**P18**);
- idle adjustment actuator (**S29**);
- vapour recovery solenoid valve (**M15**);
- E.G.R. solenoid valve (**L46**);

The control unit is also connected with:

- the climate control unit;
- the ALFA ROMEO CODE control unit (**N77**);
- the instrument cluster (**C10**) to which it supplies the signal for turning on the diagnosis warning light and for the rev counter;
- the sensor (**L17**) from which it receives the car speed signal.

The system is completed by four relays: the first three - the main relay (**S41**), secondary relay **S42** and the fuel pump relay **S12a** operate the fuel pump, the injectors, the coils and the other components of the system, while the fourth - the air-flow meter relay (**S12e**) supplies the corresponding component.

The supply line for the entire system is protected by fuse **S36**, while the control unit is protected by wander fuse (**S46**); another fuse protects the pump (**S47**).

Lastly, there is an earth point (**G60**) on the engine. Connector **T1** enables connection with the ALFA ROMEO Tester: this is located inside the car next to the control unit.

FUNCTIONAL DESCRIPTION

The Motronic control unit **S11** controls and adjusts the entire electronic ignition and injection system; all the system supplies are protected by fuse **S36** (40A).

The control unit is supplied at pin 26 directly by the battery through fuse **S46** (7.5A). At pin 54 it receives the supply from the main relay **S41**, while at pin 56 it receives the "key-operated" supply from the secondary relay **S42**.

Pins 55, 6, 28 and 34 are earthed and serve as reference respectively for the ignition, the injectors, electronic screening and the final power stages.

Two relays control the entire system:

The main relay **S41**, acts as supply relay for the whole system; it is energized by a control signal - earth - leading from pin 27 of the control unit and consequently sends the supply (12V) to pin 54 of the control unit itself, to the fuel pump relay **S12a**, to the air-flow meter relay **S12a** to the vapour recovery solenoid valve **M15**, to the idle speed actuator **S29**, to the cam angle sensor **S52**, to the EGR solenoid valve **L46** and lastly to the injectors **S3**.

The secondary relay **S42**, energized by the "key-operated" - from chassis no.____ - between the fuse **G389** - supply, supplies the control unit at pin 56 and the primary windings of the coil **A8**.

The fuel pump relay **S12a**, supplied by the main relay **S41**, is energized by a control signal - earth - leading from pin 1 of the control unit **S11**. Consequently, the relay supplies the resistance of the lambda probe **S35**, the air flow meter relay **S12e**, and of course the fuel pump **P18**; this supply line is protected by a special fuse **S47** (10A).

The earth reaches the pump **P18** via the inertial switch **H20** which cuts off the circuit in the event of impact.

The control unit **S11** receives numerous signals from the different sensors, thereby keeping all the engine operating parameters under control.

Through a frequency signal sent to pins 43 and 16 of the control unit, the rpm sensor **S31** supplies information about the engine rpm; the two above-mentioned signals are very low in intensity and are therefore suitably screened.

The sensor is inductive and detects the number of revolutions of the engine through the change in a magnetic field produced by the passage of the teeth of a "phonic" wheel (60-2 teeth) fitted on the crankshaft.

The cam angle sensor **S52** (timing sensor), is supplied at 12 V by the main relay **S41**, and sends a signal in frequency corresponding to the phase to pin 44 of the control unit itself.

The sensor comprises a Hall effect device due to which the voltage signal sent to the control unit

"lowers" abruptly when the tooth machined on the camshaft passes in front of the sensor.

The heated lambda sensor **S35** supplies the control unit information about the correct composition of the air-fuel mixture detecting the concentration of oxygen in the exhaust gas; this takes place through the signal sent to pin 12 of the control unit, while pin 11 supplies the reference earth; The sensor is heated by a resistance to make sure that it operates correctly also when the engine is cold; the resistance is supplied by the fuel pump relay **S12a**.

The throttle body sensor **S38**, is supplied by the control unit from pins 59 and 72 and through a potentiometer it sends a signal to pin 73 which is proportionate with the degree of opening of the throttle itself.

The engine temperature sensor **S7**, connected to the electronic earth at pin 72, supplies a signal to pin 78 proportionate with the temperature of the engine coolant, detected with an NTC material (resistance that lowers with the temperature).

The intaken air temperature sensor **S34**, connected to the electronic earth at pin 72, supplies a signal at pin 77 that is proportionate with the temperature of the air entering the intake box, detected with an NTC material (resistance that lowers with the temperature).

The knock sensors **S20a** and **S20b**, through a frequency signal sent to pins 69 and 70 of the control unit, supplies information about the knocking conditions, while an electronic earth leads from pin 71; these two signals are very low in intensity and are therefore suitably screened.

The sensor comprises a piezoelectric plate which detects the vibrations produced when the engine is running, exploiting a particular characteristic of piezoelectric materials which generate an output voltage when subjected to mechanical stresses; this voltage is filtered and analysed by the control unit which corrects the ignition parameters accordingly.

The air flow meter **S5**, is supplied by the special relay **S12e**: from pin 14 of the control unit it receives the reference earth, while it sends a signal proportionate with the air flow to pin 41.

The air flow meter is of the "heated film" type: a diaphragm is interposed in a measurement channel, through which the intake air flows: this diaphragm is kept at a constant temperature by a heating resistance; the mass of air that crosses the measurement channel tends to withdraw heat from the diaphragm, therefore, in order to maintain its temperature constant, a certain amount of current must flow through the resistance: this current, appropriately measured, is proportionate with the mass of air flowing in the channel.

Relay **S12e**, supplied directly with 12 V by relay **S41**, is energized by the fuel pump relay **S12a** and thus supplies the meter **S5** itself.

On the basis of the signals received from the sensors and of the calculations carried out, the control unit **S11** controls the opening of the single injectors **S3** through special signals - of the duty-cycle type - pins 3 (cyl. 1), 4 (cyl. 2), 5 (cyl. 3) 31 (cyl. 4), 32 (cyl. 5) and 33 (cyl. 6). The injectors receive consent (12V) to open from the main relay **S41**.

The static ignition system is controlled by the control unit directly which automatically adjusts the advance. N.B. the power modules which generate the high voltage pulses are located inside the control unit. The control signals (earth) for the primary windings of the coil **A8** lead from the control unit, while the secondary winding sends the pulse to the spark plugs **A12**: from pin 24 for cylinders 1/5, from pin 25 for cylinders 2/6 and from pin 52 for cylinders 3/4.

The primary windings of the coil **A8** are supplied at 12 V ("key-operated") by relay **S42**.

The power modules inside the control unit are connected to earth via pin 55.

The idle speed adjustment actuator **S29** forms a bypass line for the flow of air; this comprises two windings: one opens and the other closes a valve that adjusts the gap of the by-pass section; a safety spring establishes a mean opening value in the event of a failure to this device; the actuator, supplied by the main relay, **S41**, is controlled by the control unit through the duty-cycle signals of pins 29 (closing) and 2 (opening).

The vapour recovery solenoid valve **M15** allows the passage of the fuel vapours towards the engine intake where they are added to the mixture entering the combustion chamber; this valve, supplied by the main relay **S41**, is opened by the control unit when the engine is under load through a duty cycle signal from pin 36.

The E.G.R. solenoid valve **L46**, controlled by the control unit, operates the actual E.G.R. valve modulating its opening: the latter is a vacuum-operated diaphragm valve: the electropneumatic valve works by changing this vacuum which is withdrawn from the same "takeoff" used for the servobrake.

The solenoid valve is controlled from pin 9 of the control unit while it is supplied at 12 V by main relay **S41**.

The tachometric signal (car speed) reaches the control unit at pin 42 via sensor **L17**; while from pin 47 the control unit sends a "pulse" signal to the cluster **C10** which is proportionate with the number of revolutions of the engine; the signal for the "Check Engine" diagnosis warning light on the cluster **C10** leads from pin 8.

The control unit **S11** is connected with the air conditioning system through pins 48, 64 and 65.



This makes it possible to adapt the engine idle speed to the increased power each time the compressor cuts in, or to cut it out in the case of high speed or engine

loads. For further details see the "Climate Control" section.

The control unit **S11** is connected by pin 88 with the ALFA ROMEO CODE control unit **N77** via the diagnosis line K; if the ALFA ROMEO CODE does not recognise a correct "key code" it will not enable the Motronic control unit to start the engine.

The control unit possesses a self-diagnosis system which can be used through connection to the ALFA ROMEO Tester at connector **T1**; the tester receives the fault signals from the control unit through the diagnosis lines L - pin 87 - and K - pin 88 -, while the earth leads from **G60** (line K is also used by the ALFA ROMEO CODE system).


ELECTRONIC CONTROL UNIT



CONTROL UNIT PINOUTS

- | | |
|--|---|
| <ul style="list-style-type: none"> 1. Fuel pump relay consent 2. Idle actuator control (open) signal 3. Electroinjector control, cylinder no.1 4. Electroinjector control, cylinder no.2 5. Electroinjector control, cylinder no.3 6. Earth for final stages (injectors) 8. "Check Engine" warning light 9. E.G.R. solenoid valve control 11. Lambda sensor earth 12. Lambda sensor signal 14. Earth for air flow meter 16. Rpm sensor signal 24. Ignition cylinders no.1 and 5 25. Ignition cylinders no.2 and 6 26. Direct 12V supply 27. Main relay control 28. Electronic earth (sensor screening) 29. Idle speed actuator signal (closed) 31. Electroinjector control, cylinder no.4 32. Electroinjector control, cylinder no.5 33. Electroinjector control, cylinder no.6 34. Earth for final stages 36. Evaporative solenoid valve signal 41. Air-flow meter signal | <ul style="list-style-type: none"> 42. Car speed signal input 43. Rpm sensor signal 44. Camanglesensor 47. Engine rpm signal output 48. Climate control unit relay control 52. Ignition cylinders no. 3 and 4 54. Supply from main relay 12V 55. Earth for ignition 56. "Key-operated" supply from secondary relay 59. Reference voltage (5V) for throttle sensor 64. Climate control system signal (compressor cut in request) 65. Climate control system signal (system control) 69. Knock sensor signal 2 70. Knock sensor signal 1 71. Earth for knock sensors 72. Electronic earth for sensors 73. Throttle angle sensor signal 77. Air temperature sensor signal 78. Water temperature sensor signal 87. Diagnosis, line L 88. Diagnosis, line K (also for ALFA ROMEO CODE system) |
|--|---|

LOCATION OF COMPONENTS




3.0 V6

- (•) Black fuseholder
- (••) Red fuseholder
- (1) Black base
- (2) Grey base
- (3) Black base
- (4) Black base
- (5) Red fuseholder
- (6) Brown fuseholder


CHECKING COMPONENTS

Rpm sensor (S31)




SPECIFICATIONS	
Sensor winding resistance 20 °C	~ 540 Ω
Gap between sensor and phonic wheel	0.5 ÷ 1.5 mm

Engine temperature sensor (S7)






SPECIFICATIONS	
Temperature (°C)	Resistance (Ω)
- 10°C	8100 ÷ 10770 Ω
+ 20°C	2280 ÷ 2720 Ω
+ 80°C	292 ÷ 362 Ω

Intaken air temperature sensor (S34)




SPECIFICATIONS	
Temperature (°C)	Resistance (Ω)
- 10°C	8100 ÷ 10770 Ω
+ 20°C	2280 ÷ 2720 Ω
+ 80°C	292 ÷ 362 Ω

Air flow meter (S5)




- pin 1 - Earth
- pin 2 - Reference earth
- pin 3 - 12 V supply
- pin 4 - Measurement signal
- A = air
- Rs = hot film sensor

Throttle position sensor (S38)




SPECIFICATIONS	
Resistance between terminals:	
1 - 2 (fixed)	≈ 2 kΩ
1 - 3 (throttle closed)	≈ 1 kΩ
1 - 3 (throttle completely open)	≈ 2.7 kΩ

Cam angle sensor **(S52)**




SPECIFICATIONS	
The voltage signal "lowers" sharply when the tooth machined on the camshaft passes in front of the sensor itself:	
Gap T = 0.1 ÷ 1.5 mm	



pin 1 - Supply
pin 2 - Signal output
pin 3 - Earth

Lambda probe **(S35)**




SPECIFICATIONS	
Heating resistance	3 Ω

Electroinjectors **(S3)**




SPECIFICATIONS	
Winding resistance	15.9 ± 0.35 Ω

Fuel pump **(P18)**




SPECIFICATIONS	
Flow rate	≥120 l/h
Pressure	4 bar
Nominal voltage	12V

Idle speed adjustment actuator **(S29)**




SPECIFICATIONS	
Resistance between terminals:	
1 - 3	~ 26 Ω
1 - 2	~ 13 Ω
2 - 3	~ 13 Ω

Ignition coil **(A8)**




SPECIFICATIONS	
Primary resistance	0.5 Ω
Secondary resistance	13.3 kΩ

Evaporative solenoid valve **(M15)**




SPECIFICATIONS	
Duty-cycle signal	12 V; 10 Hz
Ohmic resistance of the winding	26 ± 4 Ω
When not energized the solenoid valve is normally closed	

Inertial switch **(H20)**




SPECIFICATIONS	
Check the continuity between pins NC and C: this continuity is cut off in the event of a crash; the contact is re-connected by pressing the special pushbutton	

E.G.R. Solenoid valve **L46**



SPECIFICATIONS	
Duty cycle signal	12V; 15.3 Hz
Ohmic resistance of winding	~ 30Ω

Knock sensor **S20a** **S20b**



SPECIFICATIONS		
Resonance frequency	> 20 kHz	
Impedance	≥ 1 MΩ	
Vibration allowed	for long periods	≤ 80 g
	for short periods	≤ 40 g

FAULT-FINDING

The control unit possesses a self-diagnosis system which continuously monitors the signals leading from the different sensors for plausibility and compares them with the allowed limits: if these limits are exceeded the system detects a fault, memorizes it and turns on the warning light on the instrument cluster.

For certain parameters the control unit replaces the abnormal values with suitable mean values to enable the car to "limp" to a point of the Service Network.

These "recovery" values depend on the other correct signals and are defined each time by the operating logic of the control unit.

The self-diagnosis system also makes it possible to quickly and effectively locate faults by connection with the ALFA ROMEO TESTER, through which all the errors memorised may be "read". It is also possible to check the operating parameters recorded by the control unit and command the engagement of the single actuators to check whether they are working properly.

Diagnosis using the ALFA TESTER

N.B. Before carrying out diagnosis with the Tester, make the preliminary check given on the next page (**TEST A**).

The Tester and the control unit should be connected as follows:

1. Power the Tester either through the cigar lighter socket or connecting it directly to the battery using the special cable.

2. Connect the Tester socket to that of the control unit (the socket is to be found next to the control unit).

The Tester can give the following information:

- display of parameters;
- display of errors;
- active diagnosis.

Error clearing

Before ending diagnosis the contents of the "permanent" memory must be erased using the Tester in the Active Diagnosis mode.

PRELIMINARY CHECK OF THE BOSCH M3.7 SYSTEM	TEST A
---	---------------

NOTE: Check beforehand that the ALFA ROMEO CODE is working properly which might have cut off the supply to the system!


TEST PROCEDURE		RESULT	CORRECTIVE ACTION
A1	CHECK FUSE	OK →	Carry out step A2
	– Check intactness of fuses S36, S46, S47 and G389	OK →	
			Change fuses S36 : 40A S46 : 7.5A S47 : 10A G389 : 10A (from chassis no. ___)
A2	CHECK VOLTAGE	OK →	Carry out step A3
	– Check for 12 V at pin 30 of relays S41, S42 and S12a and also at pin 86 of S41	OK →	
			Restore the wiring between the battery A1 and relays S41, S42 and S12a
A3	CHECK VOLTAGE	OK →	Carry out step A4
	– With the key turned, check for 12 V at pin 86 of relay S42	OK →	
			Restore the wiring between the ignition switch B1 and relay S42 and from chassis no. ___ through fuse G389
A4	CHECK RELAYS	OK →	Carry out step A5
	– Check the correct operation of relays S41, S42 and S12a	OK →	
			Change any faulty relays
A5	CHECK CONTROL UNIT SUPPLY	OK →	Carry out step A6
	– Check for 12 V at pin 26 of control unit S11 ; with the key turned 12 V also at pins 54 and 56 of S11 and appr. 0 V (very low voltage) at pin 1 and 27 of S11	OK →	
			Restore the wiring between the control unit S11 and the relays and between the control unit and fuse S46
A6	CHECK EARTH	OK →	CONTINUE DIAGNOSIS USING THE ALFA ROMEO TESTER
	– Check for an earth at pins 6 and 34. Also check for an earth at pin 85 of S42 and at pin 85 of S12a	OK →	
			Restore the wiring between S11 and the relays and earth G131a

ABS SYSTEM (BOSCH 2Si)

INDEX

WIRING DIAGRAM	31-2
GENERAL DESCRIPTION	31-3
FUNCTIONAL DESCRIPTION	31-3
LOCATION OF COMPONENTS	31-4
FAULT-FINDING	31-5

WIRING DIAGRAM



GENERAL DESCRIPTION

The car is equipped with an electronic wheel anti-lock system (**BOSCH 2Si**) which adjusts the braking pressure transmitted to the wheels preventing loss of road-holding under all tyre and road conditions.

The system has been designed to integrate, and not replace, the normal mechanical braking system, guaranteeing a high degree of safety in the event of a failure: in fact it operates on the same brake fluid as the conventional mechanical circuit.

Four sensors, located on the four wheels, inform the electronic control unit of the speed of each wheel continuously, thereby recording locking situations affecting the wheels, skidding and loss of grip.


In these situations, the control unit suitably operates the solenoid valves that modulate the pressure in the hydraulic circuit, eliminating wheel locking and bringing the car back to the limit of roadholding, which means that the braking distance is reduced to a minimum, without losing control of steering.

The **modulating solenoid valves** are, in this version of the system, four, one for each wheel.

Components

The system comprises:

- four magnetic induction sensors which read the speed of the wheels: **L28; L29; L30; L31**.
- the integrated electronic and hydraulic control unit **N51**, which houses the following:
 - the electronic control module (CPU)
 - the four solenoid valves
 - the brake fluid pump
 - a safety relay
 - a pump control relay
- the connector for self-diagnosis **T8**
- the brake switch **H3** (the same that turns on the stop lights) which signals the system the braking condition.

The ABS includes a self-diagnosis system which continually monitors all the system parameters and components: in the event of a failure or fault, the system cuts itself off automatically leaving the conventional servo-assisted mechanical braking system operational: the driver is alerted of this situation by a special warning light  on the instrument cluster (**C10**).

Connecting to the diagnosis connector (**T8**) located next to the control unit, it is possible to use the signals of the "flashing code" to quickly locate the faulty component (see "Fault-finding").

The connector **T8** can also be used to connect to the ALFA ROMEO Tester.

FUNCTIONAL DESCRIPTION

System supply:

With a line protected by wander fuse **G125a** (10A) the key-operated voltage - leading from relay **I108** and from fuse **G384** - supplies pin 1 of connector **G272** of the ABS hydraulic unit **N51**, and from here it supplies the safety relay and energizes the coil: this way the relay supplies with battery voltage -leading from pin 2 of **G272** and from the line protected by fuse **G125b** (60A) - the electronic module and the coil of the engine relay: following a command from the electronic module, this operates the pump motor which delivers the pressure of the brake fluid to the wheels.

The electronic module and relays are earthed by pin 4 of connector **G272**, while the pump is earthed by connector **G202**.


Sensors and solenoid valves:

Directly inside the control unit **N51**, the module is connected with three adjustment solenoid valves, which modulate the pressure on the brakes of the four wheels; outside, through connector **G273**, it is connected with the four sensors **L28 - L29 - L30 - L31** which signal the speed of the single wheels, and with the brake switch **H3**, which sends a consent signal: in fact the ABS system cannot come into operation if the brake pedal is not pressed.

Self-diagnosis:

When the control unit detects problems through the self-diagnosis function, it sends a signal to the instrument cluster **C10** which turns on the ABS warning light: this signal depends on a failure of the electronic module -pin 1 of connector **G273**- or on the hydraulic control - pin 3 of **G272**. The diagnosis connector **T8**, allows connection of the control unit with the ALFA ROMEO Tester or "reading" of the flashing code (see "Fault-finding").

LOCATION OF COMPONENTS



(•) Blue base
(••) Black fuseholder

FAULT-FINDING

AUTOMATIC CHECK UPON IGNITION: when the car is started the "ABS warning light" on the instrument cluster turns on for appr. 2 secs., then it goes off meaning that the system is working properly. If the warning light stays on, carry out diagnosis using the flashing code, as mentioned previously.

If the warning light does not turn on, carry out **test J**.

Fault-Finding using the Flashing Code

The self-diagnosis system with which this system is fitted, makes it possible to quickly locate a faulty component following the instructions of a **FLASHING CODE**, which is activated as follows:

- earth the line of pin 1 of connector **T8**

- power the ABS control unit **N51** ("key-operated" supply")

Read the sequence of flashes on the "ABS warning light" on the instrument panel **C10**:

- for three times code "12" appears, meaning correct operation: if this does not occur, carry out **test J**
- the codes of the errors memorised appear (each repeated three times): carry out the test given in the following table
- code "12" appears for another three times, indicating the end of the sequence

NOTE: Resetting the memorised code is obtained by disconnecting the line of pin 1 of **T8** and engaging the ignition switch 20 times (or using the ALFA ROMEO Tester)

Error Codes Table

CODE	FAULT	CARRY OUT TEST
12	Start and end of diagnosis	—
No code (*)	Control unit and self-diagnosis fault	A
16	Faulty LH front solenoid valve (VL)	Check the impedance of the solenoid valve (1.5÷2.5 Ω) and the condition of the connections between the control unit and the solenoid valve; if necessary change the solenoid valve
17	Faulty RH front solenoid valve (VR)	Check the impedance of the solenoid valve (1.5÷2.5 Ω) and the condition of the connections between the control unit and the solenoid valve; if necessary change the solenoid valve
19	Faulty safety relay	B
25	Incorrect number of phonic wheel teeth	Change the phonic wheel concerned see Group 33 "BRAKES")
26	Faulty LH rear solenoid valve (HL)	Check the impedance of the solenoid valve (1.5÷2.5 Ω) and the condition of the connections between the control unit and the solenoid valve; if necessary change the solenoid valve
27	Faulty RH rear solenoid valve (HR)	Check the impedance of the solenoid valve (1.5÷2.5 Ω) and the condition of the connections between the control unit and the solenoid valve; if necessary change the solenoid valve
35	Faulty pump motor	C
37	Faulty brake switch (H3)	D
39	Faulty LH front sensor (L29)	Check the impedance of the sensor (appr. 1 kΩ); change it if necessary. Then carry out the next test E .
41	LH front sensor (L29) not connected	E
42	Faulty RH sensor (L28)	Check the impedance of the sensor (appr. 1 kΩ); change it if necessary. Then carry out the next test F .
43	RH front sensor (L28) not connected	F
44	Faulty LH rear sensor (L31)	Check the impedance of the sensor (appr. 1 kΩ); change it if necessary. Then carry out the next test G .
45	LH rear sensor (L31) not connected	G
46	Faulty RH rear sensor (L30)	Check the impedance of the sensor (appr. 1 kΩ); change it if necessary. Then carry out the next test H .
47	RH rear sensor (L30) not connected	H
48	Insufficient supply voltage	I
55	Faulty electronic control unit	Change the control unit, contained in N51
56	Operating error in diagnosis	-

(*) if the warning light is not working, see **test J**

Fault-finding using the Alfa Romeo Tester

N.B. Before carrying out diagnosis with the Tester, perform the preliminary check described later (TEST A); if the warning light is not working properly also carry out TEST J.

The connection between the TESTER and the control unit must be made as follows:

1. Supply the TESTER either through the cigar lighter socket or connecting directly to the battery using the special lead.
2. Connect the TESTER socket to the control unit (the socket is near the control unit).

The instrument can give the following information:

- parameter display;
- error display;
- active diagnosis.

ERROR STORAGE:

The control unit self-diagnosis system checks a series of components, checking the operating parameters and logging any faults permanently in the control unit; in this situation the control unit de-activates the sys-

tem and turns on the warning light on the instrument panel.

N.B. the control unit can memorise up to three errors contemporaneously: if a failure is present when three more are memorised, the last one supersedes the "oldest" of the three previous ones.

ERROR CLEARING:

Stored errors may only be cleared SOLELY using the ALFA ROMEO TESTER.

ACTIVATING DIAGNOSIS:

Diagnosis begins with the engine stopped and the ignition key turned to MARCIA.

N.B.: During diagnosis it will also be requested to set the car in motion. Under this circumstance system is disabled and the warning light on the instrument cluster stays on; therefore, the control unit is unable to memorise new errors. Great care is also necessary because in the event of emergency braking, the ABS system is not operational and only the conventional braking system is available.

N.B.:

The system is disabled when the supply voltage falls below 8.6 V, when the solenoid valves are not energized or 9.4 V, when the solenoid valves are energized.

PRELIMINARY SYSTEM CHECK	TEST A
---------------------------------	---------------

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
A1	CHECK FUSES	(OK) ▶	Carry out step A2
	– Check the intactness of wander fuses G125a and G125b	(OK) ▶	Change fuses – G125a (10A) – G125b (60A)
A2	CHECK RELAYS	(OK) ▶	Carry out step A3
	– Check the two relays in unit N51	(OK) ▶	Change the relays if faulty
A3	CHECK VOLTAGE	(OK) ▶	Carry out step A4
	– Check for 12 V at pin 2 of G272	(OK) ▶	Restore the wiring between pin 2 of G272 and branch terminal board G56
A4	CHECK VOLTAGE	(OK) ▶	Carry out step A5
	– Turn the key and check for 12 V at pin 1 of G272	(OK) ▶	Restore the wiring between pin 1 of G272 and the fuse box G1 , through fuse G125a , and relay I108
A5	CHECK EARTH	(OK) ▶	Carry out step A6
	– Check that G202 is earthed	(OK) ▶	Restore the wiring between G202 and earth G63
A6	CHECK EARTH	(OK) ▶	CONTINUE DIAGNOSIS USING THE ALFA ROMEO TESTER OR USING THE FLASHING CODE
	– Check that pin 4 of G272 is earthed	(OK) ▶	Restore the wiring between pin 4 of G272 and earth G55b

FAULTY SAFETY RELAY	TEST B
----------------------------	---------------

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
B1	CHECK RELAY	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	Carry out step B2
	– Check that the safety relay is working properly (in group N51)	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	Change the relay
B2	CHECK VOLTAGE	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	Carry out step B3
	– Check for 12 V at pin 87 of the safety relay	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	In this case breaks of the connection between G272 and the safety relay are likely. Change group N51
B3	CHECK VOLTAGE	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	Carry out step B4
	– Turn the key and check for 12 V at pin 86 of the safety relay	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	In this case breaks of the connection between G272 and the safety relay are likely. Change group N51
B4	CHECK VOLTAGE	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	Change the motor relay (also see test C)
	– Turn the key and check for 12V at pin 86 of the motor relay	<div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin: 0 auto;"> OK ▶ </div>	Change group N51

FAULTY PUMP MOTOR	TEST C
--------------------------	---------------

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
C1	CHECK RELAY	(OK) ►	Carry out step C2
– Check the correct operation of the motor relay (in group N51)		(OK) ►	Change the relay, contained in N51
C2	CHECK VOLTAGE	(OK) ►	Carry out step C3
– Check for 12 V at pin 87 of the motor relay		(OK) ►	In this case breaks are likely in the connection between G272 and the motor relay. Change group N51
C3	CHECK VOLTAGE	(OK) ►	Carry out step C4
– Turn the key and check for 12 V at pin 86 of the motor relay		(OK) ►	Check the safety relay (see test B). If not, breaks are likely in the connection between the safety relay and the motor relay. Change group N51
C4	CHECK EARTH	(OK) ►	Carry out step C5
– Check for 0 V at pin (-) of the pump motor		(OK) ►	In this case breaks are likely in the connection between pin (-) of the pump motor and G202 . Change group N51
C5	CHECK PUMP	(OK) ►	If necessary , check the brake hydraulic circuit. (see Group 33 "BRAKES")
– Bridge pins 30 and 87 of the motor relay. Check that the pump motor is working properly		(OK) ►	Change group N51 , complete with pump motor

FAULTY BRAKE SWITCH	TEST D
----------------------------	---------------

TEST PROCEDURE	RESULT	CORRECTIVE ACTION
D1 CHECK STOP LIGHTS – Check that the stop lights are working properly	(OK) ► (OK) ►	Carry out step D2 Change the stop lights switch H3 , or proceed as described in the "STOP LIGHTS" section
D2 CHECK VOLTAGE – With the pedal pressed, check for 12 V at pin 9 of G273	(OK) ► (OK) ►	Check and if necessary change the electronic control unit contained in N51 Restore the wiring between pin 9 of G273 and H3

LH FRONT SENSOR NOT CONNECTED	TEST E
--------------------------------------	---------------

TEST PROCEDURE	RESULT	CORRECTIVE ACTION
E1 CHECK OPEN CIRCUIT – Turn the key and check for an open circuit between pins 7 and 13 of G273	(OK) ► (OK) ►	Carry out step E2 Carry out step E3
E2 CHECK CONTINUITY – Disconnect the sensor L29 and check for continuity between the sensor and pin 7 of G273 , and between the sensor and pin 13 of G273	(OK) ► (OK) ►	Check and if necessary change the sensor L29 . Restore the wiring between L29 and G273
E3 CHECK OPEN CIRCUIT – Disconnect the sensor L29 and check for an open circuit between pins 7 and 13 of G273 (wiring side)	(OK) ► (OK) ►	Check and if necessary change sensor L29 . Restore the wiring eliminating the short circuit between the cables connecting L29 with G273

RH FRONT SENSOR NOT CONNECTED	TEST F
--------------------------------------	---------------

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
F1	CHECK OPEN CIRCUIT	(OK) ▶	Carry out step F2
	– Turn the key and check for an open circuit between pins 5 and 11 of G273	(OK) ▶	
			Carry out step F3
F2	CHECK CONTINUITY	(OK) ▶	Check and if necessary change the sensor L28 .
	– Disconnect the sensor L28 check for continuity between the sensor and pin 5 of G273 , and between the sensor and pin 11 of G273	(OK) ▶	Restore the wiring between L28 and G273
F3	CHECK OPEN CIRCUIT	(OK) ▶	Check and if necessary change the sensor L28 .
	– Disconnect the sensor L28 and check for an open circuit between pins 5 and 11 of G273 (wiring side)	(OK) ▶	Restore the wiring eliminating the short circuit between the cables connecting L28 with G273

LH REAR SENSOR NOT CONNECTED	TEST G
-------------------------------------	---------------

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
G1	CHECK OPEN CIRCUIT	(OK) ▶	Carry out step G2
	– Turn the key and check for an open circuit between pins 4 and 2 of G273	(OK) ▶	
			Carry out step G3
G2	CHECK CONTINUITY	(OK) ▶	Check and if necessary change the sensor L31 .
	– Disconnect the sensor L31 and check for continuity between the sensor and pin 4 of G273 , and between the sensor and pin 2 of G273	(OK) ▶	Restore the wiring between L31 and G273
G3	CHECK OPEN CIRCUIT	(OK) ▶	Check and if necessary change the sensor L31 .
	– Disconnect the sensor L31 and check for an open circuit between pins 4 and 2 of G273 (wiring side)	(OK) ▶	Restore the wiring eliminating the short circuit between the cables connecting L31 with G273

RH REAR SENSOR NOT CONNECTED	TEST H
-------------------------------------	---------------

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
H1	CHECK OPEN CIRCUIT	OK ▶	Carry out step H2
	– Turn the key and check for an open circuit between pins 6 and 14 of G273	OK ▶	
			Carry out step H3
H2	CHECK CONTINUITY	OK ▶	Check and if necessary change the sensor L30 .
	– Disconnect the sensor L30 and check for continuity between the sensor and pin 6 of G273 , and between the sensor and pin 14 of G273	OK ▶	
			Restore the wiring between L30 and G273
H3	CHECK OPEN CIRCUIT	OK ▶	Check and if necessary change the sensor L30 .
	– Disconnect the sensor L28 and check for an open circuit between pins 6 and 14 of G273 (wiring side)	OK ▶	
			Restore the wiring eliminating the short circuit between the cables connecting L30 with G273

INSUFFICIENT SUPPLY VOLTAGE	TEST I
------------------------------------	---------------

TEST PROCEDURE		RESULT	CORRECTIVE ACTION
I1	CHECK VOLTAGE	OK ▶	Carry out step I2
	– Check that the battery voltage is 12V	OK ▶	
			Restore the correct voltage recharging or changing the battery A1
I2	CHECK VOLTAGE	OK ▶	Carry out step I3
	– Check for a voltage of 12 V at pin 2 of G272	OK ▶	
			Restore the wiring between pin 2 of G272 and the battery A1 , through fuse G125b
I3	CHECK VOLTAGE	OK ▶	CONTINUE DIAGNOSIS USING THE ALFA ROMEO TESTER
	– With the key turned, check for a voltage of 12 V at pin 1 of G272	OK ▶	
			Restore the wiring between pin 1 of G272 and the fusebox G1 , through fuse G125a , and relay I108

"ABS" WARNING LIGHT NOT WORKING (fails to turn on for faults)	TEST J
--	---------------

	TEST PROCEDURE	RESULT	CORRECTIVE ACTION
J1	CHECK CONTINUITY	(OK) ►	Carry out step J2
	– Check the continuity between pin 12 of G273 and pin 3 of connector T8 and between pin 15 of G273 and pin 1 of T8	(OK) ►	Restore the wiring between G273 and connector T8
J2	CHECK EARTH SIGNAL	(OK) ►	Change the instrument cluster C10
	– Turn the key and check for, 0V for a few seconds at pin B3 of the instrument cluster C10	(OK) ►	Carry out step J3
J3	CHECK EARTH SIGNAL	(OK) ►	Restore the wiring between G273 and C10 Also check the wiring between pin 3 of G272 and C10
	– Turn the key and check for, 0V for a few seconds at pin 1 of G273	(OK) ►	Change the control unit contained in N51

KEY TO COMPONENTS

A STARTING - RECHARGING

- A1 Battery
- A3 Alternator, with integrated voltage regulator
- A8 Ignition coil
- A8a Ignition coil A
- A8b Ignition coil B
- A11 Starter motor
- A12 Spark plugs

B MANUAL ELECTRICAL CONTROLS

- B1 Ignition switch
- B9 Heated rearscreen control switch
- B10 Fog lights control switch
- B11 Rear fog guards control switch
- B12 Hazard warning lights control switch
- B16 Instrument panel light dimmer button
- B21a Right front power window control switch (on RH door)
- B21b Right front power window control switch (on LH door)
- B36 Wing mirror control switch
- B40 Trip meter reset switch
- B47 Sun roof motor control switch
- B53 Front power window switch with automatic mechanism
- B61 Fuel flap opening switch
- B68 Steering column lever unit
- B69 Headlamp aiming device
- B87 Luggage compartment opening switch with glove box light
- B98 Air recirculation switch
- B99 Hood release switch
- B100 Hood cover release switch
- B101 Automatic hood control switch

C INSTRUMENTATION

- C10 Instrument cluster
- C18 Auxiliary instrument cluster

D WARNING LIGHTS

- D31 Anti-theft device led indicator
- D43 Signalling led for automatic hood

E EXTERIOR LIGHTS

- E1a LH front direction indicator bulb
- E1b RH front direction indicator bulb
- E2a LH front side light bulb
- E2b RH front side light bulb
- E5a LH low beam light bulb
- E5b RH low beam light bulb
- E7a LH high beam light bulb
- E7b RH low beam light bulb
- E9a LH direction indicator light bulb
- E9b RH direction indicator light bulb
- E10a LH fog light bulb
- E10b RH fog light bulb
- E17a LH number plate light bulb

- E17b RH number plate light bulb
- E19 RH tail light cluster
- E20 LH tail light cluster
- E28 Third stop light
- E30 Rear RH fog guard/reversing light
- E31 Rear LH fog guard/reversing light

F INTERIOR LIGHTS

- F3 Passenger compartment ceiling light
- F5 Luggage compartment light
- F8a Heating/ventilation controls light bulb a
- F8b Heating ventilation controls light bulb b
- F23 RH foot well light
- F24 LH foot well light
- F45 Light on LH front door
- F46 Light on RH front door

G FUSEBOX - CONNECTORS - EARTHS

- G1 Fusebox
- G3 Fusebox terminal connector
- G4 Free fuse
- G21 Connector for RH front door wiring
- G23 Connector for LH front door wiring
- G38 Air conditioner wiring connector
- G43 Connector for heating and ventilation control wiring
- G53a RH engine compartment earth
- G53b LH engine compartment earth
- G55b LH side panel earth
- G56 Branch terminal board
- G60 Injection wiring earth
- G63a RH rear earth
- G63b LH rear earth
- G65 Coaxial cable for aerial
- G73 Connector for rear services
- G73b Connector for rear services
- G84 Console wiring connector
- G92 Luggage compartment earth
- G99 Connector for dashboard wiring/engine wiring
- G115 Connector for tow bar trailer socket
- G124 ABS system connector
- G125a ABS system fuse
- G125b ABS system fuse
- G131 Earth on upper cover
- G133a Connector for electronic injection wiring A
- G133b Connector for electronic injection wiring B
- G148b Earth under dashboard LH
- G193 Connector for electric aerial wiring
- G202 Connector for ABS system earth
- G219 Connector for sun roof
- G254 Fuse for engine fan
- G255 Fuse for heating and ventilation fan
- G261 Fuse for sun roof
- G272 Connector for ABS hydraulic unit
- G273 ABS control unit connector
- G308 Connector for engine sensors
- G310 Fuse for RH front power window
- G311 Fuse for LH front power window
- G313 Connector for additional conditioner wiring

- G314a Connector for engine wiring / conditioner wiring A
- G314b Connector for engine wiring / conditioner wiring B
- G320 Connector for rear loudspeaker cables
- G337 Connector for conditioner syst./injection syst.
- G380 Airbag connector
- G380a Airbag connector
- G381 Earth for airbag
- G383 Connector for airbag capsule
- G384 Services supply fuse
- G385 Connector for wiring in front bumper
- G389 Fuse for ALFA ROMEO CODE unit
- G391 Rear fog guard fuse
- G399 Dashboard connector for automatic hood
- G400 Rear connector for automatic hood
- G401 Fuse for automatic hood system
- G402 Fuse for automatic hood control unit
- G403 Fuse for automatic hood switch
- G404 Fuse for automatic hood switch
- G405 Automatic hood power window opening fuse
- G406 Automatic hood power window closing fuse

H SWITCHES

- H1 Handbrake switch
- H2 Reversing light switch
- H3 Stop lights switch
- H9 RH front brake pad switch
- H10 LH front brake pad switch
- H17 Brake fluid minimum level switch
- H20 Inertial switch
- H24 Luggage compartment light switch
- H44 Bonnet anti-theft device switch
- H51 Sun roof stroke limit switch
- H55a RH hood closing switch
- H55b LH hood closing switch
- H56a RH hood cover closing switch
- H56b LH hood cover closing switch
- H57 "5th arc" raised switch
- H58 Intermediate "5th arc" switch
- H59 Hood cover raised switch
- H60 Hood position switch

I RELAYS

- I2 Heated rearscreen relay
- I3 Horn relay
- I17 Fog light relay
- I26 Ceiling light relay
- I29 Fuel pump relay
- I35 Key-operated supply relay
- I49 Low beam relay
- I50 High beam relay
- I52 Luggage compartment opening relay
- I53 Fuel flap opening relay
- I58 Sun roof relay
- I64 Side lights relay
- I99 Engine cooling fan 1st speed relay
- I99a Engine cooling fan 1st speed relay
- I99b Engine cooling fan 1st speed relay
- I100 Engine cooling fan 2nd speed relay

- I106 Hood release relay
- I106b Hood emergency release relay
- I107a Hood cover release relay
- I107b Hood cover release relay
- I108 Key-operated supply cutoff relay
- I109 Anti-theft switch relay
- I112a RH hood closing relay
- I112b LH hood closing relay
- I113 Hood cover closing relay
- I114a LH power window opening relay
- I114b RH power window closing relay
- I115a LH power window closing relay
- I115b RH power window closing relay
- I116 Automatic hood control relay
- I117 Automatic hood electric pump relay

L SENDERS

- L2 Minimum engine oil pressure
- L9 Sender for fuel level gauge
- L10 Sender for engine coolant temperature gauge and max. temperature warning light contact
- L17 Speedometer sensor
- L28 RH front phonic wheel inductive sensor
- L29 LH front phonic wheel inductive sensor
- L30 RH rear phonic wheel inductive sensor
- L31 LH rear phonic wheel inductive sensor
- L33 Two-level thermal contact
- L46 E.G.R. solenoid valve

M ELETTRIC MAGNETS - SOLENOID VALVES

- M12 Luggage compartment opening actuator electromagnet
- M13 Fuel flap opening actuator electromagnet
- M15 Evaporation solenoid valve
- M26a LH hood release actuator electromagnet
- M26b RH hood release actuator electromagnet
- M27 Hood cover release actuator electromagnet
- M27a LH hood cover release actuator electromagnet
- M27b RH hood cover release actuator electromagnet
- M28 Automatic hood solenoid valve

N ELECTRONIC DEVICES - INTERMITTENCES- TIMERS

- N11 Door locking control unit
- N13 Hazard warning lights and direction indicators intermittence
- N14 Electronic windscreen wiper intermittence
- N18 Electronic headlamp switching device
- N25 Rear fog guard electronic device
- N38 Power window control unit
- N45 Anti-theft device control unit
- N51 Hydraulic unit with ABS control unit
- N53 Anti-disturbance condenser on luggage compartment light
- N60 Sun roof control unit
- N67 Remote control signal receiver
- N77 ALFA ROMEO CODE control unit
- N78 ALFA ROMEO CODE receiver
- N79 Car radio supply antisturbance condenser
- N80 Hood cover release timer

O SERVICES

- O1 Heated rearscreen
- O2a High tone horn
- O2b Low tone horn
- O3 Aerial
- O4 Car radio
- O5a RH front loud-speaker
- O5b LH front loud-speaker
- O5c RH rear loud-speaker
- O5d LH rear loud-speaker
- O6 Cigar lighter - current socket
- O18 RH wing mirror defroster
- O19 LH wing mirror defroster
- O22a Additional engine fan resistance
- O22a Additional engine fan resistance
- O31a RH Tweeter loud-speaker
- O31b LH Tweeter loud-speaker
- O37 Rear subwoofer speaker

P ELECTRIC MOTORS

- P2 Engine cooling fan
- P2a Engine cooling fan
- P2b Engine cooling fan
- P8 LH wing mirror motor
- P9 RH wing mirror motor
- P10 Front RH door lock motor
- P11 Front LH door lock motor
- P14 Front RH power window motor
- P15 Front LH power window motor
- P18 Electric fuel pump
- P19 Windscreen and rearscreen washer pump
- P24 Sun roof motor
- P27 Windscreen wiper motor with control unit
- P35a RH headlamp aiming motor
- P35b LH headlamp aiming motor
- P51 Automatic hood control pump

Q HEATING/VENTILATION - AIR CONDITIONING

- Q1 Heater fan
- Q4 Heater fan control
- Q5 Heater fan speed adjustment resistance
- Q9 Minimum pressure switch
- Q11 Compressor electromagnetic coupling
- Q15 Heating and ventilation fan relay
- Q20 Min. and max. sensor pressure contact (Tertiary)
- Q22 Electromagnetic coupling relay
- Q27 Air recirculation flap control motor
- Q32 Auxiliary relay for heating and ventilation
- Q39 Fuse for conditioning system (30A)
- Q40 Fuse for conditioning system (15A)

- Q41 Set of relay and fuses for air conditioner
- Q42 Conditioner fan delay device
- Q65 Fuse for conditioning system
- Q68 Compressor and air recirculation engagement switches
- Q69 Heater fan 1st speed relay

R SAFETY DEVICES

- R22 Airbag control unit
- R23 Capsule on steering wheel for airbag
- R27 Passenger's side airbag capsule
- R28 Capsule on RH pretensioner
- R29 Capsule on LH pretensioner





S ELECTRONIC INJECTION

- S3 Elettroinjectors
- S5 Air flow meter
- S7 Engine temperature sensor
- S11 Motronic control unit
- S12a Motronic fuel pump relay
- S12c Phase variator relay
- S12e Air flow meter relay
- S15 Phase variator
- S20 Pinging sensor
- S20a Pinging sensor a
- S20b Pinging sensor b
- S29 Idle adjustment actuator
- S31 Rpm and crankshaft position sensor
- S34 Air temperature sensor
- S35 Heated lambda probe
- S36 Fuse for injection relay
- S38 Sensor on throttle body
- S41 Main relay
- S42 Secondary relay
- S43 Absolute pressure sensor
- S45 Lambda probe fuse
- S46 Fuse for Motronic supply
- S47 Fuse for fuel pump
- S52 Cam angle sensor

T DIAGNOSIS

- T1 Connector for ALFA TESTER (Motronic and ALFA ROMEO CODE)
- T3 Connector for ALFA TESTER (airbag)
- T7 Connector for ALFA TESTER (anti-theft device)
- T8 Connector for ALFA TESTER (ABS)
- T13 Diagnosis connector for ALFA ROMEO TESTER (automatic hood)









COMPONENTS AND CONNECTORS











(*) from chassis no. _____
 PA49720000006

Ignition coil		(A8)
Starter motor		(A11)
Ignition switch	(B1) (A)	
Ignition switch	(B1) (B)	
Heated rearscreen control switch	(B9)	
Fog lights control switch	(B10)	

(*) from chassis no. _____
 PA497200000005


<p>Rear fog guards control switch</p>	<p>B11</p>	<p>Hazard warning lights control switch</p>	<p>B12</p>
			
<p>Instrument panel light dimmer button</p>	<p>B16</p>	<p>Right front power window control switch (on RH door)</p>	<p>B21a</p>
			
<p>Right front power window control switch (on LH door)</p>	<p>B21b</p>	<p>Wing mirror control switch</p>	<p>B36</p>
			
<p>Trip meter reset switch</p>	<p>B40</p>	<p>Sun roof motor control switch</p>	<p>B47</p>
			<p>GTV</p>

<p>Front power window switch with automatic mechanism</p>	<p>(B53)</p>	<p>Fuel flap opening switch</p>	<p>(B61)</p>
			
<p>Steering column lever unit</p>	<p>(B68) A</p>	<p>Steering column lever unit</p>	<p>(B68) B</p>
			
<p>Steering column lever unit</p>	<p>(B68) C</p>	<p>Steering column lever unit</p>	<p>(B68) D</p>
			
<p>Steering column lever unit</p>	<p>(B68) E</p>	<p>Headlamp aiming device</p>	<p>(B69)</p>
			


<p>Luggage compartment opening switch with glove box light (B87)</p>	<p>Air recirculation switch (B98)</p>
<p>Hood release switch (B99)</p> <p>SPIDER</p>	<p>Hood release switch (*) (B99)</p>
<p>Hood release switch (B99)</p>	<p>Hood cover release switch (B100)</p> <p>SPIDER</p>
<p>Hood cover release switch (*) (B100)</p>	<p>Hood cover release switch (B100)</p>

(*) from chassis no. _____
PA497200000005


Automatic hood control switch B101



Instrument cluster C10 A



Instrument cluster C10 B



(*) from chassis no. _____
PA49720000005




Auxiliary instrument cluster		C18
Anti-theft device led indicator	D31	Signalling led for automatic hood
LH front direction indicator bulb		E1a
RH front direction indicator bulb	E1b	LH front side light bulb

(*) from chassis no. _____



<p>RH front side light bulb.</p>	<p>E2b</p>	<p>LH low beam light bulb</p>	<p>E5a</p>
<p>RH low beam light bulb</p>	<p>E5b</p>	<p>LH high beam light bulb</p>	<p>E7a</p>
<p>RH high beam light bulb</p>	<p>E7b</p>	<p>LH direction indicator light bulb</p>	<p>E9a</p>
<p>RH direction indicator light bulb</p>	<p>E9b</p>	<p>LH fog light bulb</p>	<p>E10a</p>

<p>RH fog light bulb</p>	<p>E10b</p>	<p>LH number plate light bulb</p>	<p>E17a</p>
<p>RH number plate light bulb</p>	<p>E17b</p>	<p>RH tail light cluster</p>	<p>E19</p>
<p>LH tail light cluster</p>			<p>E20</p>
<p>Third stop light</p>			<p>E28</p>
<p>GTV</p>		<p>SPIDER</p>	



<p>Rear RH fog guard/reversing light (E30)</p>	<p>Rear LH fog guard/reversing light (E31)</p>
<p>Passenger compartment ceiling light (F3)</p>	<p>Luggage compartment light (F5)</p>
<p>Heating/ventilation controls light bulb a (F8a)</p>	<p>Heating ventilation controls light bulb b (F8b)</p>
<p>RH foot well light (F23)</p>	<p>LH foot well light (F24)</p>





(*) up to chassis no _____
 PA49720000006




(*) up to chassis no. _____
 PA497200000005




(*) from chassis no. _____
 PA49720000005



Fusebox G1 H



Fusebox G1 I







(*) from chassis no. _____
 PA49720000005

<p>Fusebox G1 J</p>	<p>Fusebox G1 L</p>
<p>Fusebox G1 M</p>	<p>Fusebox G1 Q</p>
<p>Fusebox terminal connector G3</p>	<p>Free fuse G4</p>

(*) up to chassis no. _____

Connector for RH front door wiring (vehicle side)

G21



1 1.5PNK-BLK • 04 [A]

2 1.5BLK-PPL • 04 [A]

3 RED —◇— 1ORN-BLU • G1 [G]

4 PPL-WHT —◇— 1.5PPL • I26

5 1BRN-WHT —◇—
 1BRN-WHT • G23
 1.5BRN-WHT • G1 [G]

6 GRY-GRN • G84

7 YEL-RED —◇—
 YEL-RED • G84
 YEL-RED • G23

8 LTB-WHT • G84

9 N.C.

10 N.C.

11 1.5GRN-BLK • G23

12 1.5GRN • G23

13 N.C.

14 N.C.

15 1YEL —◇—
 1YEL • G23
 1.5YEL • G1 [G]

16 1GRY —◇—
 1GRY • G23
 1.5GRY • G1 [G]

17 WHT —◇—
 WHT • G99
 WHT • G23
 WHT • G1 [L]

18 LTB —◇—
 LTB • G99
 LTB • G23
 LTB • G1 [L]

19 GRY-GRN —◇—
 GRY-GRN • G99
 GRY-GRN • C10 [A]

20 N.C.





21 N.C.

22 1.5BLK • G148b

23 N.C.


Connector for RH front door wiring (door side)

G21



- 1 1.5PNK-BLK — — 1.5PNK-BLK • (05a)
 1.5PNK-BLK • (031a)
- 2 1.5PPL-BLK — — 1.5PPL-BLK • (05a)
 1.5PPL-BLK • (031a)
- 3 RED • (F46)
- 4 PPL-WHT • (F46)
- 5 1BRN-WHT • (018)
- 6 GRY • (P9)
- 7 YEL-RED • (P9)
- 8 LTB • (P9)
- 9 N.C.
- 10 N.C.
- 11 1.5GRN-BLK • (B21a)
- 12 1.5GRN • (B21a)
- 13 N.C.





- 14 N.C.
- 15 1YEL • (P10) [A]
- 16 1GRY • (P10) [A]
- 17 WHT • (P10) [A]
- 18 LTB • (P10) [A]
- 19 GRY-GRN • (P10) [B]
- 20 N.C.
- 21 N.C.



- 23 N.C.

Connector for LH front door wiring (chassis side)

G23



1 1.5RED-BLK • (04) [A]

2 1.5WHT-BLK • (04) [A]

3 RED —◇— 10RN-BLU • (G1) [G]
RED • G21

4 1PPL-WHT —◇— 1.5PPL • (I26)

5 1BRN-WHT —◇— 1BRN-WHT • G21
1.5BRN-WHT • (G1) [G]

6 GRY-RED • G84

7 YEL-RED —◇— YEL-RED • G84
YEL-RED • G21

8 LTB-RED • G84

9 10RN-BLK • (N38) [A]

10 10RN • (N38) [A]

11 1.5GRN-BLK • G21

12 1.5GRN • G21

13 1.5PPL-YEL • (N38) [B]

14 1.5WHT-GRN • (N38) [B]

15 1YEL —◇— 1YEL • G21
1.5YEL • (G1) [G]

16 1GRY —◇— 1GRY • G21
1.5GRY • (G1) [G]

17 WHT —◇— WHT • G99
WHT • G21
WHT • (G1) [L]

18 LTB —◇— LTB • G99
LTB • G21
LTB • (G1) [L]

19 GRY-YEL —◇— GRY-YEL • G99
CRY-YEL • (C10) [A]

20 N.C.



21 1PPL-BLK —◇— 1.5BLK • G148b

22 1.5BLK • G148b


23 1.5PNK • (G310)

Connector for LH front door wiring (door side)


G23




Air conditioner wiring connector **G38**




Connector for heating and ventilation control wiring **G43**




RH engine compartment earth **G53a**




(*) 2.0 TS 16v up to chassis no.6023906






Connector for rear services

G73



Connector for rear services (*)


G73b



(*) from chassis no _____
 PA497200000005

Connector for dashboard wiring/engine wiring

G99




(*) from chassis no.6023907

ABS system connector		G124
ABS system fuse	G125a	ABS system fuse
Earth on upper cover	G131a	Earth on upper cover
Connector for electronic injection wiring A		G133a

(*) from chassis no ____
 PA497200000006


Connector for electronic injection wiring A


G133a




Connector for electronic injection wiring B

G133b









Connector for engine sensors

G308

2.0 T.S. 16v



3.0 V6





Fuse for RH front power window

G310


Fuse for LH front power window


G311



Connector for additional conditioner wiring

G313






(*) from chassis n° _____
 PA49720000005



Connector for conditioner syst./injection syst.		G337	
2.0 T.S. 16v			
<p>1GRN-WHT • S11 3</p> <p>1GRY-YEL • S11 2</p> <p>1BRN-BLK • S11 1</p>	<p>3 GRY • Q9</p> <p>2 1GRY-YEL ◊ 1GRY-YEL • Q20</p> <p>1 1BRN-WHT • Q41 [A]</p>		
3.0 V6			
<p>1GRY-YEL • S11 3</p> <p>1GRN-WHT • S11 2</p> <p>1BRN • S11 1</p>	<p>3 GRY • Q20</p> <p>2 1GRY-YEL ◊ 1GRY-YEL • Q20</p> <p>1 1BRN-WHT • Q41 [A]</p>		
Airbag connector		G380	
<p>1PNK • R27 5</p> <p>6 GRY-GRN • G383</p> <p>3 RED • R22</p> <p>(*) LTB-RED • G380a 3</p> <p>1LTB-RED • G1 [B] ◊ LTB-RED 3</p> <p>(*) 1PPL-WHT • G380a 4</p> <p>PPL-WHT • C10 [A] 4</p> <p>1GRN-WHT • R27 2</p> <p>1 LTB • G383</p>	<p>5 1PNK • R22</p> <p>6 1GRY-GRN ◊ 1GRY-GRN • R22</p> <p>2 1GRY-GRN</p> <p>4 PPL-WHT ◊ LTB-WHT • R22</p> <p>1 LTB • R22</p> <p>LTB-WHT • T3</p>		
Airbag connector (*)	G380a	Airbag connector (•)	G380
<p>PPL-WHT • C10 [A] 2</p> <p>1LTB-RED • G99 1</p> <p>2 LTB-RED • G380</p> <p>1 PPL-WHT • G380</p>		<p>PPL-WHT • R22 2</p> <p>2 PPL-WHT • C10 [A]</p> <p>1 LTB-RED • R22</p> <p>1 LTB-RED ◊ 1LTB-RED • G99</p>	

(*) from chassis n° PA49720000006

(•) from chassis n°6016879
- 32 -




(•) from chassis n°6016879
 PA497200000005











Rear connector for automatic hood

G400a





Rear connector for automatic hood		G400b
Rear connector for automatic hood	G400c	Fuse for automatic hood system
Fuse for automatic hood control unit	G402	Fuse for automatic hood switch
Fuse for automatic hood switch	G404	Automatic hood power window opening fuse


<p>Automatic hood power window closing fuse</p>	<p>G406</p>	<p>Handbrake switch</p>	<p>H1</p>
			
<p>Reversing light switch</p>	<p>H2</p>	<p>Stop lights switch</p>	<p>H3</p>
			
<p>RH front brake pad switch</p>	<p>H9</p>	<p>LH front brake pad switch</p>	<p>H10</p>
			
<p>Brake fluid minimum level switch</p>	<p>H17</p>	<p>Inertial switch</p>	<p>H20</p>
			

<p>Luggage compartment light switch</p>	<p>H24</p>	<p>Luggage compartment light switch (*)</p>	<p>H24</p>
<p>BLK • N53 WHT-YEL • G73 PNK-BLK • G73 PNK-BLK • F5</p>		<p>PNK-BLK 2 BLK 1</p>	
<p>Bonnet anti-theft device switch</p>	<p>H44</p>	<p>RH hood closing switch</p>	<p>H55a</p>
<p>1WHT • I109 WHT • C10 WHT 2 BLK • G53b 1</p>		<p>WHT • G400a 3 1.5BLK-PPL • G400a BLK-PPL • H56b BLK-PPL • H55b BLK-PPL • H56a PNK-WHT • G400a 1 BLK-PPL 2</p>	
<p>LH hood closing switch</p>	<p>H55b</p>	<p>RH hood cover closing switch</p>	<p>H56a</p>
<p>ORN • G400a 3 1.5BLK-PPL • G400a BLK-PPL • H56b BLK-PPL • H55a BLK-PPL • H56a ORN-WHT • G400a 1 BLK-PPL 2</p>		<p>BLU • G400a 3 1.5BLK-PPL • G400a BLK-PPL • H56b BLK-PPL • H55a BLK-PPL • H55b WHT-BLU • G400a 1 BLK-PPL 2</p>	
<p>LH hood cover closing switch</p>	<p>H56b</p>	<p>Intermediate "5th arc" switch</p>	<p>H58</p>
<p>RED • G400a 3 1.5BLK-PPL • G400a BLK-PPL • H56a BLK-PPL • H55a BLK-PPL • H55b WHT-RED • G400a 1 BLK-PPL 2</p>		<p>1WHT-RED • N81 BLK • H57 BLK • H59 BLK • H60 1BLK • G400a 1BLK B A</p>	

(*) from chassis no. _____
PA497200000005









Hood cover release relay

I107




Hood cover release relay

I107a




Hood cover release relay





I107b




Key-operated supply cutoff relay

I108



















<p>Anti-theft switch relay</p>	<p>I109</p>
	
<p>RH hood closing relay</p>	<p>I112a</p>
	
<p>LH hood closing relay</p>	<p>I112b</p>
	
<p>Hood cover closing relay</p>	<p>I113</p>
	











LH power window closing relay		(I115a)
<p>1YEL-RED • (I115b) —◇— 1YEL-RED 85 1YEL-RED • <u>G400b</u> 1.5RED • (G406) 87 1.5PPL • <u>G399</u> 87a 1LTB-RED • (G1) (E) —◇— LTB-RED 86 30 1.5WHT-GRN • <u>G399</u></p>		
RH power window closing relay		(I115b)
<p>1YEL-RED • (N81) (D) —◇— 1YEL-RED 85 1YEL-RED • (I115a) 1.5BLK • <u>G63b</u> 87 1GRN-BLK • <u>G399</u> 87a 1LTB-RED • (G1) (E) —◇— LTB-RED 86 30 1.5GRY-RED • <u>G399</u></p>		
Automatic hood control relay	(I116)	Automatic hood electric pump relay
<p>1LTB • (B1) —◇— LTB 85 1.5RED • <u>G84</u> 87 1.5BLK • <u>G148b</u> —◇— BLK 86 30 1.5RED-BLK • (G404)</p>	<p>1WHT-BLK • <u>G400a</u> —◇— RED 85 4RED • (P51) 87 1RED-BLK • (N81) (D) 86 4RED • <u>G400c</u> 30</p>	
Minimum engine oil pressure		(L2)
<p>1GRY-BLK • <u>G308</u> 2.0 T.S. 16v 1GRY-BLK • <u>G308</u> 3.0 V6</p>		

Sender for fuel level gauge		L9
<p>PNK • G1 E 2</p> <p>1BLK • G73 1</p>		
Sender for engine coolant temperature gauge and max. temperature warning light contact		L10
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>2.0 T.S. 16v</p> <p>GRY-GRN • C18 1</p> <p>GRY-RED • C18 2</p> </div> <div style="text-align: center;"> <p>3.0 V6</p> <p>GRY-RED • C18</p> <p>GRY-GRN • C18</p> </div> </div>		
Speedometer sensor	L17	RH front phonic wheel inductive sensor
<p>ORN • C10 B 3</p> <p>LTB • G133a</p> <p>LTB • C10 B</p> <p>LTB 2</p> <p>BLK • G53b 1</p>		<p>WHT • G273</p> <p>BRN • G273</p>
LH front phonic wheel inductive sensor	L29	RH rear phonic wheel inductive sensor
<p>GRN • G273</p> <p>BRN • G273</p>		<p>RED • G273</p> <p>BRN • G273</p>

<p>LH rear phonic wheel inductive sensor</p>	<p>L31</p>	<p>Two-level thermal contact</p>	<p>L33</p>
 <p>YEL • G273 BRN • G273</p>	 <p>WHT-BLK • 199 1BLK • G53b 2.0 T.S. 16v 1WHT-RED • G314a 1WHT-RED • I100 3.0 V6 1WHT-RED • G314a</p>		
<p>E.G.R. solenoid valve</p>			<p>L46</p>
<p>2.0 T.S. 16v</p>  <p>1RED-WHT • S41 1RED 1GRY-RED • S11 1GRY-RED</p>		<p>3.0 V6</p>  <p>1GRY-RED • S11 4RED-BLK • S41 1RED</p>	
<p>Luggage compartment opening actuator electromagnet</p>	<p>M12</p>	<p>Fuel flap opening actuator electromagnet</p>	<p>M13</p>
 <p>2.5GRN • I52 2.5BLK • G63b</p>	 <p>2.5GRN-BLK • I53 2.5BLK • G63b</p>		
<p>Evaporation solenoid valve</p>			<p>M15</p>
<p>2.0 T.S. 16v</p>  <p>10RN • S11 1WHT-RED • S41 1BLU-RED ORN-BLK • S46</p>		<p>3.0 V6</p>  <p>10RN • S11 1BLU-RED 4RED-BLK • S41</p>	

LH hood release actuator electromagnet	M26a	LH hood release actuator electromagnet	M26a
<p>SPIDER</p> 			
RH hood release actuator electromagnet	M26b	RH hood release actuator electromagnet	M26b
<p>SPIDER</p> 			
Hood cover release actuator electromagnet	M27a	RH hood cover release actuator electromagnet	M27b
<p>SPIDER</p> 		<p>SPIDER</p> 	
RH hood cover release actuator electromagnet	M27	Automatic hood solenoid valve n.1	M28a
			

<p>Automatic hood solenoid valve no.2</p>	<p>M28b</p>	<p>Automatic hood solenoid valve no.3</p>	<p>M28c</p>
			
<p>Automatic hood solenoid valve no.4</p>	<p>M28d</p>	<p>Automatic hood solenoid valve no.5</p>	<p>M28e</p>
			
<p>Automatic hood solenoid valve no.6</p>	<p>M28f</p>	<p>Hazard warning lights and direction indicators intermittence</p>	<p>N13</p>
			
<p>Electronic windscreen wiper intermittence</p>			<p>N14</p>
			



(*) from chassis no. _____
PA49720000005

Automatic hood control unit		N81	D
Heated rearscreen	O1	High tone horn	O2a
Low tone horn	O2b	Car radio	O4 A









<p>Car radio</p>	<p>O4 B</p>	<p>RH front loud-speaker</p>	<p>O5a</p>
<p>LH front loud-speaker</p>	<p>O5b</p>	<p>RH rear loud-speaker</p>	<p>O5c</p>
			<p>GTV</p>
<p>LH rear loud-speaker</p>	<p>O5d</p>	<p>Cigar lighter - current socket</p>	<p>O6</p>
	<p>GTV</p>		
<p>RH wing mirror defroster</p>	<p>O18</p>	<p>LH wing mirror defroster</p>	<p>O19</p>

(*) up to chassis n° _____

<p>Additional engine fan resistance O22</p> <p>2.5WHT • I99 2.5WHT • G314a 2.5WHT M2.10.4 2.5WHT • I99 6BRN • I100 6BRN • P2 2.5BRN</p> <p>2.0 T.S. 16v</p>	<p>Additional engine fan resistance O22</p> <p>2.5WHT • G314a 2.5WHT 2.5WHT • I99a 6BRN • G314b 2.5BRN</p> <p>2.0 T.S. 16v</p>
<p>Additional engine fan resistance O22a</p> <p>2.5LTB-WHT • G314b 2.5LTB-WHT • O22b 2.5LTB-WHT 2.5WHT • Q41 2.5WHT • O22b 2.5BRN • P2b 2.5BRN • P2a 2.5BRN • Q41</p> <p>3.0 V6</p>	<p>Additional engine fan resistance O22a</p> <p>2.5WHT • I99 2.5WHT 2.5WHT • O22b 4BRN • P2a 4BRN • P2b 6BRN • I100 2.5BRN • O22b</p> <p>2.0 T.S. 16v M2.10.4</p>
<p>Additional engine fan resistance O22b</p> <p>2.5LTB-WHT • G314b 2.5LTB-WHT • O22a 2.5LTB-WHT 2.5WHT • Q41 2.5WHT • O22a 2.5BRN • P2b 2.5BRN • P2a 2.5BRN • Q41</p> <p>3.0 V6</p>	<p>Additional engine fan resistance O22b</p> <p>2.5WHT • I99 2.5WHT 2.5WHT • O22a 4BRN • P2b 4BRN • P2a 6BRN • I100 2.5BRN • O22a</p> <p>2.0 T.S. 16v M2.10.4</p>
<p>RH Tweeter loud-speaker O31a</p> <p>1.5PNK-BLK • O5a 1.5PNK-BLK • G21 1.5PNK-BLK 1 1.5PPL-BLK • O5a 1.5PPL-BLK • G21 1.5PPL-BLK 2</p>	<p>LH Tweeter loud-speaker O31b</p> <p>1.5RED-BLK • O5b 1.5RED-BLK • G23 1.5RED-BLK 1 1.5WHT-BLK • O5b 1.5WHT-BLK • G23 1.5WHT-BLK 2</p>

(*) from chassis n°

<p>Engine cooling fan</p>	<p>P2a</p>	<p>Engine cooling fan</p>	<p>P2b</p>
<p>3.0 V6</p>		<p>3.0 V6</p>	
<p>LH wing mirror motor</p>	<p>P8</p>	<p>RH wing mirror motor</p>	<p>P9</p>
<p>Front RH door lock motor</p>	<p>P10 A</p>	<p>Front RH door lock motor</p>	<p>P10 B</p>
<p>Front LH door lock motor</p>	<p>P11 A</p>	<p>Front LH door lock motor</p>	<p>P11 B</p>


















<p>Front RH power window motor</p>	<p>P14</p>	<p>Front LH power window motor</p>	<p>P15</p>
 <p>1.5WHT-RED • B21a A 1.5PPL-WHT • B21a B</p>		 <p>1.5PPL-YEL • G23 A 1.5WHT-GRN • G23 B</p>	
<p>Electric fuel pump</p>	<p>P18</p>	<p>Windscreen and rearscreen washer pump</p>	<p>P19</p>
 <p>1.5PPL-BLK • H20 A 1.5PNK-YEL • G73 B</p>		 <p>1PNK-BLK • P27 1 1BLK • G53b 2</p>	
<p>Windscreen wiper motor with control unit</p>	<p>P27 A</p>	<p>Windscreen wiper motor with control unit</p>	<p>P27 B</p>
 <p>1PNK-BLK • P19 3 1GRY-WHT • N14 4 1ORN • N14 5 1GRY-BLK • G99 2 1BLK • G53b 1</p>		 <p>1.5ORN-BLK • G1 3 1WHT-BLK • G99 4 1.5GRN • N14 2 1.5PNK-BLK • G99 1.5PNK-BLK • N14 1</p>	
<p>.RH headlamp aiming motor</p>	<p>P35a</p>	<p>LH headlamp aiming motor</p>	<p>P35b</p>
 <p>YEL • G99 YEL • P35b 1BLK • G53a 3 1YEL-BLK • P35b 1YEL • G1 1</p>		 <p>YEL • G99 YEL • P35a 1BLK • G53b 3 1YEL • G1 A 1 1YEL-BLK • P35a</p>	

<p style="text-align: center;">Automatic hood control pump</p>	<p>P51</p>
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div>	
<p style="text-align: center;">Heater fan</p>	<p>Q1</p>
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div>	
<p style="text-align: center;">Heater fan control</p>	<p>Q4 A</p>
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div>	
<p style="text-align: center;">Heater fan control</p>	<p>Q4 B</p>
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div>	

Heater fan speed adjustment resistance		Q5
<p>1GRN • Q4 [B] 4</p> <p>1.5GRY-RED • Q4 [B] 3</p> <p>1.5WHT-GRN • Q4 [A] 2</p> <p>2.5BLK-BLU • Q1 1.5BLK-BLU 1</p> <p>2.5BLK-BLU • Q4 [A]</p>	<p>1GRN • Q4 [B] 4</p> <p>1GRN • Q69</p> <p>1.5GRY • Q4 [B] 3</p> <p>1.5WHT • Q4 [A] 2</p> <p>2.5BLK-BLU • Q1 1.5BLK-BLU 1</p> <p>2.5BLK-BLU • Q4 [A]</p>	
Minimum pressure switch	Q9	Compressor electromagnetic coupling
<p>2.0 T.S. 16V</p> <p>M2.10.4 1GRN-WHT • G133a 2</p> <p>GRY • G337 2</p> <p>BLU • Q20 1</p> <p>M2.10.4 1GRN-WHT • Q20 1</p>		<p>1BRN • Q41 [A]</p>
Heating and ventilation fan relay	Q15	Min. and max. sensor pressure contact (Trinary)
<p>2.5BLK • G43 85</p> <p>2.5ORN • Q1 87</p> <p>PNK • G43 86</p> <p>2.5ORN • G313 30</p>		<p>3.0 V6</p> <p>GRY-BLK • Q41 [A] 4</p> <p>4BLK • Q41 [C]</p> <p>4BLK • G53a 1BLK 3</p> <p>GRY • G337 2</p> <p>1GRY-YEL • G337 1GRY-YEL 1</p> <p>1GRY-YEL • Q41 [A]</p>
Min. and max. sensor pressure contact (Trinary)	Q20	Min. and max. sensor pressure contact
<p>2.0 T.S. 16v</p> <p>GRY-BLK • Q41 [A] 4</p> <p>4BLK • Q41 [C]</p> <p>4BLK • G53a 1BLK 3</p> <p>BLU • Q9 2</p> <p>1GRY-YEL • G337 1GRY-YEL 1</p> <p>1GRY-YEL • Q41 [A]</p>		<p>M2.10.4</p> <p>1GRY-BLK • G133a 6</p> <p>1GRN-WHT • Q9 2</p> <p>1PPL • G133a 3</p> <p>1GRN • Q32 1</p> <p>1BLK • G53a 4</p>

(**) up to chassis n° _____



<p>Electromagnetic coupling relay</p>		<p>Q22</p>
<p>Auxiliary relay for heating and ventilation</p>		<p>Q32</p>
<p>Air recirculation flap control motor</p>	<p>Q27</p>	<p>Fuse for conditioning system (30A)</p>

<p>Fuse for conditioning system (30A) (*)</p>	<p>Q39</p>	<p>Fuse for conditioning system (15A) (*)</p>	<p>Q40</p>
<p>3.0 V6 </p> <p>4RED • G56 —◇— 2.5RED</p>  <p>2.5RED • P2b</p>		<p>2.0 T.S. 16v </p> <p>4RED • A1</p>  <p>2.5RED • Q41 D</p>	
<p>Set of relay and fuses for air conditioner</p>	<p>Q41 A</p>	<p>Set of relay and fuses for air conditioner</p>	<p>Q41 B</p>
<p>1BRN-WHT • G337 3 </p> <p>1BRN • Q11 4</p> <p>GRY-BLK • Q20 5</p> <p>2.5WHT-RED • G314a 7</p> <p>ORN • G38 6</p>  <p>1GRY-YEL • Q20 —◇— 1GRY-YEL 2</p> <p>1GRY-YEL • G337 —◇— 1GRY • G38 1</p>		<p>2.0 T.S. 16v 2.5BRN • P2 2 </p> <p>M2.10.3</p> <p>2.0 T.S. 16v 2.5LTB-WHT • G314b 1 </p> <p>M2.10.3</p> <p>2.5BRN • P2a —◇— 3.0 V6 2</p> <p>2.5BRN • P2b —◇— 2.5BRN 2</p> <p>2.5WHT • O22a —◇— 2.5WHT • O22b</p> 	
<p>Set of relay and fuses for air conditioner</p>	<p>Q41 C</p>	<p>Set of relay and fuses for air conditioner</p>	<p>Q41 D</p>
<p>M2.10.3 2.0 T.S. 16v 2.5WHT • G314a 2 </p> <p>1BLK • Q20 —◇— 4BLK • G53a 1</p> <p>2.5LTB-WHT • G314b —◇— 2.5LTB-WHT • O22a 1</p> <p>2.5LTB-WHT • O22b —◇— 2.5WHT 2 3.0 V6</p> 		<p>4RED • G56 —◇— 2.5RED-BLK</p> <p>(*) 2.0 T.S. 16v 2.5RED • Q40 </p> <p>M2.10.3</p> 	
<p>Compressor and air recirculation engagement switches</p>	<p>Q68</p>	<p>Heater fan 1st speed relay</p>	<p>Q69</p>
<p>WHT-BLK • Q4 B 2 </p> <p>PPL • Q4 B 4</p> <p>2.5BLK • G43 —◇— BLK 5</p> <p>YEL-BLK • G43 —◇— YEL-BLK 6</p> <p>PNK • G43 —◇— PNK 3</p> <p>LTB-BLK • Q27 —◇— LTB-BLK 1</p> <p>LTB-BLK • Q4 B</p> 		<p>2.5BLK • G43 —◇— 1BLK 30 </p> <p>GRY-RED • Q4 B 85</p> <p>1GRN • G313 87b</p> <p>1GRN • Q4 B —◇— 1GRN 87</p> <p>1GRN • Q5 —◇— 86 BLK-PPL 30</p> 	


(*) from chassis n° _____

Airbag control unit		(R22)
<p>1 BLU</p> <p>2 1GRY-GRN</p> <p>3 LTB-WHT</p>	<p>4 WHT-RED</p> <p>5 1PNK</p> <p>6 1LTB</p> <p>7 BRN</p> <p>8 BLK</p> <p>9 RED</p> <p>10 BRN</p>	
Airbag control unit (*)		(R22)
Capsule on steering wheel for airbag	(R23)	Passenger's side airbag capsule
Capsule on RH pretensioner	(R28)	Capsule on LH pretensioner


(*) from chassis n°6016879
PA49720000006




Elettroiniettori **S3**



Air flow meter **S5**



Engine temperature sensor **S7**



Motronic control unit

S11

2.0 T.S. 16V

M2.10.3

1 1.5LTB-YEL • A8 [1]

2 2.5BLK • G60

3 1GRY-BLK • S12a

4 1LTB-BLK • S29

5 1ORN • M15

6 1BRN-WHT • G133a

7 1WHT-BLK • S5

8 1GRN • S52

9 1LTB • G133a

10 1GRN • S35

11 1RED • S20

12 1GRY-GRN —◇— 1LTB-WHT • S38
 GRY-RED • S52

13 1LTB-WHT • T1

14 1.5BLK • G60

16 1YEL-BLK • S3 [3]

17 1YEL • S3 [1]

18 2.5RED • S46

19 1.5BLK —◇— 1.5BLK • G60

20 1.5LTB-BLK • A8 [3]

21 1.5LTB-WHT • A8 [4]

22 1ORN-BLK • S29



24 1.5BLK • G60

26 1GRN • S5

27 1PNK • S42

28 1BLK • S35

30 1WHT —◇— 1WHT • S34
 1WHT • S38
 1WHT • S7
 1WHT • S20



32 1BRN-BLK • G337

33 1GRY-RED • L46

34 1YEL-RED • S3 [2]

35 1YEL-GRN • S3 [4]

36 1GRN-BLK • S41

37 1.5GRY —◇— 1RED-WHT • S41

38 1.5LTB-RED • A8 [2]

40 1GRN-WHT • G337

41 1GRY-YEL • G337

45 1BRN • S7

48 1BLK • S31

49 1YEL • S31

51 RED-GRN • G133b

52 1BLK-PPL • S12c

53 1PPL-WHT • S38

54 1PNK-BLK • S34

55 1WHT-GRN • G133b

Motronic control unit

(S11)

3.0 V6

1 1GRY-BLK • (S12a)

2 1ORN-BLK • (S29)

3 1YEL • (S3) [1]

4 1YEL-BLK • (S3) [2]

5 1YEL-GRN • (S3) [3]

6 1.5BLK • G131a

8 1RED-GRN • G133b

9 1GRY-RED • (L46)

11 BLK • (S35)

12 GRN • (S35)

14 1GRN • (S5)

16 BLK • (S31)

24 1GRY • (A8)

25 1LTB • (A8)

26 1RED • (S46)

27 1GRN-YEL • (S41)

28 1BLK —◇— 1BLK • G131b

29 1LTB-BLK • (S29)

31 1YEL-RED • (S3) [4]



32 1YEL-BLU • (S3) [5]

33 1GRY-YEL • (S3) [6]

34 1.5BLK • G131a

36 1ORN • (M15)

41 1WHT-BLK • (S5)



42 1LTB • G133a

43 YEL • (S31)

44 1GRY • (S52)

47 1BRN-WHT • G133a

48 1BRN • G337

52 1.5GRN • (A8)

54 1.5RED-BLK —◇— 4RED-BLK • (S41)

55 2.5BLK —◇— 2.5BLK • G131a

56 1PNK-BLK • (S42)

59 1LTB-WHT • (S38)

64 1GRN-WHT • G337

65 1GRY-YEL • G337

69 RED • (S20b)

70 YEL • (S20a)

71 1BLK —◇— BLK • (S20a)

WHT • (S20b)

72 1WHT —◇— 1WHT • (S34)

1WHT • (S7)

1WHT • (S38)


73 1YEL • (S38)









77 1PNK-WHT • (S34)


78 1BRN • (S7)


87 1LTB-YEL • (T1)

88 1WHT-GRN • G133b




<p style="text-align: center;">Phase variator</p> <p style="text-align: right;">(S15)</p> <p style="text-align: right;">2.0 T.S. 16v</p> 		<p style="text-align: center;">Pinging sensor</p> <p style="text-align: right;">(S20)</p> <p style="text-align: right;">2.0 T.S. 16v</p> 	
<p style="text-align: center;">Pinging sensor</p> <p style="text-align: right;">(S20a)</p> <p style="text-align: right;">3.0 V6</p> 		<p style="text-align: center;">Pinging sensor</p> <p style="text-align: right;">(S20b)</p> <p style="text-align: right;">3.0 V6</p> 	
Idle adjustment actuator		(S29)	
<p style="text-align: right;">2.0 T.S. 16v</p> 		<p style="text-align: right;">3.0 V6</p> 	
Rpm and crankshaft position sensor		(S31)	
<p style="text-align: right;">2.0 T.S. 16v</p> <p style="text-align: right;">M2.10.3</p> 		<p style="text-align: right;">2.0 T.S. 16v</p> <p style="text-align: right;">M2.10.4</p> 	






Main relay

S41



2.0 T.S. 16v

M2.10.3




M2.10.4

2.0 T.S. 16v

Secondary relay

S42




2.0 T.S. 16v


3.0 V6

Lambda probe fuse

S45



3.0 V6



<p>Connector for ALFA TESTER (Motronic and ALFA ROMEO CODE)</p>		<p>T1</p>	
<p>2.0 T.S. 16v</p>		<p>3.0 V6</p>	
<p>Connector for ALFA TESTER (airbag)</p>	<p>T3</p>	<p>Connector for ALFA TESTER (anti-theft device)</p>	<p>T7</p>
<p>Connector for ALFA TESTER (ABS)</p>		<p>T8</p>	
<p>Diagnosis connector for ALFA ROMEO TESTER (automatic hood)</p>		<p>T13</p>	